



# **2016**

## **OWNERS MANUAL**

**SKI NAUTIQUE 200 - OPEN BOW**  
**SKI NAUTIQUE 200 - CLOSED BOW**  
**SPORT NAUTIQUE 200 - OPEN BOW**





Dear Nautique Owner,

Welcome to the Nautique Family! For over 90 years, Nautique has been dedicated to providing our customers and their families with the finest inboard boats available. It's our passion to create the best performing boats in the industry. Boats that allow you to escape the routine of everyday life. Our customers don't just own a Nautique, they live the Nautique life.

Your boat has been built with the best material and workmanship available, a legacy handed down from our founder. Our wealth of experience gives us the edge in innovation, quality and performance. We have the most dedicated and loyal employees in the industry. Hands down. Every day, our employees do more than just punch a clock; they take personal pride in every boat that comes down the line.

Review this Owner's Manual for your boat. We have assembled this manual to inform you about your Nautique and educate you further on boating. Please pay particular attention to the safety statements labeled as **DANGER, WARNING, CAUTION** and **NOTICE**. These statements alert you to possible safety hazards to avoid so you can have a safer boating experience. There are also many tips and tricks on care and maintenance sprinkled throughout the manual. Boating is very important to us and we would like you to enjoy many years of boating in your Nautique.

By purchasing a Nautique, you have taken the first step in trading your old lifestyle for a new one. Now that you own a Nautique, life as you know it will never be the same.

Enjoy the Nautique Life.

The Nautique Team

Trust in the Lord with all thine heart; and lean not unto thine own understanding. In all thy ways acknowledge him, and he shall direct thy paths.

Proverbs 3:5-6

---

## Record Important Information

In addition to this manual, your Nautique boat is supplied with component manufacturer information such as instructions, warranties or other important information. Read these materials carefully since improper operation and maintenance can void the warranty and jeopardize personal safety.

Safeguard information about your Nautique boat, by recording the Hull Identification Number (HIN) and the model of your boat, and the model and serial numbers of your engine/transmission and trailer, if applicable.

Your HIN is located on the top right side of the transom, above the water line. The U.S. Coast Guard requires that your HIN be permanently affixed and remain on the top right side of the transom. The first two digits refer to the country of manufacture (U.S.). The next three digits represent the manufacturer, Nautique Boat Company, Inc. (CTC). The next five digits are the boat's serial number. The next digit is a letter from "A" where "A" = January through "L" where "L" = December, designating the month the boat was made.

The last three digits represent the last digit of the year the boat was built and the final two digits of the boat model year. A boat built in July 2006 is actually a 2007 model boat. Example: A boat with "607" as the last digits indicates the boat was built in 2006, but it is a 2007 model boat.

### Hull

HIN \_\_\_\_\_

Date Purchased \_\_\_\_\_

Dealer/Phone \_\_\_\_\_

Ignition Key Number \_\_\_\_\_

Registration Number/State \_\_\_\_\_

### Engine

Model Number \_\_\_\_\_

Serial Number \_\_\_\_\_

### Trailer

Model Number \_\_\_\_\_

Serial Number \_\_\_\_\_

### Accessory

Model Number \_\_\_\_\_

Serial Number \_\_\_\_\_

The identification numbers are important! Keep a copy of these numbers stored in a safe place off the boat. In case of theft, damage, etc., report these numbers to the local authorities, your insurance agent and your Nautique dealer.



---

# Boater's Checklist

For improved safety and enjoyment, check each of these items:

## Check Before You Launch Your Boat:

- Read both the engine and the boat operator manuals.
- Drain plug (Securely in place?)
- Propeller Condition (Prop nut tight and secured, no cracked or bent blades, prop turns freely?)
- Steering System (Working smoothly and properly, self locking nuts in place?)
- Battery (Fully charged, cable terminals clean and tight?)
- Capacity Plate (Are you overloaded?)
- Weather conditions (Safe to go out?)
- Fuel and Oil (Sufficient for trip, check bilge area for gas odor, no leaks?)
- Hoses and Connectors (No leaks or damage?)
- Electrical Equipment (Lights, horn, pumps, etc.?)
- Safety Equipment (Fire extinguisher, bailer, paddle, anchor and line, mooring lines, signaling device, tool kit, first aid kit, first aid manual?)
- Personal Flotation Devices for all occupants
- Float Plan submitted to Responsible Person (Verbal or written?)

## Check Before You Start Your Engine:

- Fuel (Sufficient for trip, check bilge area for gas odor?)
- Control Lever in Neutral
- Capacity Plate (Are you overloaded?)
- Personal Flotation Devices for all occupants
- Seating (Everyone in proper place?)
- Engine Stop Switch and Lanyard (Operational and securely fastened?)
- No one in water near boat
- Keep firm and continuous grip on steering wheel
- Engine Cooling Water Valve open



---

## Restricted Areas

Before boating, check with Local, State and Federal authorities to identify restricted areas. Because of the threat of terrorism, the U.S. Coast Guard has and will continue to implement strict limits on watercraft near U.S. Navy and Coast Guard ships and other potential targets.

## Proposition 65

### ⚠ WARNING

A wide variety of components used on this vessel contain or emit chemicals known to the State of California to cause cancer and birth defects and other reproductive harm.

**EXAMPLES INCLUDE:**

Engine and generator exhaust.  
Engine and generator fuel, and other liquids such as coolants and oil, especially used motor oil.  
Cooking fuels.  
Cleaners, paints and substances used for vessel repair.  
Waste materials that result from wear of vessel components.  
Lead from battery terminals and from other sources such as ballast or fishing sinkers.

**TO AVOID HARM:**

Keep away from engine, generator and cooking fuel exhaust fumes.  
Wash area thoroughly with soap and water after handling the substances above.

California Health & Safety Code 25249.5-.13

KC-0206-B

## Emission Control Warranty Information




The engine in your Nautique boat meets the strict requirements set forth by the California Air Resources Board (CARB). The engine has a special environmental tag and the boat has this label affixed to it. The tag and the label are required by the California Air Resources Board (CARB). The label has 1, 2, 3 or 4 stars. The label **MUST** be affixed to the boat, if the boat is operated in the state of California and/or bordering waters.



---

# Boating Terminology



CORC001

\* An easy way to remember PORT side from STARBOARD side is “PORT” and “LEFT” both have four letters.

## Product Improvement

Because of our policy of continuous product improvement, the illustrations used in this manual may not look the same as on your boat and are intended only as representative reference views. Some illustrations may also show optional accessories which may or may not be available for your boat. Many optional accessories can only be installed at the time the boat is manufactured and cannot be installed by your dealer. Your dealer will be happy to provide details on installing accessories.



# Table of Contents

Welcome.....	i	Safety and Required	
Record Important		Equipment .....	1-15
Information.....	ii	Navigation Lights .....	1-16
Boater's Checklist.....	iii	Emergency Safety	
Restricted Areas .....	iv	Lanyard .....	1-16
Proposition 65 .....	iv	Personal Flotation	
Emission Control Warranty		Devices.....	1-18
Information .....	iv	Fire Extinguisher .....	1-20
Boating Terminology.....	v	Horn or Whistle .....	1-20
Product Improvement.....	v	Bilge Pump(s).....	1-21
<b>Boating Safety .....</b>	<b>1-1</b>	Visual Distress Signals .....	1-21
Introduction.....	1-1	Recommended Safety	
About this Owner's		Equipment .....	1-22
Manual .....	1-2	<b>General Boating Safety</b>	
Signal Words and Symbols		Topics .....	1-23
Used In This Manual .....	1-3	Safe Speed.....	1-23
Basic Safety Rules .....	1-4	Passenger Safety .....	1-23
Pre-operation Check		Carbon Monoxide	
List – Before Leaving		Safety .....	1-24
the Dock.....	1-5	Proper Loading .....	1-27
Precautions While		Weighting Your Boat	
Underway .....	1-7	During Watersport	
Safety While Maintaining		Activities .....	1-28
the Vessel .....	1-10	Visibility from the Helm ...	1-30
Owner Responsibility and		Boating Under the	
Boating Education.....	1-12	Influence .....	1-31
Important Safety		Product Misuse .....	1-32
Information .....	1-12	Reporting Accidents .....	1-32
Responsibilities of Boat		Rendering Assistance .....	1-32
Owner and Operators.....	1-12	Hazardous Conditions .....	1-33
Registration.....	1-13	Environmental	
Insurance .....	1-13	Concerns .....	1-34
Boating Safety Education		<b>On Product Warning</b>	
Opportunities .....	1-14	Labels.....	1-37
Operation by Minors		Warning Labels &	
and Licensing .....	1-15	Locations.....	1-37
		Basic Rules of the Road .....	1-50





Boating Regulations.....	1-50	200 Open Bow Deck	
Encountering Another		Layout.....	2-10
Vessel.....	1-51	200 Closed Bow Deck	
Aids to Navigation .....	1-55	Layout.....	2-12
Night Running .....	1-61	200 V-Drive Deck Layout ....	2-14
Watersports Safety .....	1-64	200-OB Seating Area .....	2-16
Hand Signals.....	1-66	200-CB Seating Area.....	2-17
Towed Person Safety		200-V Seating Area .....	2-18
Responsibilities .....	1-66	Standard and Optional	
Additional Precautions		Equipment .....	2-19
for Towed Skier/Rider ....	1-68		
Tow Line Guidelines.....	1-70	<b>Controls and Indicators .....</b>	<b>3-1</b>
Fallen Skier or Rider.....	1-71	Steering .....	3-1
Develop WATER SENSE ..	1-72	Hydro-Gate™ Control and	
Emergency Procedures .....	1-77	SportShift™ .....	3-2
Explosion and Fire.....	1-77	Shifter/Throttle.....	3-4
Swamping and Flooding..	1-78	Emergency Stop Switch .....	3-5
Capsizing.....	1-79	Nautique Dash Pod .....	3-6
Staying Afloat.....	1-79	Gauges.....	3-6
Collisions.....	1-79	Speedometer Calibration ..	3-8
Grounding .....	1-80	Control Switches.....	3-8
Person Overboard .....	1-80	12-Volt Port.....	3-11
Drowning .....	1-81	Nautique Digital	
Medical Emergency.....	1-81	Cruise .....	3-12
Operation Failure.....	1-81	Team Dash Pod .....	3-15
Towing.....	1-81	Keypad.....	3-15
		Switches .....	3-20
<b>200-OB, 200-CB, 200-V.....</b>	<b>2-1</b>	Nautique LINC 2.0.....	3-22
Specifications .....	2-1	Product Information.....	3-22
200-OB, 200-CB .....	2-1	Basic Navigation	
200-V .....	2-1	Features.....	3-23
200 Nautique Dash Pod and		Quick Access Key	
Console.....	2-3	Features .....	3-24
200-OB, 200-CB Team Dash		Nautique LINC 2.0 – River	
Pod and Console .....	2-5	Mode .....	3-44
Keys .....	2-5	Nautique LINC 2.0 – River	
200-V Team Dash Pod and		Mode in Integrated	
Console.....	2-7	Zero Off 3 Event.....	3-52
Keypad .....	2-9	MENU Options .....	3-55



LINC 2.0 General	200-OB, 200-CB .....	4-2
Troubleshooting Guide ...3-63	200-V .....	4-3
Standard Equipment.....3-64	Ballast Tanks and Bilge	
Watersports Tow Point ....3-64	System .....	4-4
Tow Rope Attachment –	Ballast Tank Valves –	
Center.....3-65	200-V.....	4-5
Tow Rope Attachment –	Port and Starboard	
Tower Pylon.....3-66	Ballast Tanks – 200-V .....	4-6
Bow Features - Open	Bilge System – 200-OB,	
Bow Only.....3-67	200-CB, 200-V.....	4-7
Driver's Seat	12-Volt System – 200-OB,	
Adjustment.....3-68	200-CB .....	4-8
Rearview Mirror	12-Volt System – 200-V	
Adjustment.....3-69	Only .....	4-9
Observer's Seat.....3-70	Cockpit Heater System –	
200 Engine Box Cover/	Optional .....	4-10
Lifting/Removal.....3-71		
Walk-Thru Windshield	<b>Getting Underway .....</b>	<b>5-1</b>
Opening/Latching.....3-72	Safety Checklist.....	5-1
Dash Storage.....3-72	Safety Equipment .....	5-2
Boarding Platform .....	Fueling.....	5-2
3-73	Gasoline Containing	
Engine Cooling Water	Alcohol.....	5-3
Intake Valve .....	When Fueling .....	5-4
3-75	After Fueling.....	5-5
Battery Disconnect	Boarding.....	5-5
Switch .....	Boat Planing.....	5-5
3-76	Pre-Operation Checks.....	5-6
Nautique Electrical	Flooded Engine .....	5-11
System.....	Break In Procedure.....	5-13
3-76	Propeller Selection.....	5-13
Rudder Remote Lube .....	Shifting .....	5-14
3-76	Steering .....	5-14
Fuel Tank.....	Stopping .....	5-15
3-77	Docking.....	5-15
Optional Equipment.....		
3-78	<b>Running.....</b>	<b>6-1</b>
Folding Instructions for	Hydro-Gate™ .....	6-1
Flight Control Tower®.....	Maneuvering Techniques .....	6-2
3-78		
Bimini Top.....		
3-80		
Battery Charger .....		
3-81		
Optional Accessories .....		
3-81		
Stereo Systems .....		
3-81		
<b>Boat Systems .....</b>		
<b>4-1</b>		
Fuel System .....		
4-1		



Tow Pattern.....	6-3	Tunable Rudder .....	7-19
Freezing Temperatures.....	6-4	Rudder Remote Lube	
Anchoring .....	6-4	Fitting .....	7-20
Dropping Anchor .....	6-5	Checking Transmission	
Weighing (Pulling In)		Fluid.....	7-20
Anchor.....	6-5	Checking V-Drive Unit	
Performance Boating .....	6-6	Fluid (200-V Only) .....	7-21
Propellers .....	6-6	<b>Troubleshooting.....</b>	<b>8-1</b>
<b>Care and Maintenance .....</b>	<b>7-1</b>	Trouble Check Chart.....	8-2
General Maintenance.....	7-1	Performance .....	8-2
Engine Intake Raw Water		Electrical.....	8-3
Strainer.....	7-2	<b>Storage .....</b>	<b>9-1</b>
Bilge Pumps .....	7-4	Lifting Rings.....	9-1
CE Bilge Discharge Filter.....	7-4	Winterizing Your Boat.....	9-3
Cartridge Replacement.....	7-5	Winterizing the Heater	
Ballast Filtration System		System (in Closed-Cooled	
(optional) .....	7-6	Engines Only) .....	9-4
Propeller.....	7-7	Check for Water in Your Fuel	
Removal.....	7-7	System .....	9-5
Installation .....	7-8	Trailer/Trailering .....	9-7
Through-Hull Fittings.....	7-8	Hitch.....	9-7
Quick Oil Drain System .....	7-9	Wiring.....	9-7
Salt Water Boating.....	7-10	Security.....	9-7
Freshwater Flushing Kit -		Towing Your Boat .....	9-8
Optional .....	7-10	Long Trips .....	9-9
Proper Use of Freshwater		<b>Glossary.....</b>	<b>G-1</b>
Flushing Kit.....	7-10	<b>Warranty .....</b>	<b>W-1</b>
Coastal Edition.....	7-11	<b>NAUTIQUE LIMITED</b>	
Battery Maintenance .....	7-12	<b>WARRANTY.....</b>	<b>W-1</b>
Battery Cable Warning		Lifetime Limited	
Alarm.....	7-14	Warranty .....	W-1
Gelcoat Maintenance .....	7-15	Transferable Lifetime	
Care of Metal .....	7-16	Limited Warranty.....	W-1
Care of Glass .....	7-17	Boat Five (5) Year	
Adhesive-Backed		Transferable Limited	
Non-Skid.....	7-17	Warranty .....	W-2
Vinyl Maintenance and			
Cleaning .....	7-17		



---

Gel Coat Three (3) Year Transferable Limited Warranty .....	W-2
Engine/Power Train Warranty .....	W-2
Exceptions .....	W-2
Procedure .....	W-4
NAUTIQUE COASTAL EDITION LIMITED	
WARRANTY.....	W-5
Lifetime Limited Warranty .....	W-5
Transferable Lifetime Limited Warranty.....	W-5
Boat Three (3) Year Transferable Limited Warranty .....	W-6
Gel Coat One (1) Year Transferable Limited Warranty .....	W-6
Engine/Power Train Warranty .....	W-6
Exceptions .....	W-7
Procedure .....	W-9





## **Section I**

# **Boating Safety**

### **Introduction**

Congratulations on your purchase of a new high-performance recreational tow boat. Your Nautique boat has been constructed to meet and/or exceed all U.S. Coast Guard (USCG) and National Marine Manufacturers Association (NMMA) requirements applicable at the time of its manufacture. However, it is still your responsibility as the boat owner to ensure the boat is operated in a safe manner and is properly maintained.

Before operating this vessel, please take the time to get acquainted with the vessel and its various features and controls. We recommend that you carefully read and familiarize yourself with this Owner's Manual and all on-product safety labels prior to operating your new watercraft. This manual contains important information on Boating Safety, Boating Rules, Proper Operation and Maintenance of your boat. This manual provides a guideline for proper operation and maintenance of your boat, and you should consider it a permanent part of your vessel. In the event that this boat is sold, this manual should be included along with the boat to ensure that it will provide the same important information to the next owner.

# Section I

---

## About this Owner's Manual

The recommended practices and warnings in this manual represent sound advice for recreational boating and identify common risks encountered by boaters engaging in towed watersport activities. Read and understand the contents of this manual. Ask questions of a boating professional if anything in this manual does not make sense to you. The manual does not cover all instances of risk or danger, so please use common sense and good judgment when boating. If you follow the advice provided in this manual you will significantly reduce risk to yourself, your passengers, towed participants, and other boaters.

This manual is not intended to be a substitute for taking a course on boating safety nor is it a substitute for boating experience. It is recommended that if you are unfamiliar with the use and operation of a boat you seek advice and training from a qualified individual or organization. Check with your local marine law enforcement agency or dealer for more information about boating safety classes in your area.

The precautions listed in this manual and on the boat are not all-inclusive. If a procedure or method is not specifically recommended, YOU must be satisfied that it is safe for you and your passengers, and that the boat will not be damaged or made unsafe as a result of your decision. Remember - always use caution and common sense when operating and maintaining your boat!



## Signal Words and Symbols Used In This Manual

Throughout this manual specific precautions and symbols identify safety-related information. You will find **DANGER**, **CAUTION**, **WARNING**, **NOTICE** and **SAFETY INSTRUCTIONS** symbols which require special attention. Please read them carefully and follow these precautions as indicated! They will explain how to avoid hazards that may endanger you, your passengers, towed participants, and other boaters. **PLEASE REVIEW ALL SAFETY INFORMATION.**



**DANGER** indicates a hazardous situation which, if not avoided, will result in death or serious injury.



### **WARNING**

**WARNING** indicates a hazardous situation which, if not avoided, could result in death or serious injury.



### **CAUTION**

**CAUTION** indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

### **NOTICE**

*NOTICE is used to address practices not related to physical injury.*

### **SAFETY INSTRUCTIONS**

*SAFETY INSTRUCTIONS (or equivalent) signs indicate specific safety-related instructions or procedures.*



# Section I

---

## Basic Safety Rules

**Make sure you understand all of the operating instructions prior to attempting to operate this boat.** Boating-related accidents are generally caused by the operator's failure to follow basic safety rules or written precautions. Most accidents can be avoided if the operator is completely familiar with the boat and its operation, follows recommended practices, and is able to recognize and avoid potentially hazardous situations.



### **WARNING**

**Failure to adhere to these warnings may result in severe injury or death to you and/or others.**

**Past accident data shows that most FATALITIES involve actions which cause falls or ejections overboard, mishaps with towed persons, propeller strikes, collisions, and carbon monoxide exposure.**

**Past accident data shows that most INJURIES are associated with collisions, mishaps with towed persons, falls or ejections overboard, being struck by the propeller, and fires and explosions.**

**These incidents are mostly caused by operator inattention, operator inexperience, reckless operation, alcohol/drug use, excessive speed, passenger or towed person behavior, and violation of navigation rules.**

**Failure to observe the safety recommendations contained in this manual may result in severe personal injury or death to you or to others.** Use caution and common sense when operating your boat. Don't take unnecessary chances! Basic safety rules are outlined in this section of the manual.





## Pre-operation Check List - Before Leaving the Dock



### **WARNING**

**Failure to follow these precautions may result in severe injury or death to you and/or others.**

### **The operator shall:**

- Check that weather conditions are safe for boating. It is the driver's responsibility to determine if weather or other factors have created an unsafe boating environment. Boaters must continuously be aware of weather conditions. Sudden storms, wind, water conditions, lightning, etc., can unexpectedly put boaters in grave danger. Always check the local weather report before going boating.
- Check that drain plugs are securely in place.
- Check bilge pump, horn, lights, blower and other equipment to verify they are operating properly.
- Verify that the emergency cutoff switch lanyard is in proper operating condition and is properly affixed to the driver.
- Check the operation of the steering system. Verify that the steering is operational before launching the boat. If the boat is already in the water, verify proper steering wheel operation at low speed. Turn the steering wheel full stop in both directions and verify proper rudder movement. Ensure that there is no binding or stiffness in the steering wheel rotation. Binding and stiffness is an indication that the steering cable needs replacement. Failure of the steering cable will result in loss of control of the boat.
- Ensure that the load of persons, ballast, and equipment is within the limits stated on the USCG Maximum Capacities Plate and is properly distributed based on instructions in this manual.
- Check that all safety equipment and life jackets, personal flotation devices (PFDs), and throwable cushions are in good condition and suitable for your boat and passenger load.
- Inform all passengers where safety equipment is located and how to use it.



# Section I

---

- Have at least one other passenger who is capable of operating the boat safely in case of an emergency.



## **WARNING**

**Gasoline vapors can explode. Before starting engine operate blower for 4 minutes and check engine compartment bilge for gasoline vapors.**

- It is very important to open the engine cover and check the engine compartment and bilge for liquid gasoline and gasoline vapors prior to each use of your boat and after refueling. Failure to do so may result in fire or explosion as well a serious injury or death to you and/or others.
- If you see liquid gasoline in the engine compartments/bilge or smell gasoline vapors, DO NOT attempt to start the engine. Liquid gasoline in the bilge is an extreme fire and explosion hazard which may cause injury or death. Find and fix the source of the leakage, remove the liquid gasoline from the bilge. Then ventilate the engine compartment/bilge and run the blower to remove all gasoline vapors before starting the engine. If gasoline vapors persist after running the blower, DO NOT attempt to start the engine. Look for a cause and remedy before starting the engine.
- Always operate blower below cruising speed and after stopping the boat.



## Precautions While Underway



### **DANGER**

Failure to follow these precautions will result in serious injury or death.

The operator shall:

- Check that the area behind the boat is all clear before starting the engine to **AVOID PROPELLER INJURY** to persons in the water behind the boat or on the swim platform.
- Turn off the engine prior to anyone occupying the swim platform or being in the water behind the boat to **AVOID PROPELLER INJURY**. Being in neutral gear is insufficient; the propeller may still be turning, or engine may be inadvertently shifted into gear.
- Not back the boat toward persons in the water behind the boat to **AVOID PROPELLER INJURY**.
- Not allow people to be on or near the swim platform or in the water near or around the swim platform while the engine is running because **CARBON MONOXIDE** will exist around the back of the boat when the engine is running. Engine exhaust contains carbon monoxide, which is a deadly, odorless, colorless gas.
- Not operate the engine in a confined space or while tethered to another vessel as **CARBON MONOXIDE** will be around the boats.
- Not go under the boat cover with the engine running or shortly after the engine has been running because **CARBON MONOXIDE** may remain under the cover. Remove cover to ventilate the area.



### **WARNING**

Failure to follow these precautions may result in severe injury or death to you and/or others.



# Section I

---

## The operator shall:

- Follow safe operating practices, the “Rules of the Road”, and the Watersports Responsibility Code.
- Not operate a boat if under the influence of alcohol or other drugs.
- Attach the emergency cutoff switch lanyard to his person when operating the boat.
- Maintain a proper course and safe speed at all times to avoid collisions.
- Maintain a lookout for other boats, swimmers and obstructions in the water.
- Operate slowly in congested areas such as marinas and mooring areas.
- Keep a safe distance from other boats, swimmers, personal watercraft, docks, and fixed objects.
- Look before you turn/maneuver the boat so as to avoid potential collisions with oncoming or overtaking vessels.
- Be aware that this boat is a high-performance boat and is capable of quick, tight turns and changes in direction. Familiarize yourself with the handling characteristics of the boat. It is the operator’s responsibility to operate the boat in a manner that ensures the safety of all passengers. Abrupt maneuvers may result in the ejection of unsecured, unseated, or improperly positioned passengers. Verbally warn passengers before making quick, tight turns so they may have time to grasp a handrail, hand-hold, or portion of the boat.
- Be aware that your boat will handle differently depending on loading and on-board weight distribution.
- Ensure that all passengers are properly and securely seated in appropriate seating locations to avoid falling or falling overboard.
- Instruct and ensure that passengers remain properly seated at all times while the boat is in motion above idle speed.
- Not allow passengers to sit on the transom, seat backs, engine cover or sides of the boat while the engine is running and the boat is in motion to avoid falling overboard.
- Not allow passengers to sit in a position that obstructs the operator’s view.



- NEVER leave children unattended and in the boat without adult supervision.
- Have children riding in the bow of the boat be accompanied by an adult in the bow and ensure that all remain seated when the boat is in motion.
- Not let passengers occupy seats which may be in the path of the tow line.
- Slow down when crossing waves or wakes in order to minimize the impact on passengers and the boat. Crossing waves or wakes at an angle (such as 45 degrees) rather than perpendicularly will reduce the severity of the impact. Avoid rough water, large waves and large wakes from other boats when at high speed. Jumping waves/wakes or slamming the bow will cause large vertical impacts which may cause injury to occupants or cause ejections.
- For safe towing (waterskiing, tubing, wakeboarding, wake surfing, knee boarding, etc.) be experienced and have an observer [an observer or “spotter” is required by law in most states]. A rear view mirror is helpful if you are allowed to tow without an observer in your state.
- Avoid letting tow lines or mooring lines wrap around anyone’s body parts/limbs. Doing so could allow body parts/limbs to become entangled in the line and could cause significant injury, such as amputations.
- Keep track of tow lines and dock lines so that they do not become entangled in the propeller. A tow line will wrap quickly around a spinning propeller and is capable of immobilizing the boat and dragging a person entangled in the tow line underwater or causing amputations. Shut off the engine if a tow line has potential for wrapping in the propeller.
- The tower is designed to pull a limited number of individual(s), and in some cases only one (1) individual. Please consult the remainder of this manual and warning labels on the tower for details. DO NOT climb, sit on, stand on or jump/dive off of the tower. Tow line may loop on inverted tricks. DO NOT sit behind the pulling point of the tower.



# Section I

---

- NEVER allow any type of spark or open flame near gasoline or engine compartment.
- Avoid grounding the boat: be familiar with local conditions and water depth. If you are uncertain, then proceed slowly with caution. Sudden groundings from planing speeds may cause rapid decelerations and cause occupants to impact the boat and/or to be ejected from the boat. Boat damage may also occur.
- Always watch for low obstacles such as tree limbs, bridges or power lines, especially in boats with tow towers.
- Seek shelter from open water if there is threat of lightning or severe weather.
- NEVER dive from the boat without being absolutely sure of the depth of the water. Severe injury or death may occur from striking the bottom or submerged objects. Striking the bottom or a submerged object while diving head first can cause paralysis, head injury or death.
- Provide assistance to other boaters in distress while ensuring the safety of your own passengers.
- When you leave the boat, take the keys with you. This will keep untrained and unauthorized persons from operating the boat. (This may not be applicable on some keyless ignition systems.)

## Safety While Maintaining the Vessel



### **WARNING**

**Failure to follow these precautions may result in severe injury or death to you and/or others.**

### **The operator shall:**

- Visually inspect the engine compartment and ventilate after refueling.
- Inspect fuel system regularly. Examine fuel tanks, hoses and fittings for leaks or corrosion at least annually because leaking fuel is a fire and explosion hazard.



# **Boating Safety**

- Never remove or modify components of the fuel system in any way except for maintenance by qualified personnel. Tampering with fuel components may cause a hazardous condition which could lead to a fire or explosion.
- Never override or modify the engine neutral starting safety switch in any way. Your boat engine should not start in gear. If it does, do not use the boat and have this safety feature fixed by an authorized dealer.
- When charging some batteries, a small amount of hydrogen gas is generated. Hydrogen gas is highly explosive. While charging, it is a good idea to keep sparks, flames and smoking away from the battery. Failure to follow instructions when charging a battery may cause an explosion of the battery.
- Keep the engine off whenever the engine box/cover/hatch is open. The engine box/cover/hatch serves as a machinery guard. Clothing or body parts can get caught in moving parts, causing death or serious injury. Keep away from moving parts.
- Not replace your boat's marine parts with automotive parts or parts that were not designed for your boat.
- Be aware that battery electrolyte fluid is dangerous. It contains sulfuric acid, which is poisonous, corrosive and caustic. If electrolyte fluid is spilled or placed on any part of the human body, immediately flush the area with large amounts of clean water and immediately seek medical attention.
- Check the tightness of the tower bolts **BEFORE** each use. If a tower collapses it may result in injury to boat occupants or towed persons.
- Not modify the tow bar. The tow pylon/bar is not designed for vertical extensions. Any modifications to the tow pylon/bar or its mountings may result in damage to the boat and injury to the user.
- Only lift the boat from approved lift points, which are identified in later parts of the manual.



## Owner Responsibility and Boating Education

### Important Safety Information

Your safety, the safety of your passengers, and the safety of other boaters is dependent on how you operate and maintain your boat. As operator or owner of this boat, you are responsible for the safety of those with and around you while boating.

### Responsibilities of Boat Owner and Operators

It is the owner's responsibility to ensure that the operator of the boat has been properly instructed in the lawful and safe operation of this vessel. Therefore, before operating the boat, thoroughly read this owner/operator manual. Be sure you understand each item before operating it. Improper operation or trailering of the boat could lead to severe personal injury or death. Improper operation or trailering of the boat may also damage the boat.

The operator and the boat owner assume all risks for themselves, their guests and anyone in proximity to their boat and ensure that all passengers understand the risks and responsibilities associated with boating.

This manual is not intended to provide complete training on all aspects of boat operation. We strongly recommend that all operators of this boat seek additional training on boat handling and safety. Have all operators become familiar with the handling characteristics, and proper steering and control system usage before attempting high-speed operation.

At the time of delivery, the owner/operator is responsible for:

- Understanding the warranty terms and conditions of your boat, your engine, and your trailer.
- Obtaining insurance.
- Examining the boat to ensure the proper operation of all systems.





Before operating the boat, the owner/operator is responsible for:

- Registering the boat as required in the jurisdiction where the boat is being operated.
- Providing the proper (USCG) safety equipment, and checking local, state and federal agencies as to laws and regulations (USCG carriage requirements).
- Carefully reading and understanding safety information and proper operating procedures within this manual.
- Obtaining other boating education if you lack operational experience.
- Familiarizing yourself with the navigable waters where you intend to operate the boat.
- Following the proper break-in procedure for the engine.

## **Registration**

Federal Law requires that all motorboats be registered and that all motorcraft not documented by the U.S. Coast Guard display registration numbers. In nearly all states, this means registration with the designated state agency. In a few jurisdictions, the Coast Guard retains registration authority. Your dealer will either supply registration forms or tell you where they may be obtained. The agency will supply you with a certificate which must be carried with you when the boat is in operation. International laws may vary as to required registration.

## **Insurance**

The boat owner may be legally responsible for damages or injuries caused by both himself and the operator (if different than the owner). Common sense dictates that you carry adequate personal liability and property damage insurance on your boat, just as you would on your automobile. Many states have laws detailing minimum insurance needs. Your insurance agent or your dealer may be able to supply you with more information. You should also protect your boat from physical damage or theft.



# Section I

---

## Boating Safety Education Opportunities

It is recommended that the boat owner/operator obtain boater safety education. If you have never owned a boat before, you can get an excellent introduction to boat handling from organizations such as the U.S. Coast Guard, American Red Cross, United States Coast Guard Auxiliary, or your local boating authority. Even if you are a veteran boater, these courses will help sharpen your boating skills as well as bring you up to date on current rules and regulations. See your local boating agency or dealer for information on classes in your area.

Some states require youths, 16 years of age and younger, to complete a boating safety course before operating any watercraft. Many others require operators under the age of 18 to be licensed in small boat operation.

Boat smart from the start: take a boating safety course and get a free vessel safety check annually for your boat. For more information, contact: United States Coast Guard Auxiliary, [www.cgaux.org](http://www.cgaux.org); United States Power Squadrons, 1-888-FOR-USPS, [www.usps.org](http://www.usps.org).

The following is a list of some other agencies and organizations that offer Water Safety, First Aid and CPR courses or information. To find boating safety courses in your area, call your state's local boating agency or the USCG boating safety course line at 1-800-336-2628 (1-800-245-2628 in Virginia).

- USCG Office of Boating ( [www.uscgboating.org](http://www.uscgboating.org) )
- American Red Cross ( [www.redcross.org](http://www.redcross.org) )
- U.S. Coast Guard Auxiliary ( [www.cgaux.org](http://www.cgaux.org) )
- U.S. Power Squadrons ( [www.usps.org](http://www.usps.org) )
- State Boating Offices
- Canadian Power and Sail Squadrons ( [www.cps-ecp.ca](http://www.cps-ecp.ca) )
- Boat Owners Association of the United States ( [www.boatus.com](http://www.boatus.com) )
- National Safe Boating Council ([www.safeboatingcouncil.org](http://www.safeboatingcouncil.org))
- Water Sports Industry Association ( [www.wsia.net](http://www.wsia.net) )
- European or international organizations



## Operation by Minors and Licensing

If your boat will be operated by a minor, remember to have an adult present at all times. Many states have laws regarding minimum age and licensing requirements for minors. Some states require boat training courses, certification, or licensing for minors and/or adults. Contact state and local authorities for requirements that apply in your area.

## Safety and Required Equipment

**Your boat and equipment must be in compliance with federal, state and local safety equipment regulations.** USCG regulations require certain safety equipment be present on your boat during operation. For a detailed description, obtain “Federal Requirements for Recreational Boats” published by the U.S. Coast Guard and available online at: [http://www.uscgboating.org/regulations/federal\\_requirements\\_brochure.aspx](http://www.uscgboating.org/regulations/federal_requirements_brochure.aspx).

In addition to the USCG regulations, other local and/or international law enforcement agencies may have similar requirements. You should check with your local marine law enforcement agency regarding any such requirements before boating.

Equipment requirements for coastal and inland waters differ. Check with local authorities and/or the USCG for further information about coastal water requirements.

The Federal Boat Safety Act of 1971 (FBSA/71) and the National Recreation Boating Safety Program have established minimum safety standards for boats and associated equipment, specified by the USCG. In addition, the American Boat and Yacht Council (ABYC) and the National Marine Manufacturers Association (NMMA) work with boat builders to develop voluntary standards that exceed the USCG requirements. The included safety equipment on your boat meets or exceeds the standards of the USCG, ABYC and the NMMA.



# Section I

---

Some required safety equipment, such as life jackets (PFDs), are not included with your boat. Your dealer can help you choose the appropriate equipment.

## NOTICE

*Many states' equipment requirements go beyond USCG requirements. Contact your state boating office for further information.*

## Navigation Lights

Your boat is equipped with navigational lights. Recreational boats are required to display navigational lights between sunset and sunrise and other periods of reduced visibility (fog, rain, haze, etc.). Navigation lights are provided to keep other boats informed of your presence and course. It is up to you to make sure they are operational, displayed correctly, and turned on when required.

## Emergency Safety Lanyard

Your boat is equipped with an Emergency Safety Lanyard (cutoff switch). We recommend that the lanyard be secured to the operator and the lock plate attached to the emergency cutoff switch prior to starting the engine and anytime the engine is operating. The Emergency Safety Lanyard is designed to turn off the engine whenever the operator moves far enough away from the helm to activate the switch. The purpose is to stop the engine, propeller, and boat in the event the operator leaves the helm location, falls overboard, or is ejected from the boat. If the engine is stopped it will prevent the boat from becoming a run-away, unmanned boat, which may cause injury or death to boat occupants who have fallen overboard or been ejected, or to other nearby people. If the engine stops it will minimize the subsequent opportunity for propeller contact with the operator or other persons in the water. If the engine and boat stop it will afford opportunity for the operator or other persons who have fallen overboard to safely re-board the boat.





## **WARNING**

**It is recommended that you use the Emergency Safety Lanyard system as failure to do so can cause death or serious injury.**

**DO NOT operate the boat if the Emergency Safety Lanyard system does not function properly.**

- Attach the Emergency Safety Lanyard to a secure place on your clothing, your arm or your leg while operating.
- DO NOT attach the lanyard to clothing that could tear loose.
- DO NOT route the lanyard where it could become entangled, preventing it from functioning.
- Avoid accidentally pulling the lanyard during normal operation.
- Loss of engine power means loss of most steering control.
- Without engine power, the boat will decelerate rapidly. This could cause people in the boat to be thrown forward or ejected overboard if they are not properly seated in the boat.

There are practical limitations to what the Emergency Safety Lanyard can do. It can take several seconds for the engine and propeller to stop turning. The boat can continue to coast for several hundred feet depending on the boat speed at the time the switch is activated. While the boat is coasting, it can cause injury to anyone in its path. Accidental loss of power can be hazardous particularly when docking or in heavy seas, strong current, or high winds.

While at the dock or when the boat is not moving, periodically disconnect/pull the Emergency Safety Lanyard out of the switch while the engine is running to test for proper operation. The engine should shut off when the lanyard is disconnected/pulled from the switch. You should not be able to restart the engine until the lanyard is back in place.



# Section I

---

## Personal Flotation Devices

Federal law requires that you have at least one wearable Personal Flotation Device (PFD) of the proper size (Type I, II, III or V), for each person on board or being towed, and at least one throwable PFD (Type IV) in the boat. PFDs must be Coast Guard approved, in good and serviceable condition and the appropriate size for the user. To meet requirements, each lifesaving device must have a current, legible USCG approval stamp permanently affixed. At the beginning of each season, inspect life jackets (PFDs) for damage and test for proper flotation. Refer to the lifejacket (PFD) manufacturer's information.

**REMEMBER - The best PFD is the one that is worn – that is, the one that can save your life.** PFDs are intended to save lives; it is highly recommended that you and your passengers wear them while in the boat. Learn how to use them and adjust as necessary for comfort. It is especially important that children and non-swimmers wear a life jacket (PFD) at all times. Make certain all passengers know where life jackets are located, how to put on and properly adjust their life jackets (PFDs), and that life jackets are readily accessible at all times.

**Your dealer can help you select appropriate life jackets (PFDs) and throwable lifesaving devices for your area.** Some PFDs are specially made for use while waterskiing or wakeboarding and are not U.S.C.G. approved. Please check local law with respect to their use. Some states require children to wear a PFD at all times. There are four types of wearable PFDs (Type I, II, III or V) and one throwable type of PFD (Type IV) used for throwing in emergency situations. Examples of these USCG approved PFDs are shown below:



**Type I PFD – Offshore Lifejacket:** This PFD is designed for extended survival in rough, open water. It usually will turn an unconscious person face up and has over 22 pounds of buoyancy. This is the best PFD to keep you afloat in remote regions where rescue may be slow in coming.





**Type II PFD – Near Shore Buoyant Vest:** This “classic” PFD comes in several sizes for adults and children and is for calm inland water where there is chance of fast rescue. It is less bulky and less expensive than a Type I, and many will turn an unconscious person face-up in the water.



**Type III PFD - Flotation Aid:** These life jackets are generally considered the most comfortable, with styles for different boating activities and sports. They are for use in calm water where there is good chance of fast rescue since they will generally not turn an unconscious person face-up. Flotation aids come in many sizes and styles.



**Type IV Throwable Device:** These are designed to be thrown to a person in the water. Throwable devices include boat cushions, ring buoys, and horseshoe buoys. They are not designed to be worn and must be supplemented by wearable PFD. It is important to keep these devices immediately available for emergencies.



**Type V PFD - Special Use Device:** Special use PFDs include work vests, deck suits, and hybrids for restricted use. Hybrid vests contain some internal buoyancy and are inflatable to provide additional flotation. These PFDs may be used instead of a Type I, II, or III PFD with non-towed participants if used in accordance with the

approval conditions on the label and if worn when the boat is underway. Some Type V PFDs provide increased protection against hypothermia.



# Section I

---

## NOTICE

*A Type V PFD must be worn to be counted toward the minimum carriage requirements.*

## NOTICE

*Special lifejackets are available for skiing and other water sports. These non-Coast Guard approved lifejackets do not count as PFDs.*

## Fire Extinguisher

A portable fire extinguisher is required if your boat has an inboard engine, or when fuel is stored in closed stowage compartments.

Approved fire extinguishers are classified by a letter symbol, either B-I or B-II with the B designating that the material will extinguish flammable liquids such as gasoline, oil, etc. B-I extinguishers are required for boats less than 26 feet in length. Check periodically to ensure that the extinguisher is in working condition and fully charged. Check local, state and federal agencies as to laws and regulations.



## Horn or Whistle

All boats over 16 feet (4.8 meters) in length must be equipped with an operable horn or whistle. Test the operation of the horn periodically, so as to make sure it will sound when you actually need to alert someone or another boat. The following are standard signals when using a whistle or a horn:

- One prolonged blast: Warning.
- One short blast: Pass on my port (left) side.
- Two short blasts: Pass on my starboard (right) side.
- Three short blasts: My engines are in reverse.
- Five or more blasts: Danger!





## Bilge Pump(s)

Bilge pump(s) are installed in your boat to remove water that may accumulate in the bilge. Know the location of the pump(s), where they discharge, and where switches are located. Typically there are manual switch and/or an automatic switch position(s). Periodically test the operation of bilge pumps by activating the manual switch and observing the water discharge. It is best to leave the bilge pump switches in automatic mode, so as to not allow excess water to unknowingly accumulate in the bilge of your boat. If your bilge pump comes on too frequently or continuously, investigate the source of leaking water (check for hull damage, hose or piping leaks, missing drain plug, exhaust system or ballast system failures, etc.), and/or return to shore. Excess water in the bilge of your boat can cause loss of engine power, sinking, and/or capsizing.

## Visual Distress Signals

All vessels used on coastal waters, the Great Lakes, territorial seas, and those waters connected directly to them up to a point where a body of water is greater than two miles wide, must be equipped with USCG approved visual distress signals. Your dealer or local authorities can help you select appropriate visual distress signals for your area.

If you are required to carry distress signals, you must have three USCG approved pyrotechnic devices. Be sure they are in serviceable condition, not exceeding the expiration date and stored in a cool, dry location in a red or orange waterproof container.



### **WARNING**

**Pyrotechnic signaling devices can cause fire and/or explosion, death, serious injury, and property damage if improperly handled. Follow the pyrotechnic manufacturer's directions.**



# Section I

---

## Recommended Safety Equipment

As a precaution, a prudent boater will avoid potential problems on an outing by having additional equipment on board. Normally, this equipment is dependent on the size and type of the body of water and the length of the trip. Your dealer can assist you in acquiring this additional equipment.

We recommend the following equipment:

- First aid kit and manual
- Anchor with at least 75 feet (23 meters) of line
- Mooring lines and fenders
- Bailing device (bucket, hand pump)
- Combination paddle/boat hook
- Local charts and compass
- Day/night distress signals
- Waterproof flashlight and spare batteries
- Cellular phone
- Waterproof container for cell phone
- GPS Global Positioning System
- Binoculars
- Portable AM/FM radio with weather band
- A non-electric horn or whistle
- Extra engine oil
- Tool kit
- Spare propeller and mounting hardware
- Spare fuses
- Spare keys
- Sunglasses and sun block lotion



## **General Boating Safety Topics**

### **Safe Speed**

Navigation rules state that a boat be operated at a safe speed at all times. Determination of a safe speed involves consideration of many factors, such as, but not limited to:

- Boating activity (tubing, water skiing, wakeboarding, wake surfing, etc.)
- Boat traffic congestion
- Water conditions
- Environmental conditions (shore line, docks, and depth of water)
- Weather
- Visibility

The boat should not be driven at a rate of speed faster than will allow it to be brought to a full stop within the operator's field of view given the environmental conditions at the time. Safe speed for the conditions and driver attention (lookout) are important factors in avoiding collisions which may cause injury or death. When in doubt it is prudent to slow down within adequate time and distance so as to be able to assess the conditions and paths of other boats.

It is important to know the Rules of the Road, although do not assume that all boaters also know the rules or that they will abide by them. Avoid collisions by constantly assessing the ever-changing situation and be sure to make appropriate speed and course changes early.

### **Passenger Safety**

The operator of the boat is responsible for the safety of the passengers, all skiers/riders, as well as his/her own safety. Ensure that you and your passengers adhere to these safety recommendations:

- Any time you take your boat out, make sure that there is at least one other passenger aboard who is familiar with the operation of your boat.



# Section I

---

- Ensure that all passengers are properly and securely seated in appropriate seating locations to avoid falling or falling overboard.
- While the engine is running, and while the boat maneuvering, all occupants should be properly seated. DO NOT stand while the boat is moving.
- DO NOT sit on the engine box, seat backs, transom seating, sunpad, boarding platform or gunnels while the boat is underway. You could fall overboard and be hit by the propeller, or another boat.
- DO NOT allow objects, arms or legs, or any other body parts to hang over the bow or gunnels. Stay within the boat.
- Passengers should not sit in locations that obstruct the operator's visibility.
- Persons and gear should be stowed in a way that distributes weight appropriately and in a manner that trims the boat properly (pitch angle). Excessive weight at either the bow or the stern relative to one another can cause trim problems leading to reduced driver visibility, erratic steering, loss of control, or bow submergence and flooding/swamping.
- Passengers should be well aware of emergency equipment and instructed in its use.
- Passengers should assist with lookout duties and notify the operator of any approaching watercraft or potentially unsafe conditions to provide assistance with collision avoidance.

## Carbon Monoxide Safety

Carbon Monoxide (CO) is a deadly, colorless and odorless gas produced by all engines and fuel burning appliances. Even with the best boat design and construction, plus the utmost care in inspection, operation and maintenance, hazardous levels of carbon monoxide may be present in or near the boat under certain conditions. Even catalyst equipped boats still generate carbon monoxide. The boat owner, operator, as well as all boat occupants, must understand the dangers of carbon monoxide and must comply with all safety recommendations/requirements. For boats with cabins, always ventilate the boat interior and avoid boating situations which cause increased exposure.





## DANGER



**CARBON MONOXIDE (CO)  
CAN CAUSE BRAIN DAMAGE  
OR DEATH.**

**Engine exhaust contains  
odorless and colorless  
carbon monoxide gas.**

**Carbon monoxide will be around the back of the boat  
when engines or generators are running.**

**MOVE TO FRESH AIR if you feel nausea, headache,  
dizziness, or drowsiness.**

- Do not allow people to be on or near the swim platform or in the water near the swim platform while the engine is running. Carbon monoxide will exist around the back of the boat when engines are running.
- Do not operate the engine in a confined space or while the boat is tethered to another vessel.
- Do not go under the boat cover while the engine is running or shortly after the engine has been running. Carbon monoxide may be trapped under the cover. It is important to remove the cover and/or ventilate the area before going under the boat cover.
- Do not drag behind the boat while holding onto swim platform (sometimes referred to as “Teak surfing”). Carbon monoxide will exist in high concentrations in the vicinity of the swim platform near the water while the engine is running. The USCG has deemed platform dragging as a dangerous and hazardous activity which should be prohibited, as it can result in injury or death.
- In the event that someone exhibits the symptoms of carbon monoxide exposure (nausea, headache, dizziness, or drowsiness), have them breathe fresh air and, if necessary, immediately seek medical attention.



# Section I

Hazardous boating situations involving carbon monoxide include:

Blockage of boat exhaust by obstruction.




Exhaust traveling along obstruction.



Operating at slow speed or while dead in the water.




Operating with high bow angle.



Exhausts from other vessels in confined areas.



Operating with canvas tops and side curtains in place without ventilation.



For the most current information on carbon monoxide, you may call, write or visit on-line any of the following:

United States Coast Guard  
Office of Boating Safety (CG-5422)  
2100 Second Street SW STOP 7581,  
Washington, DC 20593-7581  
1-800-368-5647 [www.uscgboating.org](http://www.uscgboating.org)  
([www.uscgboating.org/recreational-boaters/carbon-monoxide.php](http://www.uscgboating.org/recreational-boaters/carbon-monoxide.php))

NMMA  
National Marine Manufacturers Association  
231 S. LaSalle St., Suite 2050, Chicago, IL 60604  
312-946-6200 [www.nmma.org](http://www.nmma.org)



American Boat & Yacht Council, Inc.  
613 Third St., Suite 10, Annapolis, MD 21403  
410-956-4460 [www.abycinc.org](http://www.abycinc.org)

## Proper Loading



### **WARNING**

**DO NOT overload your boat.**

**Overloading or uneven loading can cause loss of control, capsizing, or swamping, which may lead to death or serious injury.**

**Adhere to the load capacity plate restrictions, and always account for persons, gear, and all non-factory installed ballast or other equipment.**

Your boat is equipped with a maximum load capacity plate indicating the maximum acceptable load as determined by the manufacturer following certain Federal guidelines. In addition to following these weight guidelines, it is critical that you properly distribute this weight throughout the boat. If too much weight is placed in one area it can have serious impact on the boat's handling and control, which has the potential to lead to injury or death.

The load capacity plate is used by boat manufacturers participating in the National Marine Manufacturers Association certification program. Your manufacturer has submitted your model for inspection and compliance with their guidelines. The maximum number of persons allowed on the boat has been determined by the manufacturer and displayed on the capacity plate. This information on the capacity plate applies under normal conditions and special care must be used in any abnormal conditions. Check the capacity plate on your boat and abide by these limits.



# Section I

---

The capacity plate has the following information permanently printed on it:

- The total weight of persons, gear and other items which the boat is capable of carrying under normal conditions. **This weight must include any added ballast above and beyond boat manufacturer's factory installed ballast system(s).**



## **WARNING**

**Any non-factory installed ballast must be properly secured to prevent injury.**



## **WARNING**

**Do not fill the bilge area with water. Excessive water in the bilge can cause changes in the boat trim and reduce boat stability which may lead to submergence or capsizing.**

## **Weighting Your Boat During Watersport Activities**

Although water intrusion and waves spilling inside a boat is an obvious boating hazard, this hazard can be increased when weighting your boat for water sports such as wakeboarding or wakesurfing. As wakeboarding has evolved, ballast systems have been developed to add weight and increase the size of the wake. The simplest ballast system on the market is the water ballast type, such as the "FAT SAC." The quest for the largest wake has caused some boat operators to excessively overload their boats. It is not uncommon to see operators use aftermarket ballast systems and then put additional people and gear in their boat. Be advised that this practice can lead to overloading your boat which may lead to any of the following: changes in handling and performance; capsizing, flooding, and sinking; boat occupants going overboard. **Do not overload your boat.**

Always be aware of the load in your boat and do not load the boat in excess of the listed capacity. Each boat has a maximum capacity label displaying the maximum weight of people, gear and ballast that can be placed in the boat. Always have your passengers in designated occupant positions when underway.





When loading your boat, give attention to the effect that the load distribution has on the boat's trim angle. Trim angle is the technical term for the up or down pitch angle of your boat (also known as the "bow up" or "bow down" angle). The fore and aft load distribution of weight, passenger, and gear can affect the running trim angle of the boat.

- Excessive weight placed in the stern of the boat can cause the inability to get on plane, high bow up angles, and can lead to steering difficulties. High bow up angles can be dangerous due to the reduction in the operator's forward visibility which can lead to collisions and groundings. High bow up angles cause longer transition times from displacement mode (slow velocity, 0 to 5 mph) to planing speeds (18 to 20 mph and above). During transition, it is important that the boat operator pays attention so that they are able to see forward and that the time in transition (or in the "hump" speed region) is minimized.
- Excessive weight placed in the bow of the boat can lead to very flat planing trim angles which may lead the boat to turn aggressively, unpredictably, and without steer input. The phenomenon of yaw instability is caused by heavy bow weights and running very flat (bow down or flat trim angles). This can occur with excessive weight in the bow compared to weight in the stern of the boat. Another ill effect of too much bow weight in comparison to stern weight is that with extremely heavy bow loads, the boat's bow may dive or submerge when coming off plane (decelerating rapidly, or encountering waves/wakes at slow speed). If the bow submerges, then water will enter and flood your boat.
  - When encountering conditions which may lead to bow diving or bow submergence, it is recommended to accelerate the boat before the wave/wake in order to help raise the bow and get over the wave/wake.
  - If the bow submerges, the recommended action is to reduce throttle to stop forward speed, get passengers to move aft, and turn on the bilge pump.



## Section I

---

It is the boat operator's responsibility to tell passengers to move to other seats on the boat, so as to not overload the stern or bow of the boat, nor restrict the boat operator's forward visibility. There is no single recommended seating or load distribution for all conditions. Experience with your boat will allow you to determine where to properly allow passengers and gear to be placed.



### **WARNING**

**Excess and improper loading of bow area forward of windshield may cause water influx, operating instability, and loss of control resulting in injury or death.**

**Bow Capacity Limit – X persons or XXX lbs. person, gear and ballast. This is posted separately on your boat but still included in overall capacity.**

**Use good judgment when weighting your boat for any towed water sports.**

### **Visibility from the Helm**

The operator of the boat is responsible, by law, to “maintain a proper lookout by sight and hearing.” The operator must ensure that he/she has appropriate visibility for safe operation. No passengers or equipment should block the operator's view, including the view of other boats, skier(s), rider(s), swimmer(s), or anyone or anything else in the water. Even momentary interference can result in the driver's inability to respond to a situation that requires avoidance of another vessel or submerged or partially-submerged object(s).

Look carefully before turning, especially when you are turning around to pick up a fallen skier/rider. Other boats in your vicinity may not necessarily be following the “Rules of the Road.” Be alert and keep a visual check for other boats in and around your intended path. Do not turn or maneuver your boat without first checking that it is clear to do so. Failure to look before turning can result in an encounter with another boat where neither boat has enough time to avoid a collision. This situation can develop very quickly if you fail to look first and turn in front of another oncoming boat.





## **WARNING**

**Obstructed visibility can cause death or serious injury. The operator must maintain clear visibility at all times while operating the boat.**

**Arrange passengers and equipment appropriately or designate a passenger to assist when visibility is limited.**

## **Boating Under the Influence**



## **WARNING**

**Operating boat or boating under the influence of alcohol and/or drugs can cause serious injury or death.**

**Alcohol and drugs slow your reaction time and impair your judgment.**

**Do not operate a boat or allow passengers to boat while under the influence of alcohol and/or drugs.**

Boating under the influence of alcohol or drugs can be deadly. Alcohol and/or drug use is the leading contributing factor to all recreational boating fatalities. Alcohol and drugs can increase your reaction time and impair your judgment. Combined with the sun, wind, waves, and noise of other watercraft, the effects of drugs and alcohol can be increased and can significantly increase your reaction time. As the owner/operator, you are responsible for the alcohol/drug use and onboard behavior of your passengers. Additionally, civil lawsuits in cases of property damage or injury/death to others can result in significantly higher verdicts when alcohol or drugs are allowed.



## **WARNING**

**Impaired operation may result in severe injury or death.**

**Federal and state laws prohibit operating a boat under the influence of alcohol and other drugs.**

**If the operator's blood alcohol content is above the legal limit, violators are subject to fines and may go to jail. Violators may also lose automobile driving privileges.**



# Section I

---

## Product Misuse

Misuse of the product or use of it in a manner for which it was never intended can create dangerous situations. The boat operator and passengers are responsible for using the product safely and as intended. The driver must operate the boat in a manner that ensures the safety of all passengers. If you or your passengers are unsure about the proper use of the product, unsure about performing certain boating maneuvers or are unsure about a particular water activity, refer to this manual or contact a knowledgeable source, such as your local dealer, the US Coast Guard, or your local boating authority.

## Reporting Accidents

Boat operators may be required by law to file a Boating Accident report with their state boating law enforcement agency or local authority, the USCG, or their country's boating law enforcement agency when their boat is involved in certain boating accidents. A boating accident must be reported if there is a loss or probable loss of life or a personal injury requiring medical attention beyond first aid. In these situations, a formal report must generally be filed within 48 hours of the accident. Also a boating accident must be reported for accidents when damage exceeding \$500 is incurred, or there is a complete loss of the boat. In these situations, a formal report must generally be filed within 10 days. If any of these events occur, seek further assistance from local law enforcement personnel. Please note that the submittal of a report is the responsibility of the boat owner. This requirement is different than laws associated with the reporting of automobile accidents.

## Rendering Assistance

If you see a distress signal or suspect a boat is in trouble, you must assume it is a real emergency and render assistance immediately. By law, the operator in charge of the craft is obligated to provide assistance to any individual in danger, presuming assistance can be safely provided. Failure to render assistance can result in a fine and/or imprisonment.



The 1971 Boating Safety Act grants protection to a “Good Samaritan” boater providing good faith assistance, and absolves a boater from any civil liability arising from such assistance.

## **Hazardous Conditions**

Every waterway poses hazards that should be avoided. You will be best prepared to avoid these hazards if you are familiar with the waterway where you are boating. Whenever possible familiarize yourself with navigation charts, depth charts, and waterway maps before you go boating. The following information outlines some of the most common hazards which may be encountered:

### *Shallow Water Operation*

Shallow water brings on obvious hazards such as sand bars, stumps, rocks, etc. Know the area in which you will be operating the boat. Grounding the vessel or striking submerged objects can result in serious injury or death and can cause severe damage to your watercraft. At high speed, this can cause rapid deceleration or stop your boat abruptly, which may cause occupants to impact the interior of the boat or be ejected. Stick to deeper water whenever possible, and if you must travel in shallow water, proceed at low speed and post a lookout.

Know the minimal depth your boat can safely travel.

### *Warning Markers*

Learn to recognize the different buoys and day markers; they are used as the signposts of the waterways identifying navigable routes and water hazards. It is a good idea to ask local authorities about hazard areas and if they are marked. Stay within boundaries and clear of hazards.

### *Weeds*

Weeds can generally be a threat to a boat’s engine and other components on the boat. If weeds wrap around the propeller, they can create vibration in the engine. They also can restrict water intakes or clog the water filter causing the engine to overheat. Learn to recognize the typical normal operating temperature range for your engine. If temperature rises high above normal, then check for blockage of the engine cooling water system.



## NOTICE

*Weeds can sometimes be removed by shifting to NEUTRAL, pausing for a moment, then shifting to REVERSE to unwind the weeds from the propeller.*

### ***Dam Spillways***

The area around dam spillways is very hazardous and conditions can change rapidly. Keep clear of the spillways and areas below dams. Currents created by spillways can draw in objects, including your boat.

### ***Restricted Areas***

Before boating, check with Local, State, and Federal authorities to identify restricted areas. Because of the threat of terrorism, the U.S. Coast Guard has and will continue to implement strict limits on watercraft near U.S. Navy and Coast Guard ships and other potential targets.

### ***Weather/Seas***

Learn and understand weather patterns and signs of change. Bad weather can cause an uncomfortable and unsafe situation. If a storm approaches, seek a safe harbor. Check forecasts before getting underway and continue to monitor conditions while on the water.

## **Environmental Concerns**

As a boater, you already appreciate nature's beauty and the peace of the great outdoors. It is a boater's responsibility to protect the natural environment by keeping waterways clean.

### ***Foreign Species***

If you trailer your boat from lake to lake, you have the potential of unknowingly introducing a foreign aquatic species from one lake to the next. It is important to thoroughly clean the bottom of the boat below the water line, remove all weeds and algae, and drain the bilge, ballast, and livewells before launching the boat in a new body of water. Check local, state, country agencies as to laws and regulations.



## *Fuel/Oil Spillage*

The spilling of fuel or oil into our waterways contaminates the environment and is dangerous to wildlife. **DO NOT EVER** discharge or dispose of fuel, oil or other chemicals into the water; it is prohibited and can result in fines. These are three common, accidental types of discharge:

- During initial fueling of a nearly empty tank
- Overfilling the fuel tanks
- Pumping contaminated bilge water



### **WARNING**

**Fumes from rags can collect in bilge and pose an extremely hazardous fire and explosion risk, which can result in injury or death.**

**Never store rags used to wipe up fuel or solvent spills in the boat.**

**Dispense of rags properly ashore.**

## *Discharge/Disposal of Waste*

Waste means all forms of garbage, plastics, recyclables, food, wood, detergents, sewerage and even fish parts in certain waters – in short, nearly everything. We recommend you bring back everything you take out with you for proper disposal ashore.

## *Excessive Noise*

Noise means engine noise, radio noise, loud conversation, or even yelling. Many bodies of water have adopted noise limits. Noise can carry a considerable distance on water, especially at night. Be sure to follow regulations and be courteous.

## *Speed/ Wake/Wash*

Be alert for **NO WAKE** zones. You are responsible for any damage or injury caused by your wake/wash. Prior to entering a **NO WAKE** zone, reduce throttle, come off plane to the slowest steerable speed. Use caution when operating around smaller crafts, in channels and marinas, and in congested areas.



# Section I

---

Some states and boating areas have imposed speed limits for the operation of boats, including, but not limited to, no-wake zones. Check local, state, and federal agencies as to laws and regulations. The U.S. Coast Guard and local boating authorities are excellent sources for this information, which can include penalties for failure to observe the requirements.

## *Exhaust Emissions*

Increased exhaust (hydrocarbon) emissions pollute our water and air. Keep your engine tuned and boat hull clean for peak performance. Consult your Nautique dealer for information.

## *Paints*

If your boat is kept in water where marine growth is a problem, the use of anti-fouling paint may reduce the growth rate. Be aware of environmental regulations that may govern your paint choice. Contact your local boating authorities for information.

## *Cleaning Agents*

Household cleaners should be used sparingly and not discharged into waterways. Never mix cleaners and be sure to use plenty of ventilation in enclosed areas while cleaning your boat. **DO NOT** use products which contain phosphates, chlorine, solvents, non-biodegradable or petroleum based products. Refer to **CARE AND MAINTENANCE** in this manual for more information.

## *MARPOL Treaty*

The USCG enforces the International Convention for the Prevention of Pollution from ships, commonly referred to as the MARPOL Treaty (Marine Pollution). This treaty prohibits the overboard dumping of all ship-generated plastics, chemicals, garbage and oil.





## **On Product Warning Labels**

### **Warning Labels & Locations**


Warning labels are placed at specific locations on your Nautique boat at the time of manufacture to alert you to potential hazards that may not be obvious. These labels also indicate how to avoid these hazards. Warning labels should never be removed and must remain legible. If you suspect a label is missing, or if a label becomes damaged or becomes unreadable (damaged, faded, or sun bleached), contact your dealer for replacement.

**It is the responsibility of the boat owner and occupants of the boat to understand and comply with all warning labels and safety recommendations/requirements. The driver of the boat and the boat owner are responsible for the proper operation of the boat and the safety of the occupants of the boat.** Failure to adhere to and comply with the on-product warning labels and safety statements labeled as dangers, warnings, and cautions that appear in this manual can lead to serious injury, or death, as well as property damage. **READ AND ADHERE TO ALL WARNING PLATES AND LABELS** from bow to stern, including those that are installed inside the engine compartment, lockers, and underneath seating.



# Section I

## 200 Closed Bow Safety Labels



CORC0622




1. Warning Passenger Remain Properly Seated (replacement part #160183)
2. Warning Only Use This Pylon (replacement part #160177)
3. Warning Tow Tower (replacement part #160166) (optional)
4. Caution Water Strainer (replacement part #8293)
5. Warning Leaking Fuel (replacement part #80068)
6. Danger Carbon Monoxide (replacement part #1601320)
7. Danger Spinning Propeller (replacement part #160157)
8. Danger Carbon Monoxide (replacement part #160158)
9. Danger Spinning Propeller (replacement part #160319)
10. Warning Tow Tower Only Use This Pylon (replacement part #160195) (optional)
11. Warning Avoid Personal Injury (replacement part # 160174)
12. Max Capacity Label (replacement part #100233)
13. Caution Single Reverse Polarity (replacement part #140255)
14. CE Capacity Label (replacement part #100328)
15. Fire Extinguisher System (replacement part #110162) (optional)
16. Check Engine or Check Engine/Service Soon (replacement part #120043 or part #120042)
17. Danger Spinning Propeller (replacement part #160170)



# Section I

## 200 Open Bow Safety Labels



CORC0623




1. Warning Bow Max 3 Persons or 350 LBS. (replacement part #160164)
2. Warning Passenger Remain Properly Seated (replacement part #160184)
3. Warning Only Use This Pylon (replacement part #160177)
4. Warning Tow Tower (replacement part #160166) (optional)
5. Caution Water Strainer (replacement part #8293)
6. Warning Leaking Fuel (replacement part #80068)
7. Danger Carbon Monoxide (replacement part #160320)
8. Danger Spinning Propeller (replacement part #160157)
9. Danger Carbon Monoxide (replacement part #160158)
10. Danger Spinning Propeller (replacement part #160319)
11. Warning Tow Tower Only Use This Pylon (replacement part #160195) (optional)
12. Warning Avoid Personal Injury (replacement part # 160174)
13. Max Capacity Label (replacement part #100234)
14. Caution Single Reverse Polarity (replacement part #140255)
15. CE Capacity Label (replacement part #100327)
16. Fire Extinguisher System (replacement part #110162) (optional)
17. Check Engine or Check Engine/Service Soon (replacement part #120043 or part #120042)
18. Danger Spinning Propeller (replacement part #160170)



# Section I

## 200 Sport Safety Labels



CORC0624



1. Warning Bow Max 3 Persons or 350 LBS. (replacement part #160164)
2. Warning Passenger Remain Properly Seated (replacement part #160185)
3. Warning Only Use This Pylon (replacement part #160177)
4. Warning Leaking Fuel (replacement part #80068)
5. Warning Tow Tower (replacement part #160166) (optional)
6. Caution Water Strainer (replacement part #8293)
7. Caution Single Reverse Polarity (replacement part #140255)
8. Danger Carbon Monoxide (replacement part #160158)
9. Danger Carbon Monoxide/Spinning Propeller/Tow Point Combo (replacement part #160176)
10. Danger Spinning Propeller (replacement part #160157)
11. Warning Tow Tower Only Use This Pylon (replacement part #160195) (optional)
12. Warning Avoid Personal Injury (replacement part # 160174)
13. Max Capacity Label (replacement part #110132)
14. CE Capacity Label (replacement part #110260)
15. Fire Extinguisher System (replacement part #110162) (optional)
16. Check Engine or Check Engine/Service Soon (replacement part #120043 or part #120042)
17. Danger Spinning Propeller (replacement part #160170)



# Section I

## Maximum Capacity Labels



CORC0632a

P/N 100328



CORC0632b

P/N 100327



CORC0632c

P/N 110260






## Helm Labels



CORC0633a

P/N 160170



CORC0633b

P/N 160174



# Section I

## Passenger Compartment Labels



CORC0629a

P/N 160183



CORC0629b

P/N 160184




CORC0629c

P/N 160185




# Boating Safety

## Transom Labels



CORC0628a

P/N 160157



CORC0628b

P/N 160158



CORC0628c

P/N 160319



CORC0628d

P/N 160320




CORC0628e

P/N 160176




# Section I

## Tow Tower Labels




CORC0630a



CORC0630b

P/N 160166

P/N 160195



CORC0630c

P/N 160177



## Miscellaneous Labels



CORC0631a

P/N 120042



CORC0631b

P/N 120043




CORC0631c

P/N 110162



CORC0638e

P/N 8293



CORC0631e

P/N 140255



CORC0638f

P/N 80068



## Basic Rules of the Road

### Boating Regulations

The U.S. Coast Guard (USCG) is the governing authority of the United States waterways and serves to help the boating public. State boating regulations are enforced by local authorities. Owners and users outside of the United States must be cognizant of that country's laws and regulations. You are subject to marine traffic laws and "Rules of the Road" for both federal and state waterways; you must stop if signaled to do so by enforcement officers, and permit them to board if asked.

**Review and understand all local, state, federal, and country boating laws.**

There are many USCG pamphlets available to you. These pamphlets go beyond the contents of this manual and explain "Rules of the Road," signal lights, buoys, safety, international and inland regulations. An example is the Ultimate Watersports Handbook you should have received with your new boat, or which can be ordered by contacting WSIA, go to: *www.WSIA.net*. For more information, contact your local USCG Unit or visit *http://www.uscgboating.org*.

You should be aware of these rules and follow them whenever you encounter another vessel on the water. The rules presented in this manual outline only the most basic of the nautical "Rules of the Road" and have been provided as a convenience only. Consult your local U.S. Coast Guard Auxiliary (USCGA), Department of Motor Vehicles (DMV) or local maritime authority for a complete set of rules governing the waters in which you will be using your boat. If you plan to travel—even for a short trip—you would be well served to contact the regional USCGA or DMV in the area where you will be boating.



The nautical Rules of the Road must be followed to prevent collisions between vessels. Like traffic laws for automobiles, the operator is legally required to follow the rules.



## **WARNING**

**Collisions between boats can cause death or serious injury.**

**Keeping a proper lookout, safe speed, and follow the nautical “Rules of the Road.”**

## **Encountering Another Vessel**

Any time two vessels on the water meet one another, one vessel has the right-of-way. It is called the “*stand-on*” or “*privileged vessel*”. The vessel which does NOT have the right-of-way is called the “*give-way*” or “*burdened vessel*”. These rules determine which vessel has the right-of-way, and accordingly, what each vessel should do.

### **Privileged Vessel**

The privileged vessel has the right-of-way and has the duty to continue its course and speed, except to avoid an immediate collision. When you maintain your direction and speed, the other vessel will be able to determine how best to avoid you.

## **NOTICE**

*In general, boats with less maneuverability have right of way over more agile crafts. You must stay clear of the vessel with right of way and pass to his stern.*

Sailboats and boats paddled or rowed have the right of way over motor boats. Sailboats under power are considered motorboats. Small pleasure craft must yield to large commercial boats in narrow channels.



# Section I


---

## Burdened Vessel

The burdened vessel does not have the right-of-way and has the duty to take positive and timely action to stay out of the way of the privileged vessel. Normally, the burdened vessel should not cross in front of the privileged vessel. The burdened vessel should slow down or change directions and pass behind the other vessel. The burdened vessel operator should always move in such a way that the privileged vessel operator can see what you are doing in ample time to avoid a collision.

## Crossing


In crossing situations, the boat to the right from the 12 o'clock to the 4 o'clock position has the right-of-way, and it must hold course and speed. The burdened boat passes behind the privileged boat. Boats going up and down a river have the privilege over boats crossing the river. The illustration below depicts a situation in which you are the boat in the center and you are the privileged vessel. You must hold course and speed. All vessels approaching your vessel from the directions depicted by the red vessels must yield to your boat.



You are the privileged vessel.  
You must stand on.



Conversely, the following illustration depicts a situation in which you are the boat in the center and you are the burdened vessel. You must give right-of-way to all vessels coming towards you from the directions shown in green.



You are the burdened vessel.  
You must give way.

## Meeting Head-On

When meeting head-on, neither vessel has the right of way. Both boats should decrease speed, turn towards their right (starboard side) and pass on their left sides (port-to-port). However, if both boats are clearly on each other's right (starboard) side then, each vessel should sound two short blasts and pass on their right sides (starboard-to-starboard).



Passing  
Port-to-Port



Meeting  
Head-to-Head



Passing  
Starboard-to-Starboard




# Section I

---

## Overtaking

The boat that is overtaking one ahead of it is the burdened boat and must make any adjustments necessary to keep out of the way of the privileged boat, until the burdened boat is well ahead and clear of the vessel being overtaken.



## The General Prudential Rule

The General Prudential Rule regarding right of way, is that if a collision appears unavoidable, neither boat has right of way. As prescribed in the “Rules of the Road”, both boats must act to avoid collision.

Rule 2 in the International Rules says, “In construing and complying with these Rules due regard shall be had to all dangers of navigation and collision and to any special circumstances, including the limitations of the vessels involved, which may make a departure from these Rules necessary to avoid immediate danger.”

## Other Rules of the Road

When navigating in narrow channels, you should keep to the right when it is safe and practical to do so. If the operator of a power-driven vessel is preparing to go around a bend that may obstruct the view of other water vessels, the operator should sound a prolonged blast on the whistle or horn—four to six seconds.

If another vessel is around the bend, it too should sound the whistle or horn. Even if no reply is heard, however, the vessel should still proceed around the bend with caution.



If you navigate these type of waters, you should carry a portable air horn, which are available from local marine supply stores.

## Aids to Navigation

Learn to recognize the different buoys and day markers; they are the signposts of the waterways. The United States Aids to Navigation System (USATONS) is the primary marking system used on inland water, coastal waters and rivers in the United States. This system is maintained by the U.S. Coast Guard (USCG).

There are two primary marking systems in use in the U.S.: the Uniform State Waterway Marking System (USWMS), used on inland waters and maintained by each state, and the Federal Waterway Marking System (FWMS), used on coastal waters and rivers and maintained by the USCG. In addition, the FWMS has two modified systems: the Western River Buoyage, and the Intercoastal Waterway Buoyage. Be sure to check with local authorities on the buoyage system in use in your boating region.

The type of hazard/warning buoys and markers depends on the area of jurisdiction. Check with local boating authorities.

### USWMS System

In the USWMS Lateral System, well-defined channels are marked with red and black buoys, and the boat should pass between them.

The USWMS Cardinal System is used when there is no well-defined channel or where an obstruction may be approached from more than one direction. With the cardinal system:

- Pass north or east of BLACK-TOPPED WHITE buoy.
- Pass south or west of RED-TOPPED WHITE buoy.
- RED and WHITE VERTICALLY STRIPED buoy indicates boat should pass outside of the buoy (away from shore).



# Section I

---

## FWMS System

The FWMS Lateral System is for use on navigable waters except Western Rivers and Intercoastal Waterways. The markings on these buoys are oriented from the perspective of being entered from seaward (the boater is going toward the port). This means that red buoys are passed on the starboard (right) side of the vessel when proceeding from open water into port, and green buoys to the port (left) side.

The right side (starboard) of the channel is marked with RED, even numbered buoys. The left (port) side of the channel is marked with GREEN, odd numbered buoys.

The middle of the channel is marked with RED and WHITE vertically striped buoys; pass close to these buoys.



### Spherical Safe Water Marker

Obstructions, channel junctions, etc. are marked with RED and GREEN horizontally striped buoys.

A RED band at the top means the preferred channel is to the left of the buoy; a GREEN top band means the preferred channel is to the right of the buoy.

Day markers are colored and numbered the same as buoys. RED, triangular day markers with even numbers mark the starboard side of the channel. GREEN, square day markers with odd numbers mark the port side of the channel.



Lights, bells and horns are used on buoys for night or poor visibility conditions. Buoys with unique light flashing characteristics are identified on nautical charts with the specific flashing pattern.

## Types of Buoys

There are several types and shapes of buoys. Buoys may be unlighted, lighted, with sound or may have both an audible and a visual signal. Lights, bells and horns are used on buoys for night or poor visibility conditions. Different shapes of buoys are shown below.



Unlighted Bell Buoy




Spar Buoy



Nun Buoy



Lighted Buoy



Can Buoy

## FWMS Marking System

Buoys with unique light flashing characteristics are identified on nautical charts with the specific flashing pattern.



# Section I

---

## Mooring Buoys

The only buoys from which you are permitted to moor are mooring buoys. Mooring buoys are white with a blue horizontal stripe. Mooring to a navigation buoy, regulatory markers or lateral markers is illegal.



**Mooring Buoy – White with Blue Band  
May Show White Reflector or Light**

## Uniform State Regulatory Markers

Regulatory markers indicate dangerous or restricted controlled areas. These markers are used to indicate speed zones, areas set aside for particular use, general information and directions.

Regulatory markers are white with orange geometric shapes and also have orange bands near the top and at the water line of the buoy. You must obey regulatory markers.

**CONTROLLED  
AREA**



**DANGER**



**BOATS KEEP  
OUT**



**INFORMATION**



## Uniform State Waterway Marking System (USWMS)



**Divers Flag**



**Alpha Flag**



**Distress Flag**

**USED BY  
RECREATIONAL  
DIVERS –  
INDICATES  
POSITION.**

Stay Far Away From Diver Flags  
Someone is underwater in the vicinity

**WORLDWIDE VESSELS  
ENGAGED IN DIVING  
OPERATIONS – DOES  
NOT INDICATE  
DIVER'S POSITION**

Stay Far Away From Diver Flags  
Someone is underwater in the vicinity

**INDICATES  
FELLOW  
BOATER IS IN  
NEED OF  
ASSISTANCE**



# Section I

---

## Warning Markers

It is a good idea to ask local authorities if there are hazardous areas and how they are marked. Boaters must also recognize the flag designs, which indicate that skin divers are present and keep well clear of the area. Divers underwater cannot be seen. Stay well away from boats or floats displaying Diver Flags.



**Skin Diver Warning Flag**

Watch for swimmers. Swimming areas may not be marked. Steer clear from the area and remain alert.



**Swim Area Warning Buoy**

Navigation markers serve as a means of identifying navigable routes, and indicate water hazards. Boaters should become familiar with navigation markers and stay within marked boundaries and clear of hazards.



## Night Running

Boats operating between sunset and sunrise (hours vary by state) must use navigational lights. Nighttime operation, especially during bad weather or fog can be dangerous. All “Rules of the Road” apply at night, but it is best to slow down and stay clear of all boats, regardless of who has right of way. Protect your night vision by avoiding bright lights and have a passenger, if possible, help keep watch for other boats, water hazards and aids to navigation. It is best to proceed slowly at night, as there is always the possibility of unlit boats, floating objects, and fixed objects which will be very difficult to see in time to avoid if you are at planning speeds or above.

There are many light patterns on different types of boats and for boats performing various functions while underway or at anchor. For most applications on recreational boats the following navigation light patterns are applicable.



Figure 1

Motorboats less than 20 meters (65.62 feet) shall exhibit navigation lights as shown in **Figure 1**.

(Note: Two masthead lights are optional for boats under 50 meters. Boats over 50 meters (164 feet) will display two masthead lights.)



Figure 2

Motorboats of less than 12 meters (39 feet 4 inches) in length, may show the lights in either **Figure 1** or **Figure 2**.

Boats of less than 7 meters (23 feet) whose maximum speed cannot exceed 7 knots may exhibit an all-around white light, and if practicable sidelights instead of the lights prescribed above, **in international waters only**.



# Section I

---




Figure 3

## Sailboats and Watercraft Under Oars

Sailboats less than 20 meters (65.62 feet) may exhibit the navigation lights shown in **Figures 3** or **4**.




Figure 4



Figure 5

Another option for sailboats is to use a single combination lantern at the top of the mast as shown in **Figure 5**.



**Figure 6**

Sailboats less than 7 meters (22.96 feet) may carry an electric torch or lighted lantern showing a white light to be displayed in sufficient time to prevent collision (see **Figure 6** - left picture).

If practicable, the lights prescribed for sailboats less than 20 meters should be displayed.

Watercraft under oars (such as a canoe) may display the lights prescribed for sailboats, but if not, must have ready at hand an electric torch or lighted lantern (flashlight) showing a white light to be displayed in sufficient time to prevent collision (see **Figure 6** - right picture).



**Figure 7**

## **Anchored Boats**

Motorboats and sailboats at anchor must display anchor lights. An anchor light for a watercraft less than 50 meters (164 feet) in length is an all-around white light, visible for 2 miles exhibited where it can best be seen (see **Figure 7**).

Sailboats operating under machinery, or under sail and machinery, are considered power driven and must display the lights prescribed for a power-driven boat.



# Section I

---

## Watersports Safety

Skiers or riders are obligated to be aware of the same fundamental safety rules as boat operators. If you are new to water skiing, wakeboarding, wake surfing, and other towed watersports, seek certified training before starting. You will find it especially helpful to join a local ski club, World Wakeboard Association, and/or the USA Water Ski, when possible.

Always remember that the majority of injuries occurring while water skiing/wakeboarding and other towed watersports are the result of impacts with other objects. Always look where you are going and be aware of what is going on around you.

When participating in towing watersports, be safe and courteous and follow these guidelines:

- Be considerate to fishermen and others who are sharing the same body of water.
- DO NOT perform watersports in congested areas.
- Stay away from navigation markers.
- Stay away from other boats and watersports participants.



### **DANGER**



**Contact with a spinning propeller will cause injury or death.**

**Do not enter or exit the water when the engine is running.**

**Do not get on the swim platform when the engine is running.**

**Do not swim towards the back of the boat if the engine is running.**





## **WARNING**

Failure to adhere to these warnings may result in severe injury or death to you and/or others.

- Every towed person must always wear a USCG-approved personal flotation device.
- Always have an experienced driver and a designated observer in the boat while being towed.
- Maintain a distance of at least 100 feet from all other objects, including other boats, piers, rafts, mooring and navigational buoys, pilings, abutments, or any other items.
- Never waterski, wakeboard or participate in other towed watersports in shallow water, close to shore, or in water where you do not know the depth or what is beneath the surface.
- Never put your arm, head, or any other part of your body through the handle-bridle of the tow line nor wrap the line around any part of the body at any time.
- Never use different line lengths if towing more than one person or towable. Each person or towed device must be the same distance from the boat.
- Do not participate in watersports while under the influence of alcohol and/or drugs.
- Do not participate in watersports during inclement weather or on rough water.
- Never waterski, wakeboard or participate in other towed watersports directly in front of other boats who may run you over if you fall.
- Never waterski, wakeboard or participate in other towed watersports at night.
- Never jump from a boat that is moving at any speed.
- Make sure that everyone knows and uses approved towed watersports hand signals.



# Section I

---

## Hand Signals

Make sure that everyone knows and uses approved towed watersports hand signals, shown below.



Circle



Back to Dock



Cut Engine



Skier in Water



Skiers OK



Speed OK



STOP



Speed Faster



Speed Slower



Turn Left



Turn Right

## Towed Person Safety Responsibilities

Most injuries and fatalities that occur on high-performance recreational tow boats occur to the persons being towed (water skiing, kneeboarding, wakeboarding, wake surfing, tubing, etc.). It is the responsibility of the boat operator to pay attention to a multitude of things while utilizing the boat for water tow sports. The towed person has little or no control over their path nor do they have much in the way of protection from impact with obstacles or other boats. Therefore, it is recommended that boat operators, observers, and towed persons communicate effectively and clearly as to their intentions and their surroundings. The main responsibilities for each participant are as follows:



## **Operators should:**

- Assign a passenger to be a designated observer.
- Turn the engine off whenever a person is on the swim platform or in the water near the boat. This is especially important for the area near the back of the boat to avoid propeller injuries.
- Ensure that it is “all clear” behind the boat when starting the engine. Ask for verbal confirmation or hand signals that it is “all clear” behind the boat. Then, and only then, start the engine.
- Keep their main focus on maneuvering the boat safely while avoiding other boats, fixed objects, the shore, and shallow water.
- Use rear view mirrors to allow the driver to glance at the towed person, while still keeping their main attention on the path of the boat and the surroundings.
- Return safely to pick up towed persons or persons in the water. Keep the individual in view, approach slowly (preferably on the driver’s side), and shut off the engine when close to an individual in the water. Do not back up or operate the boat in reverse to a person in the water.

## **Observers should:**

- Confirm for the boat operator that it is “all clear” behind the boat prior to starting the engine.
- Watch the towed person.
- Be responsible for communication of the signals and status of the towed person to the boat driver.
- Notify the boat operator of status and changing conditions with the towed person, and inform the boat driver of the towed person’s readiness to start, their desire to go faster or slower, or that they have fallen and are in need of retrieval.
- Deploy the fallen skier flag when the towed person falls, if needed. In some states, it is required to raise the “fallen skier” flag when the skier has fallen.



# Section I

---

- Monitor the tow line to ensure that it does not become tangled, it does not become wrapped around anyone in the boat, and it does not become wrapped around the towed person. Also monitor the tow line so that it does not become tangled in the propeller. Notify the boat operator if any of these conditions are observed to avoid potential injury.
- Remind the boat operator to shut off the engine when persons are on the swim platform or in the water near the back of the boat.

## **Towed persons should:**

- Wear a PFD.
- Not approach the back of the boat if the engine is running.
- Not become entangled in a tow line or wrap a tow line around any body part.
- Know signals to communicate with the observer and boat operator.

## **Additional Precautions for Towed Skier/Rider**

- Wear wet suits or protective shorts when engaging in high energy skiing/riding to prevent abrasions, hypothermia, and injuries to orifices (rectal and vaginal) from impact with the water surface.
- Inspect watersports equipment for wear, fraying, etc., before use. DO NOT use if they show signs of wear or fraying. Ropes or watersport equipment tow points may break during use, causing you to coast into obstacles or fall with the risk of being struck by another vessel.
- Inspect the boat tow points before use. If there is any evidence of corrosion or other damage, do not use until it has been inspected by your authorized boat dealer.
- NEVER attach ski/wakeboard rope to anything but approved pylons and wakeboard towers. Make sure tow ropes are properly attached to the boat tow points.
- The skier/rider should verbally indicate that s/he is safely clear of the boat prior to operator starting the boat engine or putting the boat into gear.





- Slowly take up slack in tow lines before accelerating to watersports speeds. Jerking the slack out of a tow line can cause high forces on the rope and towing equipment. This may cause the rope or equipment to break and the rope to snap back at occupants of your boat and at the towed person.
- Never put your arm, head or any other part of your body through the handle/bridle of the ski or wakeboarding line, nor wrap the line around any part of the body at any time. If you fall, the line will tighten and forcefully constrict around your body part and may result in amputation.
- DO NOT ski near swimming areas, beaches, personal watercraft, or other vessels/boats.
- Never attempt land or dock starts. These activities will increase your risk of injury or death.
- DO NOT jump from a boat that is moving at any speed, nor enter or exit the water when the engine is running.
- DO NOT “back up” to anyone in the water, they will be in danger of hitting the spinning propeller which can cause severe injury or death.
- DO NOT follow directly behind another boat or skier/rider without leaving an adequate safe distance in case that towed person falls into the water. You will need ample time and distance to maneuver your boat away from that person in the water and to avoid their tow boat which will be circling back to retrieve their downed person.
- DO NOT participate in towed watersports at night. It is illegal and other boats will not be able to see you, nor will they anticipate or expect your presence behind the towing boat. Furthermore, once you fall they will not see you swimming.
- DO NOT tow with multiple skier/riders with different length ropes.
- DO NOT ski in limited visibility conditions.



# Section I

---

- Never climb, sit or stand on a wakeboard tower. The wakeboard tower is intended for towing only as noted. It is designed to pull a limited number of individual(s), and in some cases only one (1) individual. Please consult the remainder of this manual and warning labels on tower for details. The wakeboard tower approved for use on your boat should be used only for water skis, wakeboards or recreational towables, and not for parasailing, kite flying or towing other boats.
- Many states require the use of “skier down” flags. Check your local lake and state requirements. Having the observer raise a skier down flag when your towed watersport participant falls down or off the towed device will alert boats around you to the fact that someone is in the water nearby and that they should avoid the area.
- Many lakes have recommended tow patterns. Other boats may expect that you know the local customs and practices. It is common that the tow pattern is counter-clockwise around the lake, but there are exceptions. Check for local recommendations or requirements.
- NEVER lift or trailer the boat with water in the bilge or in ballast tanks. Lift or trailer per manufacturer’s instructions.
- Around marina docks where electrical current is present (such as shore power connections) it is unsafe to swim as stray electrical currents may exist which can cause you to drown.

## Tow Line Guidelines

Tow lines come in different lengths and strengths for different activities. Make sure any line you are using is suited for skiing or riding and that it is in good condition.

- Never use a tow line that is frayed, knotted, unraveling or discolored from use or being left in the sun. If a line breaks while in use it can recoil at the skier/rider being towed or into the watercraft where it might strike passengers. Replace tow lines with any sign of damage.



- Never use a tow line with elastic or bungee material to pull skiers or riders.
- Tow line should be attached to the watercraft in an approved fashion with hardware designed for towing. Refer to your watercraft manual for instructions on proper tow line attachment.
- Always route tow lines away from the propeller, even when idling. Shut off the engine if your boat starts to cross a floating tow line.
- If a tow line should become entangled in a propeller, shut off engine, remove the key and put it in your pocket before retrieving the line.
- Tow lines should be neatly coiled and stowed in the boat when not in use.

## **Fallen Skier or Rider**

Falling and injuries are common in water skiing and other towed watersports. Keep tow speeds in a comfortable range given the rules of the activity and the skill level of participants.

- Display a red or orange skier/rider down flag to alert other vessels that a skier/rider is down. In some states, it is required to raise the “fallen skier” flag when the skier has fallen.
- Turn the boat and slowly circle toward the person in the water to return the tow line handle or towed device to that person.
- Always keep the fallen skier/rider in view and preferably on the operator’s side of the watercraft.
- Put the watercraft in neutral whenever you are near a fallen skier/rider.
- Shut off the engine when retrieving someone from the water or if the person in the water gets too close to the boat. Do not trust neutral gear with an idling engine. Someone may accidentally or prematurely shift the gear, or the linkages may be out of adjustment and the propeller may still be slowly spinning.



# Section I

## Develop WATER SENSE

The Watersports Responsibility Code and the Watersports Safety Code have been developed by WSIA and industry equipment manufacturers. These Codes are reproduced here for your reference.

### Watersports Responsibility Code



Familiarize yourself with and follow The Watersports Responsibility Code

**WATERSPORTS RESPONSIBILITY CODE**

Be aware that there are risks in boating and Watersports that good judgment and personal awareness can help reduce. To increase your enjoyment of Watersports, follow the ten elements of the Code.

**In Watersports it is your responsibility to:**

- **ALWAYS** familiarize yourself with applicable laws, waterways and inherent risks
- **ALWAYS** have a capable observer in addition to driver and agree on hand signals
- **ALWAYS** wear a USCG type III, ISO or other agency approved (PFD) life jacket
- **ALWAYS** read user's manual and inspect equipment before use
- **ALWAYS** ski or ride under control, at proper speeds and within your limits
- **ALWAYS** turn ignition off when anyone is near watercraft power drive unit
- **ALWAYS** stay clear of engine exhaust to avoid Carbon Monoxide poisoning
- **NEVER** "Platform Drag" or touch swim platform while the engine is running
- **NEVER** ski or ride near swimmers, shallow water, other boats, or obstacles
- **NEVER** operate watercraft, ski or ride under the influence of alcohol or drugs

**wsia**  
WATER SPORTS INDUSTRY ASSOCIATION

**BOAT Responsibly**



## Watersports Safety Code

### WATERSPORTS SAFETY CODE

**Before you get in the water:** Skiing or riding instruction is recommended before use. Instruction will teach general safety guidelines and proper skiing or riding techniques, which may reduce your risk of injury. For more information on skiing or riding schools, contact your dealer, Association, or local ski club.

- Know the federal, state and local laws that apply to your area.
- If you are not familiar with a waterway, ask someone who is knowledgeable to tell you about any hidden dangers or things to avoid.
- Whether you plan to be in a watercraft, or skiing/riding behind one it is important you are wearing a properly fitted life jacket (PFD) approved by your country's agency, USCG Type III, ISO, etc.
- Inspect all equipment prior to each use, check bindings, fins, tube, attachment, tow rope and flotation device. Do not use if damaged.

**Watercraft Safety:** A knowledgeable and responsible driver is the most important safety device on any watercraft.

- Never operate a watercraft, ski or ride under the influence of alcohol or drugs.
- Only use water ballast and people for additional weight.
- Never exceed the passenger or weight limitations of the watercraft.
- Never allow passengers to hang outside the watercraft or towed device or sit on the gunwales or anywhere outside of the normal seating area.
- Never allow water to overflow the bow or gunwales of the watercraft.
- Uneven weight distribution or additional weight may affect the handling of the watercraft.



## Section I

---

**Carbon Monoxide:** The exhaust from the engine on a watercraft contains Carbon Monoxide (CO) which is a colorless, odorless and poisonous gas. Excessive exposure to CO can cause severe injury or death. Follow this advice to avoid injury.

- Never “Platform Drag” by holding onto the boarding platform or being dragged directly behind the watercraft. This is where CO will be.
- Do not sit on the watercraft transom or boarding platform while the engine is running.
- Make sure the engine is properly tuned and running well. An improperly tuned engine produces excessive exhaust and CO.
- If you smell engine exhaust do not stay in that position.
- Go to the United States Coast Guard’s website: ([www.uscgboating.org](http://www.uscgboating.org)) for more information on how to help protect yourself and others from the dangers of CO.

**Tow Ropes:** Tow ropes come in different lengths and strengths for different activities. Make sure any rope you are using is suited for that activity and that it is in good condition.

- Never use a rope that is frayed, knotted, unraveling or discolored from use or being left in the sun. If a rope breaks while in use it can recoil at the skier/rider being towed or into the watercraft where it might strike passengers. Replace tow ropes with any sign of damage.
- Never use a tow rope with elastic or bungee material to pull skiers or riders.
- Rope should be attached to the watercraft in an approved fashion with hardware designed for towing. Refer to your watercraft manual for instructions on proper tow rope attachment.
- Always keep people and tow ropes away from the propeller, even when idling.
- If a tow rope should become entangled in a propeller, shut off engine, remove the key and secure it in a safe location before retrieving the rope.
- Tow ropes should be neatly stowed in the boat when not in use.



**Preparing to ski or ride:** Always have a person other than the driver act as an observer to look out for the skier/rider.

- Be sure the driver is aware of the experience and ability of the skier/rider.
- The driver, observer and skier/rider need to agree on hand signals before skiing or riding. Signals should include READY, STOP, SPEED UP, and SLOW DOWN.
- Start the engine only after making sure that no one in the water is near the propeller.
- Turn the engine off when people are getting into or out of the watercraft, or in the water near the watercraft.
- Always make sure the tow rope is not wrapped around anyone's hands, arms, legs, or other parts of the body.
- Start the watercraft and move slowly to remove slack until the tow rope is tight.
- When the skier/rider signals READY and there is no traffic ahead, take off in a straight line. Adjust the speed according to the signals given by the skier/rider.

**Skiing or Riding:** The watercraft and skier/rider should always maintain a sufficient distance from obstacles so a skier/rider falling or coasting and/or watercraft will not encounter any obstacle.

- Do not use in shallow water or near shore, docks, pilings, swimmers, other watercraft, or any other obstacles.
- Use only on water.
- Never attempt land or dock starts. This will increase your risk of injury or death.
- Always wear a properly fitted life jacket (PFD) approved by your country's agency, USCG Type III, ISO, etc.
- The faster you ski or ride, the greater your risk of injury.
- Never make sharp turns that may cause a slingshot effect on the skier/rider's speed.
- The skier/rider should be towed at an appropriate speed for his or her ability level.



# Section I

---

**Fallen skier or rider:** Falling and injuries are common in skiing or riding.

- Circle a fallen skier/rider slowly to return the tow rope handle or pick up the fallen skier/rider.
- Turn off the engine when near a fallen skier/rider.
- Always keep the fallen skier/rider in view and on the driver's side of the watercraft.
- Display a red or orange skier-down flag to alert other vessels that a skier/rider is down if required by the state in which you are operating.

**The Warnings and practices in the Watersports Safety Code represent common risks encountered by users. The code does not cover all instances of risk or danger. Please use common sense and good judgment.**





## Emergency Procedures

In an emergency situation, you may have to resort to measures which are not commonly practiced. Always assess the dangers of being in harm's way versus the protection of equipment. Keep a sound mind during an emergency and always use common sense.

### Explosion and Fire

Many boat fires and explosions involve flammable liquids such as gas or oil, which are used in your boat's propulsion engine(s) and generator. Carefully follow all warning labels and safety precautions while handling flammable substances. Many fires in inboard boats start in the bilge area due to gasoline vapors. Gasoline vapors are heavier than air and collect in the bilge of boats.

#### *Explosion*

- If explosion is imminent, put on PFDs, grab distress signals and survival gear, and immediately abandon ship.

#### *Fire*

- Immediately turn off engines, generators, stoves and blowers.
- Extinguish smoking materials.
- A fixed fire suppression system, if equipped, has heat sensors that automatically flood the machinery space with a fire extinguishant. Allow extinguishant to "soak" the compartment for at least 15 minutes to cool the hot metals or fuel before cautiously inspecting the fire area. Have portable fire extinguishers ready. Do not breathe fumes or vapors caused by the fire or extinguishant.
- If no fixed fire suppression system is installed and a fire is in the engine compartment, discharge portable fire extinguishers through the engine compartment access plate, if equipped. DO NOT open the engine hatch as this feeds oxygen to the fire.
- If you have access to the fire, direct the contents of the fire extinguishers at the base of flames, not at the top.



# Section I

---

- Throw burning materials overboard if possible.
- Move anyone not needed for firefighting operations away from the flames.
- Signal for help.
- Put on PFDs (Personal Flotation Devices), grab distress signals and survival gear, and prepare to abandon ship.



## **WARNING**

**Burn hazard from gasoline floating on water which is ignited can cause death or serious injury.**

**Gasoline will float on top of water and can burn. If the boat is abandoned, swim upwind, far enough to avoid fuel that can spread over the surface of the water.**

## **Swamping and Flooding**

In the event that the vessel begins to take on water, turn on the bilge pump to evacuate water and slow its accumulation, and try to determine the source of the water. A collision with an underwater object can cause the hull to develop a leak. A loose fitting hose clamp on a piece of equipment can cause a leak. Try to repair the leak if possible. If a leak is threatening the safety of you and your passengers, call or signal for assistance.

- Turn on bilge pump(s).
- Access PFDs, pass them out to everyone, and put them on.
- Identify source of leak and try to stop the leak and flooding.
- **STAY WITH THE BOAT!** A boat will usually float even if there is major hull damage. Rescuers can spot a boat much easier than a head bobbing in the water.
- Signal or call for help.
- If others were on board, try to locate them, make sure that they are conscious and that they can swim.
- Immersion in water speeds the loss of body heat and can lead to hypothermia (the abnormal lowering of internal body temperature).



## Capsizing

- If others were on board, try to locate them, make sure that they are conscious and they can swim.
- If possible, access lifejackets (PFDs), pass them out to everyone, and put them on.
- **STAY WITH THE BOAT!** A boat will usually float even if there is major hull damage. Rescuers can spot a boat much easier than a head bobbing in the water.
- Signal or call for help.
- Immersion in water speeds the loss of body heat and can lead to hypothermia (the abnormal lowering of internal body temperature).

## Staying Afloat

- Remain calm. Do not thrash about or try to remove clothing or footwear. This leads to exhaustion and increases the loss of air that may keep you afloat.
- Keep your lifejacket (PFD) on.
- Keep your knees bent.
- Float on your back and paddle slowly to safety.

## Collisions

- Immediately account for all passengers.
- Check for injuries.
- If any person is in the water make sure they have proper flotation devices.
- Assess the hull for damage.
- Activate the bilge pump(s) to reduce any flooding.
- Try to operate the boat to keep the damaged area above water.
- If necessary, call or signal for assistance.
- **STAY WITH THE BOAT!**



# Section I

---

## Grounding

In the event you run aground, assess the situation before proceeding. Your response to grounding will depend on how hard the boat hits bottom and whether the boat remains stranded, the extent of damage, and proximity to shore and help.

- If it is a simple touch, you may need only to inspect the hull.
- If you are aground, assess the situation before reacting. In some cases, throwing the boat into reverse can cause more damage.
- Check for leaks and immediately stop any water from entering the boat.
- Inspect the hull, steering system and propulsion system for damage.
- Maneuver the boat to safe water only if the hull and all operating systems are in satisfactory operating condition. Otherwise, call or signal for assistance.

## Person Overboard

- Immediately react to a person who has fallen overboard by sounding an alarm.
- Keep the victim constantly in your sight.
- If another passenger is on board, assign them to look at and keep pointing at the person in the water. They are to do nothing else but stay focused on the person in the water and to point at them.
- Throw the person a life preserver even if they are wearing a PFD. It will serve as a marker in the water and will provide additional flotation.
- Immediately slow or stop the boat and safely circle toward the victim as soon as possible.
- Keep the victim on the helm side of the vessel so as to keep the victim constantly in your sight.
- When almost alongside, shut off the engine.
- Assist the person into the boat.



## Drowning

- Swim to rescue a drowning victim only as a last resort.
- Immediate resuscitation is critical! It may be possible to revive a drowning victim who has been under water for some time and shows no sign of life. Start CPR immediately and get the victim to a hospital as quickly as possible.
- Keep the victim warm.
- Use care in handling. Spinal injury may exist if the victim fell overboard.
- Call and signal for help.

## Medical Emergency

In an emergency, you may be far from professional medical assistance. Be prepared and know how to use your first aid kit. Be aware of any special medical conditions of your passengers.

## Operation Failure

If you experience a propulsion, electrical, steering or control failure, immediately shut off the engine. If it is safe to do so and you are qualified, then try to determine the cause of the failure and repair. Otherwise, call or signal for assistance. Anchor the boat if drifting will put you and others in danger.

## Towing



### **WARNING**

Towing or being towed stresses the boats, hardware and lines. Failure of any part can seriously injure people or damage the boat.



## Section I

---

A recreational boat towing another should be a last resort due to the potential for damaging one or both boats. The Coast Guard or a private salvage company is better equipped for this activity. A recreational boat may assist by standing by, and possibly by keeping the disabled boat's bow at a proper angle until help arrives. Only when conditions are ideal—that is, waters are calm, disabled boat is small, appropriate hardware is available, and one or both skippers know the correct technique—should a recreational boat tow another.

### *Towing Vessel*

- Be sure your boat will not run aground too.
- Because you are maneuverable and the grounded boat is not, you should pass the tow line to the grounded boat.
- Select an appropriately strong tow line. Use double-braided or braid-on-braid line. Never use three-strand twisted nylon; it has too much elasticity and can snap back dangerously.
- Select an appropriate attachment point. If available fasten the tow line to the forward tow pylon of the towing boat. Otherwise fasten tow line to stern tow point. Fastening to the stern tow point will restrict maneuverability of the towing boat.
- If possible, use a bridle.
- Move slowly to prevent sudden strain on slack line.
- Proceed at slow speed.
- Avoid abrupt changes in throttle as that may cause the tow line to slacken and jerk tight. Sudden strain or jerking the line causes excessive tow line forces which may part the line. Keep slack out of the tow line, but if it occurs proceed slowly to again take up the strain on the line and avoid sudden jerks in the line.
- Be ready to cast loose or cut the line if the towing situation becomes hazardous.



## *Vessel Being Towed*

- Attach the tow line to the bow eye.
- If it is necessary to be towed after being freed, keep someone at the wheel to steer.

## *Both Vessels*

- If you attach the tow line to a fitting, be sure the fitting is fastened with a through bolt and is reinforced on the underside.
- Keep lines clear of propellers on both boats.
- Keep hands and feet clear of the other boat. Do not get caught, or pinched between the two boats as severe injury could occur.
- Never hold a tow line after it is pulled taut.



## NOTES







## Section 2

### 200-OB, 200-CB, 200-V

## Specifications

### 200-OB, 200-CB

Length Overall.....	20' 0" (6.10 m)
Length with Platform.....	21' 10" (6.65 m)
Lifting Ring Spacing .....	18' 10" (5.73 m)
Beam.....	95" (2.41 m)
Draft.....	22" (0.56 m)
Approximate Dry Weight* .....	2,850 lbs (1,293 kg)
Fuel Capacity .....	27 Gallons (102.1 L)
Maximum Capacity:	
Open Bow.....	9 People (1,450 lbs/658 kg)
Closed Bow .....	7 People (1,450 lbs/658 kg)
Horsepower Range .....	343, 355, 450 HP (256, 265, 336 kW)
Torque Range .....	370, 405, 465 lb-ft (502, 549, 631 N·m)
Gear Reduction Ratio.....	1.23:1

### 200-V


Length Overall.....	20' 0" (6.10 m)
Length with Platform.....	21' 10" (6.65 m)
Lifting Ring Spacing .....	18' 9" (5.72 m)
Beam.....	95" (2.41 m)
Draft.....	23.5" (0.60 m)
Approximate Dry Weight* .....	3,250 lbs (1,474 kg)
Fuel Capacity .....	28 Gallons (106.0 L)
Maximum Capacity .....	10 People (1,600 lbs/726 kg)
Horsepower Range .....	343, 409 HP (256, 305 kW)
Torque Range .....	370 lb-ft (502 N·m)
Gear Reduction Ratio.....	1.48:1
Maximum Factory Ballast Capacity.....	736 lbs (334 kg)

\* Weights are estimates and can vary from options and equipment added.

# Section 2

NOTICE

*The dash configurations used in this section may show more features than what is included in your Nautique.*



CORC0582



## 200 Nautique Dash Pod and Console


1. Stereo
2. RPM 3 in 1 Gauge w/Oil & Temp
3. Service Soon Light
4. Check Engine Light
5. Speedometer 3 in 1 Gauge w/Fuel & Volt
6. Keypad
7. Fire Extinguisher System – optional
8. Zero Off Speed Control – optional
9. SportShift™ Hydro-Gate™ Control Handle
10. Shifter/Throttle Control Handle
11. Shift Safety Lock-out Umbrella
12. Shift Override Button
13. Emergency Stop Switch
14. Driver's Seat Heater Switch
15. Ballast Pump Switch (200-V only)
16. Cockpit Heater Switch
17. Depth Finder Gauge w/Air & Water Temp
18. Steering Wheel Tilt Lever

### NOTICE

*A full description of the gauges and switches and their functions is discussed in **Section 3**.*



# Section 2




## **200-OB, 200-CB Team Dash Pod and Console**

1. Pocket Panel
2. Warning and Danger Decal
3. RCA Video Input
4. USB and Auxiliary Input\*
5. Nautique LINC System
6. Keypad
7. Fire Extinguisher System – optional
8. SportShift™ Hydro-Gate™ Control Handle
9. Shifter/Throttle Control Handle
10. Shift Safety Lock-out Umbrella
11. Shift Override Button
12. 12V Port
13. Emergency Stop Switch
14. Steering Wheel Tilt Lever

\* *This USB port communicates directly to the LINC and allows you to install LINC updates. It is not intended for use with MP3 players or other audio/video devices.*

## **Keys**




CORC0618

**Hatch Latch Key**



# Section 2



CORC0584



## 200-V Team Dash Pod and Console

1. Pocket Panel
2. RCA Video Input
3. USB and Auxiliary Input\*
4. Nautique LINC System
5. Keypad
6. Fire Extinguisher System – optional
7. Zero Off Speed Control
8. SportShift™ Hydro-Gate™ Control Handle
9. Shifter/Throttle Control Handle
10. Shift Safety Lock-out Umbrella
11. Shift Override Button
12. Emergency Stop Switch
13. 12V Port
14. Steering Wheel Tilt Lever


\* *This USB port communicates directly to the LINC and allows you to install LINC updates. It is not intended for use with MP3 players or other audio/video devices.*

### NOTICE

*A full description of the gauges and switches and their functions is discussed in **Section 3**.*



# Section 2



CORC0321






## **Keypad**

1. Stop Function
2. Blower Indicator
3. Blower Function
4. Navigation Light Indicator
5. Navigation/Anchor Light Function
6. Anchor Light Indicator
7. Bilge Function
8. Bilge Indicator
9. Horn Function
10. Code Buttons
11. Ignition Indicator
12. Start/Unlock Function
13. Accessory Indicator



# Section 2

## 200 Open Bow Deck Layout



CORC0585



## **200 Open Bow**


### **Description**

1. Bow Navigation Light
2. Bow Lifting Ring
3. Horn
4. Bilge Pump Outlet
5. Dash Pod
6. Standard Speedometer Calibration Adjustment
7. Console
8. Engine Cover
9. Rudder Shaft Remote Lube Fitting
10. Propeller Shaft Stuffing Box
11. Fuel Vent
12. Ski Locker Storage/Anchor Light Storage
13. CE Bilge Pump Filter
14. Anchor Light Receptacle
15. Fuel Tank Fill
16. Boarding Platform
17. Stern Lifting Ring
18. Engine Cooling Water Intake Shutoff Valve
19. Engine Cooling Water Intake Strainer
20. T-handle Drain
21. Watersports Tow Point
22. Operator's Seat Adjustment
23. Battery
24. Observer's Seat Storage
25. Glove Box/Stereo/USB/12V
26. Observer's Seat Heater On/Off Button (optional)



# Section 2

## 200 Closed Bow Deck Layout



CORC0586




## **200 Closed Bow**

### **Description**

1. Bow Navigation Light
2. Bow Lifting Ring
3. Horn
4. Bilge Pump Outlet
5. Dash Pod
6. Standard Speedometer Calibration Adjustment
7. Console
8. Engine Cover
9. Rudder Shaft Remote Lube Fitting
10. Propeller Shaft Stuffing Box
11. Fuel Vent
12. Ski Locker Storage/Anchor Light Storage
13. CE Bilge Pump Filter
14. Anchor Light Receptacle
15. Fuel Tank Fill
16. Boarding Platform
17. Stern Lifting Ring
18. Engine Cooling Water Intake Shutoff Valve
19. Engine Cooling Water Intake Strainer
20. T-handle Drain
21. Watersports Tow Point
22. Operator's Seat Adjustment
23. Battery
24. Observer's Seat Storage
25. Glove Box/Stereo/USB/12V
26. Observer's Seat Heater On/Off Button (optional)



200 V-Drive Deck Layout



CORC0587



## **200 V-Drive**


### **Description**

1. Bow Navigation Light
2. Bow Lifting Ring
3. Belly Ballast Tank Vent
4. Dash Pod and Console
5. SportShift™ Hydro-Gate™ Control Handle
6. Removable Pylon
7. T-Handle Drain Plug
8. Engine Cooling Water Intake Shutoff Valve
9. Engine Cooling Water Intake Strainer
10. Fuel Tank Fill
11. Fuel Tank Vent
12. Forward Bilge Pump Outlet
13. Starboard Ballast Tank Vent
14. Trunk Storage Access
15. Anchor Light Receptacle (not included with Flight Control Tower™ option)
16. CE Bilge Pump Filter
17. CE Fire Suppressor
18. Rudder Port Remote Lube Fitting
19. Boarding Platform
20. Watersports Tow Point
21. Battery Circuit Panel and Switch
22. Port Ballast Tank Vent
23. Rear Bilge Pump Outlet
24. Battery
25. Engine Cover Latch
26. Port, Belly and Starboard Ballast Water Intake/Drain Valves
27. Observer's Seat/Storage Access
28. Glove Box/Stereo/Auxiliary Input/12V Port
29. Observer's Seat Heater On/Off Button (optional)

The 200 is available with one battery, which is located in the port aft storage area. The battery selector switch is located under the helm.



200-OB Seating Area




CORC0610






## **200-CB Seating Area**



CORC0609



**200-V Seating Area**



10

Designated  
Occupant  
Positions

CORC0611



### Standard and Optional Equipment

Nautique boats are equipped with only the finest standard and optional equipment available. Your boat's equipment will vary, based on how your boat was built. Many options can only be installed during the manufacturing of the boat and cannot be retro-fitted to boats in the field.

Not all of the standard or optional equipment's use, safety and maintenance information can be covered in this manual. You will find most of the standard and optional equipment in this manual in the section pertaining to its use and function in **Section 3**. Make sure you read and understand this manual and all other manufacturers' literature provided in your Skipper's Kit to ensure your safety and maximize the benefits and uses this equipment has to offer.

If you have any questions regarding the use of any equipment on your Nautique boat, contact your Nautique dealer.



### NOTES





## Section 3

# Controls and Indicators

Knowing the systems, controls and indicators on your boat is essential for safe and proper operation.




### **WARNING**

Improperly maintained controls are hazardous and may cause sudden loss of control. Make sure all steering and shift / throttle hardware, cables and fluid levels are regularly inspected and maintained. Improper maintenance may result in a loss of control, possibly causing serious injury or death.

## Steering

The steering system in your Nautique boat provides excellent maneuvering performance for pleasure boating or during watersports. Boat steering is not self-centering. Always keep a secure grip on the steering wheel to maintain full boat control. The steering wheel is equipped with a tilt lever to adjust the wheel angle to a comfortable operating position when the boat is not moving.



CORC133

## Section 3

---

The helm transfers rotary motion of the steering wheel to linear motion in the cable which pushes or pulls the rudder. Nautique rudders are equipped with an adjustable trim tab under license from Z-Marine (U.S. patent 5,746,147) to compensate for the torque generated by the propeller.

Maintenance for the steering system is minimal because there are few serviceable parts. The rack and pinion for the system is lubricated and sealed during manufacturing. It is the responsibility of the owner/operator to inspect the steering system frequently.

If you experience difficulty in steering, refer to **Section 7 - Care and Maintenance**.



### **WARNING**

**Hazard from improper maintenance of the controls can cause death or serious injury from sudden loss of control. DO NOT operate your boat if you suspect the steering system or control are malfunctioning.**

Make sure all steering and shift/throttle hardware, cables and fluid levels are regularly inspected and maintained. Have your Nautique dealer investigate any steering system or control irregularities immediately.


## **Hydro-Gate™ Control and SportShift™**

The Hydro-Gate is engaged by moving the SportShift Hydro-Gate control handle located at the helm's starboard side fore and disengaged by moving the lever aft. When the control handle is pushed forward, into the SLALOM•CRUISE (DOWN) mode, the Hydro-Gate is engaged, creating maximum lift for a Tournament Slalom Wake. When the control handle is pushed aft, into the TRICK/JUMP (UP) mode, the Hydro-Gate is disengaged (raised), allowing your boat to sit deeper in the water, creating the optimum trick wake. The control handle can be placed in any position to create the ultimate wake. The SportShift and Hydro-Gate can be used at any speed or at rest.




# Controls and Indicators

---



CORC142A



CORC143A



## Section 3

### Shifter/Throttle




#### **WARNING**

**Hazard from replacing your shift/ throttle control without a start-in-gear protection system can cause death or serious injury. DO NOT replace the control with a control that does not have this feature.**

Your Nautique boat is equipped with a Shifter/Throttle Control Handle which features a start-in-gear protection to prevent the boat from moving when started.

A single-lever control with a safety lock-out umbrella operates as both a gear shifter and a throttle control. To engage the throttle only without shifting into gear, depress the Shift Override button. When the throttle lever is vertical, it is locked in the NEUTRAL position for safety. Be sure the control is in NEUTRAL before attempting to start the engine. Lifting the safety lock-out umbrella and moving the throttle lever forward will engage FORWARD gear in the transmission and increase the engine RPM. Moving the throttle lever backward will engage REVERSE gear in the transmission and also increase the engine RPM.



CORC0579



#### **CAUTION**

**DO NOT shift too quickly from FORWARD to REVERSE. Stay in NEUTRAL, or idle position until the boat has lost most of its headway before completing the shift to REVERSE or engine / transmission damage may occur.**






## Emergency Stop Switch

The emergency stop switch will stop the engine when the lanyard is pulled far enough to disengage it from the switch. Attach the lanyard to the boat operator whenever the engine is running but be aware there will be a loss of engine power if the switch is activated. If the operator is thrown from the seat, or moves too far from the helm, the lanyard will become disconnected from the switch, shutting off the engine. Refer to **Section 1** for more information.



### CAUTION

**DO NOT** allow your boat to be operated without the proper use of the emergency stop switch and lanyard.



To attach a lanyard, connect the clip to the emergency stop switch and the hook to a strong piece of clothing on the operator, such as a belt loop.

### NOTICE

*The engine will not start unless the emergency stop switch is attached.*



## Section 3

---



### **WARNING**

**Hazard from improper use of the emergency stop switch can cause death or serious injury. The emergency stop switch is designed to stop the engine if the operator is accidentally thrown from the helm. Attach the lanyard to the operator before starting the engine.**

The emergency stop switch can only be effective when it is in good working condition.

Observe the following:

- **DO NOT** remove or modify an emergency stop switch and/or its lanyard.
- The lanyard must be free from obstructions that could interfere with its operation.

Once a month: Check the emergency stop switch for proper operation. With the engine running, pull lanyard. If the engine does not stop, see your Nautique dealer for service of the switch.

## Nautique Dash Pod

### Gauges

#### RPM 3 in 1 Gauge w/Oil & Temp

- **Tachometer / Hour Meter** - Registers engine speed in revolutions per minute (RPM). Use the tachometer to keep the engine within the proper operating range. Consult the engine manual for the proper RPM operating range of your engine.
- **Oil Pressure** - Measures the pressure of the engine's lubricating oil. Refer to the engine manual for normal operating pressure. Many serious engine problems are reflected on oil pressure gauge readings. If the pressure is lower than the manufacturer's specification, immediately turn off the engine. Contact your Nautique dealer to correct the problem before operating the engine.



# Controls and Indicators

---

- **Temp** - Indicates the engine coolant temperature. Refer to the engine manual for normal operating temperature. After starting the engine, check your temperature gauge for abnormally high readings. If the reading is outside the manufacturer's operating range, immediately turn off the engine. An abnormally high temperature indicates a cooling system problem. Consult your Nautique dealer when experiencing a high engine temperature reading.

## Speedometer 3 in 1 Gauge w/Fuel & Volt

- **Speedometer** - Your Nautique is equipped with a precision speedometer by Faria. This gauge registers forward speed in miles per hour (optional kilometers per hour). The speedometer is equipped with an adjustment knob to calibrate speedometer accuracy. You can also use this gauge to monitor fuel consumption and propeller performance.
- **Fuel** - Indicates the approximate fuel level in the fuel tank. The accuracy of the fuel gauge may vary as the altitude of the boat changes; the reading is only an approximation. As a general guideline, always use the "one-third" rule. Use one third of the fuel to reach your destination, one third to return and one third as reserve fuel.
- **Volts** - Indicates the condition of the engine's cranking battery in volts DC. With the ignition switch on and the engine not running, a reading above 12.5 volts indicates a fully charged battery. With the engine running at idle, the gauge should read between 12.5 and 13 volts. With the engine running at cruising speeds and above, it should show 13 to 14.5 volts. Have your Nautique dealer check the charging system if the voltmeter reads outside these normal ranges.

**Hour Meter** - The hour meter LCD display registers accumulated engine operating time. Time will not be logged unless the ignition switch is on and the engine is running. Use the hour meter to keep accurate logs for scheduled maintenance.

**Engine Warning Light** - Indicates high engine temperature. If light illuminates, stop engine and investigate for cause.



## Section 3

---

**Service Soon Light** - For quality control check. When ignition is turned on without cranking the engine, the red “check engine” light will turn on for a few seconds and then turn off. The amber “service soon” light will turn on and stay on until either the engine is started or the ignition is switched off. When the engine is running, both lights will be off. The amber “service soon” light will come on if there is a problem with the catalyst system. The red “check engine” light will come on for all other engine-related problems.

### Speedometer Calibration

The speedometer calibration control knob is located on the under side of the deck beneath the dash pod above the driver’s right knee. Drive the boat at a known speed using a GPS or measured course and adjust the knob until the speedometer is reading correctly. Turning the knob one direction will raise the needle reading while turning it in the other direction will lower the reading.

### Control Switches

Each electrical circuit on your boat is equipped with a control switch. The switches have an indicator light for easy ON/OFF identification. All switches are fuse protected.

If a short is detected, the associated LED will flash on the buttonpad. To reset the circuit, turn off the offending load, stop the engine, then hold the STOP button for a couple of seconds until the flashing stops. For PDM-driven loads, or loads like the HORN that do not have a dedicated LED, the backlights flash instead.



#### Engine Compartment/Bilge Area Blower

The “BLOWER” switch activates the engine compartment ventilation blower to remove explosive fumes from the area. The blower is turned on by pressing and releasing the “BLOWER” switch. Press again to turn off. The blower must be operated for a minimum of four minutes each time before starting the engines or generator. In addition, the blower should be operated continuously when at idle or running at slow speeds.



# Controls and Indicators



## **WARNING**

Explosion and fire hazard from gasoline vapors can cause death or serious injury from failure to check for fumes in the engine compartment or operating the blower. Before engine start-up, check engine compartment for gasoline vapors, then operate blower for at least four minutes. Operate blower whenever below planing speed.



## **WARNING**

The intakes that supply fresh air into the bilge area are located in the port and starboard aft storage compartments in the Ski 200 and along the footer of the windshield in the Sport 200. The intakes must remain clear to allow air to enter the bilge area. **DO NOT** drape towels or any items which may not allow air to be drawn in while the bilge blowers are operating.



## **Navigation Lights**

The “NAV/ANCHOR” switch controls the navigation lights. The law requires the bow light and the 360 degree light (located near the stern) be turned on while running the boat after sunset or before dawn. NAV position will turn on the red and green navigation bow lights, 360 degree white stern light and gauge illumination.



## **WARNING**

Blocking navigation lights can cause death or serious injury. **DO NOT** block the navigation lights.



## Section 3

---



### Anchor Light

The “NAV/ANCHOR” switch turns on the 360 degree light. Insert this light pole into the receptacle located near the stern and push the anchor switch on the pod to turn this light on. This light is required by law to be on after sunset and before dawn when the boat is not moving.



### Bilge Pump

The “BILGE” switch turns on the bilge pump to remove excess water from the bottom of the boat. The 200 has a bilge pump in front of the engine and an additional bilge pump at the back of the boat. When you turn the switch on, the pump(s) will operate and run for several moments to “sense” if there is water in the bilge. If there is water in the bilge, the pump(s) remains on until the water is pumped out. If there is no water in the bilge, the pump(s) will turn off. If you want immediate pump action, turn the switch off and then back on again. The pump(s) will turn on periodically to determine if there is water in the bilge. If so, they will remain on until the water is pumped out.

The bilge switch must be turned on for this feature to operate. This will not drain significant power from the battery unless the bilge pump(s) is required to run frequently because of a leak or excessive rainwater. This pumping system should not be relied on over an extended period of time. Frequently inspect your boat for evidence of excessive water in the bilge area. Consult your Nautique dealer if you have any questions.

### NOTICE

*Trash in bilge area can damage the bilge pumps.*





The “HORN” button is a momentary switch. The horn will operate whenever the button is pressed and will stop when the button is released.

## **Check Engine Light**

This light will turn on when the ignition is turned (engine not cranking); it will turn on for a few seconds, then turn off. The Check Engine light will come on for all other engine-related problems. This light will be off when the engine is running. Refer to the engine manual for additional information.

## **Service Soon Light (Catantium Engine Only)**

This light will turn on and stay on until either the engine is started or the ignition is switched off. The Service Soon light will come on if there is a problem with the catalyst system. This light will be off when the engine is running.

## **Heater Switch-Optional**

The optional heater can be turned on through the Nautique LINC display (Team boats only) or a switch mounted on the driver’s throttle panel (Nautique boats).

## **12-Volt Port**

This receptacle can be used to power and charge cellular phones, MP3 players, video cameras or other electronics. These receptacles are powered through a 10-amp fuse.




## Section 3

---

### Nautique Digital Cruise

#### Home Screen



When the ignition is turned to the ON position, the Nautique Digital Cruise gauge will flash the Nautique corporate logo until the internal software is booted up, then the display screen will show the following:


- Set Speed – displays the last speed that was selected as the desired controlled speed
- ON/OFF – defines if the speed control function is activated or not
- Depth – displays current water depth from the keel
- Water/Air Temp – automatically toggles between water and air temp
- Actual Speed – displays the actual speed the boat is traveling





# Controls and Indicators

## Ballast Screen



If your boat is equipped with a ballast system, you can press and release the **SELECT** button to toggle to another screen that will display the water levels in each ballast tank.

## Actual Speed Calibration

The actual speed can be calibrated through the Menu Options choice entitled “Calibrate Paddle Wheel.”

## Setting Speed Control

Press and release the **ON/OFF/MENU** button to activate the speed control function. Push the throttle control handle down towards full throttle until you hear a beep. The Nautique Digital Cruise will now allow the boat to accelerate to the set speed. To disengage the Nautique Cruise, press and release the **ON/OFF/MENU** button. Nautique Digital Cruise will still control the speed until the throttle is reduced below the set speed.

Set speed can be adjusted with the Nautique Digital Cruise on or off by pressing the **UP/DOWN**  $\triangle \nabla$  arrow buttons until the desired speed is displayed on the screen. This allows the user to make fine adjustments during a run or have the next desired speed set and ready for the next user.



## Section 3

---

### Depth

The Depth function includes an audible and visual alarm that can be set to sound when a minimal water depth is present. If audible alarm sounds, pressing the **SELECT** button will silence the alarm. The alarm resets itself when the boat enters water that is deeper than the shallow setting. Adjustments can be made to the depth setting through the Menu Option screen.

### Menu Options

Push and hold the **ON/OFF/MENU** button, and use the **UP/DOWN**  $\triangle \nabla$  arrows to select Scrn. Use the **UP/DOWN**  $\triangle \nabla$  arrows to select Diagnostics. Push and release the **ON/OFF/MENU** button 2 times to display system errors. Pressing the **SELECT** button will clear all current readings. Push and hold the **ON/OFF/MENU** button to exit back to Scrn or Set.

Use the **UP/DOWN**  $\triangle \nabla$  arrows to select Set. Pressing the **SELECT** button will bring up a menu that includes:

- Calibrate Paddle Wheel
- Set Depth / Alarm Level
- Back Light / Contrast Adjust
- Buzzer Volume Adjust
- Units: English, Metric
- Time Zone Adjust (remains disabled unless using GPS upgrades)
- Reserved (this is available space for manufacture upgrades)
- Can Term: On / Off (should always stay on)
- Key Entry (5 tries left) (allows for dealer upgrades)
- Ballast Display: On / Off

Use the **UP/DOWN**  $\triangle \nabla$  arrows to scroll through the menu. Press the **SELECT** button to choose an item and follow the instructions on the display screen to adjust the settings. Push and hold the **ON/OFF/MENU** button to exit back to Home Screen.



## Team Dash Pod

### Keypad



CORC0325

### Keyless Ignition

The ignition switch system is keyless and has three modes of operation.



#### **CAUTION**

The keypad and switch control box will be damaged beyond repair if the boat's battery cables, the main switch control box power leads or battery charger leads are reversed. DO NOT reverse these connections.

### Locked Mode

When the boat's battery is first connected, the unit is in locked mode. In this mode, only the horn, bilge pump, bilge blower and code keys operate.



## Section 3

---

### Unlocked Mode

Unlocked mode is entered after the user successfully enters the user code, presses and releases the start key. When the code keys are pressed, the system indicator light will turn ON while the key is pressed. This indicates the key has actually been pressed. When the system is unlocked, power is supplied to the boat and the system indicator light will turn ON. At this point all keypad keys will operate and actuating these keys will control the corresponding boat functions. To put the unit back in Locked Mode, the user must successfully enter the user code, then press the STOP key. This will turn off the system indicator light and shut off power to all of the accessories except the horn, bilge pump, bilge blower and code keys.

### Run Mode

Enter the Unlocked Mode.

Pressing and releasing the START key quickly will put the unit in Run Mode. Power is supplied to the engine ignition, but the engine will not crank and the ignition indicator light is turned ON. If the start key is not pressed again within 15 minutes, the unit will exit Run Mode by shutting off power to the ignition and re-enter the Unlocked Mode. If the user presses the START key, power is supplied to the ignition and starter until the engine starts or for a maximum of 5 seconds if the engine does not start. All accessory keys will operate in this mode. Pressing the STOP key will shut off the engine and the unit is then put back in the Unlocked Mode.

After the engine starts, release the START key.

#### CAUTION

**DO NOT hold the START key for more than 30 seconds. The starter motor can be damaged.**



# Controls and Indicators

---

## Automatic Return to Locked Mode

If no keypad activity takes place for 10 hours after unlocking, the system will automatically return to the Locked Mode to help prevent battery drain.

## Automatic Back-lighting

Pressing any keypad key will automatically turn the keypad back-lighting on for 10 seconds. This feature is useful for finding the keypad at night.

## Multiple Keyless Ignition Codes

The keyless ignition system has provisions for three different ignition codes. Any of the three codes may be used to unlock or lock the system.

The “Master Embedded Code” is programmed into the system at Nautique Boat Company, Inc. It is not changeable and remains with the boat for its life. This code can be used to unlock the system, to lock the system and to erase the two user codes.

The “Primary User Code” is programmed into the system by the owner with the Nautique dealer’s help at the time of boat delivery. This code is used to unlock the system, to lock the system and to add or change the “Secondary User Code.”

The “Secondary User Code” is programmed into the system by the owner when necessary. This code is only used to unlock or lock the system. The “Secondary User Code” is ideal to limit access to the boat.

### NOTICE

*To help prevent battery drain, make sure you STOP the engine and LOCK the ignition system (two steps) when you are finished using the boat.*



### NOTICE

*The Power Indicator Light is on the left side of the START button on the keypad and the Accessories Indicator Light is on the right side.*

### Programming the Primary User Code

### NOTICE

*Until a Primary User Code is set, the keyless ignition does not require the entry of a code to unlock the system or start the engine. The system operates as follows:*

1. Press START to unlock the system.
2. Press it a second time to start the engine.
3. Press STOP to turn off the engine.
4. Press it a second time to lock the system. The system indicator light should be OFF.

To program the Primary User Code, make sure the system indicator light is off, then press and release the 1/2 key and the 7/8 key at the same time to put the system in the Code Programming Mode. The system indicator light will flash.

Enter a code from two to eight characters and press START. For verification, re-enter the code and press START again. The system indicator light should stop flashing and stay ON. If the light does not stop flashing, press STOP and begin again.

To lock the system, re-enter either the Primary User Code or the Master Embedded Code and press STOP.



# Controls and Indicators

---

## Changing the Primary User Code

### NOTICE

*The current primary code must be used to change to another primary code.*

Make sure the system indicator light is OFF.

1. Enter the Primary User Code, then press and release the 1/2 key and the 7/8 key at the same time to put the system in the code programming mode. The system indicator light will flash.
2. Enter a code from two to eight characters and press START. For verification, re-enter the code and press START again. The system indicator light should stop flashing and stay ON. If the light does not stop flashing, press STOP and begin again.

To lock the system, re-enter either the new Primary User Code or the Master Embedded Code and press STOP.

### NOTICE

*Changing the Primary User Code will erase the Secondary User Code.*

## Programming or Changing the Secondary User Code

### NOTICE

*The Secondary User Code will only lock or unlock the system and can not be used for any reprogramming*

Make sure the system indicator light is OFF.

1. Enter the Primary User Code, then press and release the 1/2 key and the 5/6 key at the same time to put the system in Code Programming Mode. The system indicator light will flash.
2. Enter a code from two to eight characters and press START. For verification, re-enter the code and press START again. The system indicator light should stop flashing and stay ON. If the light does not stop flashing, press STOP and begin again.



## Section 3

---

To lock the system, re-enter any of the three codes and press STOP.


### Erasing the User Codes

Make sure the system indicator light is OFF.

Enter the Master Embedded Code, then press and release the 1/2 key and the 7/8 key at the same time to erase the system user codes.

The keyless ignition will now act as if there are no codes in memory. Pressing the START key will unlock the system and pressing the STOP key will lock it without entering a code. Follow the steps in “Programming The Primary User Code” in this section.

### Switches



#### Navigation/Anchor Lights

A quick press and release of this button turns on the navigation lights, and the indicator light for this button will illuminate. A press and slight hold will only turn on the anchor light and cause the indicator light to flash. A press and release of the key turns off both of the lights.



#### Bilge Pump

The bilge pump turns on or off by pressing and releasing the button. The indicator light for this key will illuminate when the pump is on.





# Controls and Indicators

---



## Engine Compartment/Bilge Area Blower

The bilge area and engine compartment blower is turned on or off by pressing and releasing the button. The indicator light for this key will illuminate when the blower is on.



### **WARNING**

**Explosion and fire hazard from gasoline vapors can cause death or serious injury from failure to check for fumes in the engine compartment or operating the blower. Before engine start-up, check engine compartment for gasoline vapors, then operate blower for at least four minutes. Operate blower whenever below planing speed.**



## Horn

The horn button is a momentary switch. The horn will operate whenever the button is pressed and will stop when the button is released.



## Section 3

---

### Nautique LINC 2.0



#### Product Information

The Nautique LINC 2.0 display is designed for instrumentation and control on electronically controlled engines communicating via SAE J1939 and NMEA 2000. The display is a multifunctional tool that provides GPS tracking, multimedia display, speed control, and enables equipment operators to view many different engine parameters and service codes.

#### Care and Maintenance

General maintenance is not required; however, a soft cloth can be used for cleaning the unit. Window cleaner or alcohol can also be used to clean the glass portion of the display. Do not use harsh or abrasive cleaners on the unit.



## Basic Navigation Features

All product features are easily accessed through Quick Access Keys, Menus, and Soft Key commands.



## Quick Access Keys

The keys located to the left of the display provide one-button access to Home, Map, Media, Switching, 3 Event, User Profiles and Preferences.

### **MENU Key**

Pressing this key displays the Preferences screen and allows access to System Settings.

### **Soft Key Commands**

Soft key commands provide additional features and navigation shortcuts. Depending upon the current screen being displayed, they may appear as an icon or text.

*NOTE: The sliding effect of the soft key commands can be toggled on/off. Go to the **Preferences** screen and select **Button Slide On/Off**.*

### **Soft Keys**

The soft keys correspond to the Soft Key Commands and activate features accordingly when pressed.




## Section 3


### Quick Access Key Features

This section describes the features accessed through the Quick Access Keys located to the left of the display.

#### Home Display

The Home Display screen for viewing engine statistics can be accessed by pressing the Quick Access Key .



Pressing  or any other key launches the Soft Key Commands to overlay the right side of the display.










*NOTE: The sliding effect of the soft key commands can be toggled on/off. Go to the **Preferences** screen and select **Button Slide Off**.*





# Controls and Indicators

## Home Display – Soft Key Commands

Soft Key	Description
	<b>VOLUME UP</b> – press this soft key to increase the volume of the stereo.
	<b>VOLUME DOWN</b> – press this soft key to decrease the volume of the stereo.
	<b>SPEED CONTROL</b> – selecting SPEED CONTROL from the Home Display screen engages the cruise control.
	<b>SPEED UP</b> – increase the target speed.
	<b>SPEED DOWN</b> – decrease the target speed.
	<b>CHANGE VIEW</b> – changes the view in the middle panel of the display while staying on the home page. Press this soft key to toggle between available views. (See complete description on following page.)
	<b>USERS</b> – allows the selection of a user profile to display via the soft keys.




# Section 3

Soft Key	Description
	<p>The <b>Change View</b> soft key toggles through the different views available on the home screen. They are:</p> <ul style="list-style-type: none"><li>• Engine Statistics</li><li>• Engine Hours and Air and Water Temperatures</li><li>• Map view</li><li>• 3 Event view</li><li>• Video view</li></ul> <div data-bbox="267 459 944 797"></div>









# Controls and Indicators

## Map Display

The Map Display screen can be accessed by pressing the  key. The Map feature displays map data, latitude and longitude coordinates, depth and speed.







Soft Key	Description
	<b>UP</b> – facilitates navigating the map by moving the cross-hairs accordingly.
	<b>DOWN</b> – facilitates navigating the map by moving the cross-hairs accordingly.
	<b>LEFT</b> – facilitates navigating the map by moving the cross-hairs accordingly.
	<b>RIGHT</b> – facilitates navigating the map by moving the cross-hairs accordingly.
	<b>ZOOM IN</b> – this soft key zooms in for more detailed view of the area map.
	<b>ZOOM OUT</b> – this soft key zooms out for a larger view of the area map.



# Section 3








Soft Key	Description
	<b>CENTER</b> – returns the crosshairs to the center of the cursor.
	<b>WAYPOINTS</b> – displays a list of waypoints.
	<b>CREATE WAYPOINT</b> – displays a keyboard. Enter a name for the waypoint. The waypoint will be set where the cursor has been placed. You can edit the waypoint in Map Utilities. <div data-bbox="266 933 710 1203"></div> <p><b>LEFT – RIGHT – UP – DOWN ARROWS</b> – navigate the keyboard.</p> <p><b>SELECT</b> – places the selected letter in the space at the top of the keyboard or performs the function selected.</p> <p><b>SAVE</b> – saves the waypoint and the name.</p> <p><b>CANCEL</b> – removes the keyboard without saving the waypoint or the name.</p>





# Controls and Indicators

Soft Key	Description
	<b>CLEAR TRACK</b> – clears the currently displayed track.
	<p><b>SAVE TRACK</b> – displays a keyboard. Enter a track name. The Track can be edited in Map Utilities.</p>  <p><b>LEFT – RIGHT – UP – DOWN ARROWS</b> – navigate the keyboard.</p> <p><b>SELECT</b> – places the selected letter in the space at the top of the keyboard or performs the function selected.</p> <p><b>SAVE</b> – saves the track and the name.</p> <p><b>CANCEL</b> – removes the keyboard without saving the track or the name.</p>
	<b>BUTTON SLIDE ON/OFF</b> – allows or prevents the soft keys from sliding off the screen. The default is <b>Button Slide On</b> .
	<b>ZOOM PAN</b> – returns to the top level map and displays the <b>ZOOM IN/ZOOM OUT</b> and directional soft keys.



# Section 3

## Media Display

The Media Display can be accessed by pressing the Quick Access Key



This feature provides universal control to the Polk stereo mimicking all the controls of a standard remote control. Nautiques with the LINC displays will support the following multi-media functions:

- Audio in
- USB Input
- AM-FM Tuner
- Satellite
- Bluetooth








To access any one of these functions, press the **MODE** soft key once. Each press will scroll to the next source. If you press and hold the Mode soft key it will power on or off the stereo.

### Media Display – Soft Key Commands


Soft Key	Description
	<b>VOLUME UP</b> – increases the volume.
	<b>VOLUME DOWN</b> – decreases the volume.



# Controls and Indicators

Soft Key	Description
	<b>PREV TRACK</b> – plays the previous track of the current input and other functions depending upon the input mode.
	<b>NEXT TRACK</b> – plays the next track of the current input and other functions depending upon the input mode.
	<b>PAUSE/MUTE</b> – will pause or mute the current music depending upon the input mode.
	<b>MODE</b> – brings up a menu to select the audio source, including AM/FM Radio, Auxiliary Input, Satellite Radio, USB, Weather Band and Bluetooth.
	<b>Settings</b> – brings up the Settings menu.

## Media Settings Menu









The Media Settings menu can be accessed by pressing the  soft key from the Media Display.



## Section 3

---


### *Media Settings Menu – Soft Key Commands*

Soft Key	Description
	<b>AUDIO SETUP</b> – brings up a menu to adjust the balance, fade, bass, treble and equalizer preset. The “loudness” setting can be turned on or off here as well.
	<b>AUTO VOLUME UP</b> – increases the degree of change in volume based on boat speed.
	<b>AUTO VOLUME DOWN</b> – decreases the degree of change in volume based on boat speed.
	<b>BT MENU OR PLAYLIST</b> – depending upon the selected mode, this will either be the Bluetooth Menu button that brings up a menu for pairing and connecting Bluetooth devices OR it will be a Playlist button that brings up the playlist settings for USB-connected devices.
	<b>REPEAT</b> – repeats the current track.
	<b>RANDOM</b> – randomizes the selection of the next track.
	<b>AUDIO</b> – brings up the main audio menu.
	<b>VIDEO</b> – switches unit to video mode.






# Controls and Indicators

## Bluetooth Menu

The Bluetooth menu can be accessed by pressing the  soft key from the Media Settings menu.



### Bluetooth Menu – Soft Key Commands

Soft Key	Description
	<b>PAIR</b> – searches for nearby Bluetooth devices to pair with. Please ensure that the Bluetooth device you are trying to connect with is in “discoverable mode” before pressing pair.
	<b>CONNECT/DISCONNECT</b> – connects or disconnects the currently paired Bluetooth device. Once connected, music from the Bluetooth device can be played through LINC.
	<b>EXIT</b> – returns the user to the settings menu.



## Section 3




### User Profiles

The User Profile screen can be accessed by pressing the Quick Access Key. This feature displays rider/skier profiles containing speed and 3 Event settings. The unit comes preloaded with default user profiles and the ability to create additional users.








# Controls and Indicators

## User Profile Screen - Soft Key Commands

Soft Key	Description
	<b>EVENT MODE</b> – default user that contains settings and features for 3 Event. Please refer to the 3 Event owner's manual.
	<p><b>EDIT USER</b> – provides utilities for adding new users, editing existing users.</p>  <p><b>Soft Key Commands for Edit Profile Include:</b></p> <p><b>EDIT NAME</b> – allows the user profile name to be changed.</p> <p><b>NEXT SETTING</b> – navigates to the next field.</p> <p><b>UP – DOWN</b> – toggles through the settings within the field.</p> <p><b>CANCEL</b> – cancels any setting changes that have been made on the screen.</p> <p><b>SAVE</b> – saves the changes that have been made on the screen.</p> <p><b>EDIT ICONS</b> – brings up soft key command to change user icon type and color.</p>



# Section 3



Soft Key	Description
	<div></div> <p>Press the <b>LEFT</b>, <b>RIGHT</b>, <b>UP</b> or <b>DOWN</b> arrow soft keys to navigate the keyboard. Select <b>BACK</b> at the top of the keyboard to remove unwanted letters. Select <b>MORE CHARACTERS</b> to toggle capital/lowercase letters and numbers. Select <b>SPACE</b> to add a space between characters. Press the <b>SAVE</b> soft key when finished entering the name.</p>
	<div><p>Press the <b>NEXT SETTING</b> soft key to navigate the settings.</p></div> <p>Press the <b>UP</b> or <b>DOWN</b> arrow key to find the appropriate setting option. Press the <b>CANCEL</b> soft key to return to original settings. Press the <b>SAVE</b> soft key to save the modifications.</p>
	<p>Use the <b>EDIT ICON</b> soft key to select icon and color.</p>





# Controls and Indicators

## New User Profile

Soft Key	Description
	 <p>Press the <b>LEFT</b>, <b>RIGHT</b>, <b>UP</b> or <b>DOWN</b> arrow soft keys to navigate the keyboard. Select <b>BACK</b> at the top of the keyboard to remove unwanted letters. Select <b>MORE CHARACTERS</b> to toggle capital/lowercase letters and numbers. Select <b>SPACE</b> to add a space between characters. Press the <b>SAVE</b> soft key when finished entering the name.</p> <p>To change the default settings, press the <b>EDIT USER</b> soft key to change the default settings (see Edit User Profile for more details on how to edit a profile). Use the <b>BACK</b> soft key in the lower left corner to return to the previous screen.</p>







## Section 3

### Switching

The switching button is used to control the lighting. The lights that are displayed and controlled with the device are dependent upon the boat model and dealer settings. The soft keys on the right of the display navigate the screen.




In addition to controlling the lights on the boat, the other appliances that are not directly controlled by the display are shown. For example, the blower, navigation lights and bilge levels are displayed.



Soft Key	Description
	<b>LINC BRIGHTNESS</b> – adjusts the brightness of the LINC display. Press to dim and brighten the display. The brightness levels are displayed in increments of 10.
	<b>COURTESY LIGHTS</b> – turns on or off the courtesy lights.
	<b>OVERHEAD LIGHTS</b> – (if equipped) turns on or off tower lights.
	<b>DOCKING LIGHTS</b> – turns on or off the docking lights. Only shown if boat model comes equipped with them and selected under Dealer Settings.




# Controls and Indicators

Soft Key	Description
	<b>UNDERWATER LIGHTS</b> – (if equipped) turns on or off the underwater lights.
	<b>HEATER</b> – turns on or off the boat heater.
	<b>FEATURES</b> – displays the locations of key features on the boat. Press to toggle the highlighted feature. The features shown include: <ul style="list-style-type: none"><li>• T-Handle Drain</li><li>• Bilge</li><li>• 12 V ports</li><li>• AUX input</li><li>• USB input</li><li>• Battery</li></ul>



## Section 3

### Zero Off 3 Event


The Zero Off 3 Event screen can be accessed by pressing the  Quick Access key. This feature allows the operator to adjust intricate GPS speed settings related to competition-level slalom, jump and trick skiing.

**\*Please see the separate Zero Off 3 Event owner's manual for detailed instructions on how to properly operate Zero Off 3 Event on your LINC display.**



# Controls and Indicators








## Preferences

The Preferences screen is displayed when  is pressed briefly. The following preferences can be set on this screen; use Next Setting to scroll to additional settings:

- Home Button Slide (turn on or off)
- Map Button Slide (turn on or off)
- Units (English or Metric)
- Brightness (in increments of 10)
- Auto Volume (Levels 1-5)
- Buzzer Volume
- Depth Buzzer
- Time Zone (GMT offset 1 to -12)
- Daylight Savings Time (on or off)
- Clock Mode (12hr or 24hr)





## Section 3

Soft Key	Description
	<b>SYSTEM SETTINGS</b>  <p>(See <b>Main Menu</b> section for more information.)</p>
	<b>PREV SETTING</b> – backs up to the previous setting.
	<b>NEXT SETTING</b> – advances to the next setting.
	<b>UP</b> – toggles through the available settings.
	<b>DOWN</b> – toggles through the available settings.
	<b>SAVE</b> – saves changes and returns to the initial page.



# Controls and Indicators

Soft Key	Description
	<p><b>RESET ALL</b> – displays the reset all system settings warning.</p>  <p><b>YES</b> – resets all the preferences to the default settings (excluding any user profiles).</p> <p><b>NO</b> – cancels the reset action and returns to the <b>Preferences</b> screen.</p>



## Section 3

### Nautique LINC 2.0 – River Mode

#### Ski 200

LINC's River Mode is a feature that allows the driver to keep the boat's speed-over-water constant at the push of a button when a current is present. To compensate for the current, the boat's speed-over-ground or "GPS speed" must be adjusted up or down, depending on the direction of the boat relative to the current.

Please follow the steps listed on the following pages to learn how to turn on, operate and adjust River Mode from the Home screen and from 3 Event.

*NOTE: River Mode **CANNOT** be turned on if a Slalom or Jump event type is currently activated. The Slalom and Jump events require true GPS speed control, unaffected by River Mode, to function accurately and to provide correct timing results to the driver.*

From any screen, locate and press the USER key.



LINC Home Screen with River Mode off

CORC534





## Controls and Indicators


Once on the User screen, select either the Trick or Wake users and press “set as current” to activate that user. Please be aware of the set speed for that particular user before pressing “set as current”.



LINC User Screen

CORC535

Once returned to the Home screen, press the seventh button down from the right (will be labeled “users”).



LINC Home Screen with Wake user activated and River Mode off

CORC536



## Section 3


Press “river mode” to toggle River Mode on.



LINC Home Screen with Wake user activated and River Mode on

CORC537


Press “main” to return the first menu of soft keys to control the set speed and offset for River Mode.



LINC Home Screen with Wake user activated and River Mode on

CORC538

# Controls and Indicators





LINC Home Screen with River Mode on



Offset should be adjusted as described below to equal the estimated current speed

River Upstream/Downstream indicator  
(Depicted as downstream in the illustration)

Set speed equals the desired "water speed" and is adjusted using speed up or down soft keys

Soft Key	Description
	<p><b>OFFSET UP and OFFSET DOWN</b> – adjust the offset up or down to equal the estimated current speed.</p> <p><b>UP</b> – increases the offset.</p> <p><b>DOWN</b> – decreases the offset.</p>
	<p><b>RIVER MODE UPSTREAM/DOWNSTREAM</b> – should be pressed when driver is changing directions from upstream to downstream or vice versa. If the boat is moving upriver, this function adds the offset to the GPS speed (or speed-over-ground) to display the estimated speed-over-water, or subtracts it, if the boat is moving downriver.</p>



## Section 3

### Sport 200

LINC's River Mode is a feature that allows the driver to keep the boat's speed-over-water constant at the push of a button when a current is present. To compensate for the current, the boat's speed-over-ground or "GPS speed" must be adjusted up or down, depending on the direction of the boat relative to the current.

Please follow the steps listed on the following pages to learn how to turn on, operate and adjust River Mode from the Home screen and from 3 Event.

From the Home screen, press the seventh button down from the right (will be labeled either "users" or "SURF" depending upon the set speed).



LINC Home Screen with River Mode off

CORC0560



# Controls and Indicators

Press “river mode” to toggle River Mode on.



LINC Home Screen with River Mode off

CORC0561

Press “main” to return the first menu of soft keys to control the set speed and offset for River Mode.





LINC Home Screen with River Mode on

CORC0562



# Section 3



Soft Key	Description
	<b>OFFSET UP and OFFSET DOWN</b> – adjust the offset up or down to equal the estimated current speed. <b>UP</b> – increases the offset. <b>DOWN</b> – decreases the offset.
	<b>RIVER MODE UPSTREAM/DOWNSTREAM</b> – should be pressed when driver is changing directions from upstream to downstream or vice versa. If the boat is moving upriver, this function adds the offset to the GPS speed (or speed-over-ground) to display the estimated speed-over-water, or subtracts it, if the boat is moving downriver.



# **Controls and Indicators**

---

## **Operating and Adjusting River Mode Settings**

First, ensure that River Mode is turned on and navigate to the Home screen or 3-Event screen.

Determine whether the boat will be traveling upstream or downstream and switch River Mode Upstream/Downstream on LINC accordingly.

Estimate the current speed and adjust the offset up or down accordingly.

When changing direction while driving (e.g., going from driving upstream to driving downstream, or vice versa) be sure to press the River Mode Upstream/Downstream on LINC.





# Section 3

## Nautique LINC 2.0 – River Mode in Integrated Zero Off 3 Event

On any screen, press the 3 EVENT key.



LINC Home Screen

CORC542

Once on the 3 Event screen, press the CHANGE EVENT button.



LINC 3-Event Screen

CORC543





# Controls and Indicators

Press the TOURN TRICK button to select a tournament-approved Trick Skiing event type.



LINC 3-Event Screen

CORC544

Once on the 3-Event screen with the “Tourn Trick” event type activated, press the RIVER MODE button.



LINC 3-Event Screen

CORC545



## Section 3

The following screen shows River Mode in integrated Zero Off 3 Event for Trick Skiing. Please note that the button layout is slightly different than River Mode on the Home screen.



LINC 3-Event Screen, in River Mode

CORC546

The following screen shows River Mode at the desired set speed in integrated Zero Off 3 Event. Please refer to the previous section for a detailed description of River Mode interface and operation.



LINC 3-Event Screen, in River Mode

CORC547



## MENU Options



The menu options are accessible by pressing the **SYSTEM SETTINGS** button on the **PREFERENCES** screen. The following features are available:






- **GPS Utilities** – contains options to set up track and position, chart and time, and waypoint manager. Also displays satellite status.
- **Engine Diagnostics** – displays a list of engine fault codes and descriptions; on some engines, corrective action will be shown.
- **System Information** – allows you to customize the display options for ambient light and brightness, set US or metric units, specify the Home screen and screen setup status.
- **Dealer Settings** – allows the dealer to select specific settings for a boat model. This area is protected and a dealer must enter a dealer code to proceed.



# Section 3




## Waypoint Manager



Soft Key	Description
   	<div></div> <p><b>LEFT – RIGHT – UP – DOWN</b> soft keys are used to navigate the different areas in the Waypoint Manager.</p> <p><b>WAYPOINTS</b> – provides a list of waypoints that have been set using the tracking soft keys on the GPS Navigator screens. Use the up and down arrows to select a waypoint to edit the name, select an icon, Delete or Go To on the GPS Map.</p> <p><b>EDIT WAYPOINT NAME</b> – provides a keyboard to use to edit the waypoint name.</p> <p><b>WAYPOINT ICON</b> – provides a list of icons available to use to indicate waypoints on maps. The choices are:</p> <ul style="list-style-type: none"><li>• Flag</li><li>• Fish</li><li>• Anchor</li><li>• Marina</li></ul> <p><b>DELETE/DELETE ALL</b> – deletes either the current waypoint or will delete all in the list.</p>



# Controls and Indicators

Soft Key	Description
	<p><b>GO TO...</b> – takes you to the selected waypoint on the GPS map.</p> <p><b>Waypoint Manager – Go to Waypoint</b></p>  <p><b>YES</b> – Go to waypoint on the GPS Navigator Maps.</p> <p><b>NO</b> – Do not go to the waypoint on the GPS Navigator Maps.</p>



## Track Manager

Soft Key	Description
	<p><b>Track Manager</b></p>  <p><b>LEFT – RIGHT – UP – DOWN ARROW</b> soft keys are used to navigate the different areas in the Track Manager.</p> <p><b>TRACKS</b> – List of current tracks available to edit.</p> <p><b>EDIT TRACK NAME</b> – select to edit the track name using a keyboard.</p> <p><b>TRACK ENABLED</b> – select to show or hide the track.</p> <p><b>DELETE/DELETE ALL</b> – Allows the user to delete selected track or all tracks in the list.</p> <p><b>BACK TO GPS UTILITIES</b> – select to go back to the GPS Utilities screen.</p>



# Section 3



## Chart and Time Setup

Soft Key	Description
	<div></div> <p><b>LEFT – RIGHT – UP – DOWN ARROW</b> soft keys are used to navigate the different areas in the Chart and Time Setup.</p> <p><b>CHART SETUP PARAMETERS</b> – turn on or off available settings:</p> <ul style="list-style-type: none"><li>• Show Grids</li><li>• Show Text</li><li>• Show Waypoints</li><li>• Show Tracks</li><li>• Show Navigation Aids</li><li>• Show Waypoint Names</li></ul> <p><b>TIME SETUP PARAMETERS</b> – turn on or off the available settings:</p> <ul style="list-style-type: none"><li>• GMT Offset</li><li>• DST Enabled</li><li>• 12 Hr Format</li><li>• 24 Hr Format</li></ul> <p><b>BACK TO GPS UTILITIES</b> – select to return to the GPS Utilities screen.</p>



# Controls and Indicators


## Depth and Position Settings

Soft Key	Description
	 <p><b>LEFT – RIGHT – UP – DOWN ARROW</b> soft keys are used to navigate the different areas in the Depth and Position Settings.</p> <p><b>POSITION FORMAT SELECTION</b> – select the position from available settings:</p> <ul style="list-style-type: none"> <li>• Degrees and Decimal Degrees</li> <li>• Degrees, Minutes and Decimal Minutes</li> <li>• Degrees, Minutes, Seconds and Decimal Seconds</li> </ul> <p><b>DEPTH CONTOUR</b> – select depth contour from available settings:</p> <ul style="list-style-type: none"> <li>• All</li> <li>• 66ft</li> <li>• 33ft</li> <li>• 16ft</li> <li>• 6ft</li> <li>• Off</li> </ul> <p><b>SAFELY CONTOUR</b> – select contour from available settings:</p> <ul style="list-style-type: none"> <li>• 66ft</li> <li>• 33ft</li> <li>• 16ft</li> <li>• 6ft</li> <li>• Off</li> </ul> <p><b>BACK TO GPS UTILITIES</b> – select to return to the GPS Utilities screen.</p>



# Section 3

## Satellite Status

Soft Key	Description
	<p>This view only screen gathers data on prevailing satellites and shows the proximity of each. It also displays the following information:</p> <ul style="list-style-type: none"><li>• Longitude</li><li>• Latitude</li><li>• Number of Satellites</li><li>• Strength</li></ul> <p><b>BACK TO GPS UTILITIES</b> – select to go back to the GPS Utilities screen.</p>







# Controls and Indicators

## Engine Diagnostics



The following is a list of field definitions contained on the ENGINE DIAGNOSTICS screen:

- **Diagnostic Message** – displays the diagnostic message.
- **Description** – Most common SPNs and FMIs have text for the description stored in the display. If there is no text, then this SPN and FMI must be defined by referring to the engine manufacturer, or the SAE J1939 standard.
- **Corrective Action** – suggested action for correction.
- **SOURCE** – what the source of the message is.
- **SPN** – “Suspect Parameter Number” - fault code.  
If not translated into text by the display, see the engine manufacturer’s literature for the definition of the SPN number.
- **FMI** – “Failure Mode Indicator” - fault code. The FMI is defined by SAE J1939. If not translated into text, see the SAE standard, or the engine manufacturer’s literature.
- **Count** – The number of times the event has been flagged.

Soft Key	Description
	<b>LEFT/RIGHT ARROWS</b> – navigate through the fault list.
	<b>GET FAULTS</b> – query the engine(s) ECU for feedback on diagnostic codes that have been activated and stored in the ECU for service needs.



# Section 3

## System Information



Component	Version	Part No.
Application	The version number of the application installed on the hardware.	The part number for the application.
OS	The version number of the operating system installed on the hardware.	The part number for the operating system.
Bootloader	The version number for the bootloader.	The part number for the bootloader.



## **LINC 2.0 General Troubleshooting Guide**

### **Display appears not to work or doesn't come "ON."**

1. Display could be in *sleep* mode. Touch a key on the keypad to activate the display.
2. Check for loose connections at battery and display unit.
3. Check for reversed polarity on the power connections.
4. Verify battery has a minimum voltage of 6 Volts.

### **Display resets or goes "OFF" when starting engine.**

1. Check display supply wires are connected properly to battery.
2. Verify battery is charged properly.
3. Check battery for efficient starter current.

### **Display has no backlight.**

Contact your Nautique service center.

### **Display has no keypad backlight.**

Contact your Nautique service center.



### Standard Equipment

#### Watersports Tow Point

The watersports tow-point (pylon) is manufactured from high strength aluminum alloy, engineered for durability. It is “hard coat anodized” and impregnated with a PTFE (teflon) material. If the pylon becomes loose, stop using the pylon and take the boat to your Nautique dealer for service.



#### **WARNING**

Misuse of the tow-point can cause death or serious injury. The pylon was designed for water skiing only. **DO NOT** use for parasailing, kite flying, towing other boats and/or using pylon extensions, sit behind (aft) the pylon when towing skiers.



#### **CAUTION**

Although pylon extensions and barefoot booms have become popular additions to many tournament inboards, Nautique Boat Company strongly objects and opposes the use of any pylon extension, whether up or to the side of any of its products. The use of pylon extensions can alter the handling characteristics of the boat, possibly resulting in dangerous instability, which could then lead to loss of control, a situation which could cause serious or fatal injury to the boat driver, passengers, skiers and anyone else who might be in the vicinity of such a mishap.




## Tow Rope Attachment – Center Mounted Pylon


### **SAFETY INSTRUCTIONS**

*Nautique recommends the following technique for attaching your tow rope to the tow pylon.*

1. Locate the portion of rope where the increments are looped through one another at the skier's desired length.
2. Loosen up the aft loop (closest to the skier, shown in orange).
3. Slide only the loosened loop onto the pylon or tower.
4. Tighten by pulling the tails of both the gray and orange sections of rope.



CORC0648



CORC0649



CORC0650



CORC0651




## Section 3

### Tow Rope Attachment – Tower Pylon

#### **SAFETY INSTRUCTIONS**


*Nautique recommends the following technique for attaching your tow rope to the tow pylon.*

1. Locate the end of the wakeboard rope.



CORC0652

2. Pass a small section of the rope through the loop at the end as shown, creating another loop.



CORC0653

3. Slide the new loop onto the pylon or tower.



CORC0654

4. Tighten by pulling on the tail of the rope that leads to the skier.



CORC0655



## **CAUTION**

Nautique Boat Company **DOES NOT** approve of any structural changes, additions or modifications to our products. Any time a dealer or consumer makes a change to our product, they do so at their own risk and sole liability. Nautique Boat Company, Inc. will not be held liable for unauthorized changes, whether deletions or additions, to the original equipment/product manufactured and sold by Nautique Boat Company, Inc., even if such changes and additions are made by an “authorized” Nautique dealer, customer, promotional representative or any other person, known or unknown to Nautique Boat Company, Inc.

### **Bow Features - Open Bow Only**

The open bow section of your boat has removable cushions. The center section may be equipped with an optional filler cushion which can be removed and stored in the trunk or under the observer's seat. Storage can be accessed by removing the other cushions.



## Section 3

---


### Driver's Seat Adjustment

The lever under the driver's seat on the left side allows the seat to slide fore and aft.



#### **WARNING**

A seat or seats which are not locked in position can cause death or serious injury. Lock the seat(s) in position (fore and aft) before operating the boat.



CORC069







## Rearview Mirror Adjustment

The rearview mirror can be positioned on the windshield to observe a skier and traffic behind you. The mirror should be lowered when trailering or when using a mooring cover. To reposition the mirror bracket on the windshield frame, loosen the three socket head screws and reposition and tighten the screws in the new location. The center screw (**A**) should be tightened two turns, followed by the two outside screws (**B**) being tightened two turns. Follow this sequence until all three screws are tight.

The mirror is installed onto the bracket with a friction clamp (**C**) to allow mirror adjustment. The friction is controlled by tightening or loosening the friction clamp bolt and manually positioning the mirror to the desired view.



FRICTION CLAMP



SOCKET HEAD SCREWS




## Section 3

---

### Observer's Seat

Lift up on the bottom of the observer's seat cushion to access storage under the bow area. The seat cushion and seat leanback will hinge upward together.




CORC0278




## 200 Engine Box Cover/Lifting/Removal

The engine box cover is designed as a two-piece clam shell part. Lift up slightly on the latch located in the front of the box and open fully until it rests onto the stern seat. Access to the routine service items is now available. You can leave the top open to dry out the bilge.



To remove the entire box, locate the three black wing nuts mounted to the inside bottom half of the motor box. Turn the wing nuts counterclockwise until they are fully removed. Remove the flat washers from the threaded post. The engine box can now be lifted out of the boat.




## Section 3

### NOTICE

*The engine box is designed to cover the engine adequately while providing maximum cockpit floor space. After removing the black wing nuts and flat washers, employ the help of a second person to safely maneuver the box up over the engine and out of the boat.*

### Walk-Thru Windshield Opening/Latching

There are two latches on the inside starboard side of the walk-thru windshield. Rotate both of the window locks (A) to secure or unlock the window. Always have window closed and secured when trailering the boat.



### WARNING

An open window can cause death or serious injury. Make sure both window locks are secure when vessel is in motion.

### Dash Storage


The dash storage is for dry storage only. It is equipped with a drain in the event of water intrusion.



## Boarding Platform


The boarding platform of your boat is a convenient feature to enhance the watersports experience. There are serious safety concerns regarding the use of the platform. Nautique Boat Company, Inc. has placed warning labels at the driver's position, on the deck at the rear of the occupant area and on the transom. Refer to Section 1, Boating Safety, for more information.

To remove the boarding platform, pull the pins (A) located in the mounting brackets, under the platform, and lift the platform vertically.



## Section 3

The optional Nautique folding platform brackets allow you to fold the platform down 90 degrees for improved storage. To fold the platform, pull the lower pins, pull the platform slightly aft and lower. The platform can also be removed by pulling all four pins (A).



CORC0322



### WARNING

A spinning propeller or carbon monoxide can cause death or serious injury. **DO NOT** use the boarding platform when the engine is running or for any other purpose than boarding the boat or preparation for entering the water.

The boarding platform must be attached when the boat is in use.



### CAUTION

The maximum load on the boarding platform is 500 lbs (227 kg).




## Engine Cooling Water Intake Valve

Your Nautique is equipped with a valve (seacock) on the engine cooling water intake. The handle is red and has a slide mechanism to prevent the valve from being shut off inadvertently. The valve is used to shut off the water supply in the event a hose failure or water leakage occurs. The valve is open when the red handle is in-line with the valve body, and the valve is closed when the handle is perpendicular to the valve body. Leave the valve open at all times unless an emergency condition requires you to close the valve to stop a leak or the possibility of a leak.

### 200-OB, 200-CB


The valve is located on the starboard side of the transmission.



### 200-V

The valve is located fore of the engine compartment.

If your boat is equipped with a ballast system, the engine cooling valve (A) will be the larger valve with a red locking handle. The valve can be accessed through openings under the aft cockpit seat.



## **Section 3**

---

### **Battery Disconnect Switch**

The battery disconnect switch allows you to isolate all power to the boat. This switch provides positive disconnect of the battery to protect against tampering, electrical fire hazards and battery rundown. Rotate the switch to the OFF position when the boat is not in use.

### **Nautique Electrical System**

To ensure proper electrical system boot up when using the battery switch, please wait at least 30 seconds after turning the switch on before entering the user code and starting the boat. Failure to do this can disrupt the Accessory circuit causing the LINC display, Stereo, Zero Off, and various electrical components not to turn on. If the operator accidentally disrupts the Accessory circuit, press and hold "Stop" for 2 seconds; then restart the system to regain functionality of the Accessory circuit and the components dependent upon it.

### **Rudder Remote Lube**

The service allows for easy access to lubricating the rudder. The remote lube fitting is located under the aft removable floorboard in the Ski 200 and in the engine compartment in the Sport 200. Use a quality marine grease and gun. Connect the grease gun to the fitting and apply a light pressure to the gun until slight resistance is felt.





## Fuel Tank

There is a fuel fill cap on the center of the transom on the Ski 200 and one on each gunnel near the aft of the boat for the Sport 200 for your convenience. Press and release the black button on the bottom of the cap to open. Use caution when fueling your boat.

Avoid overfilling of the tank by monitoring the fuel level gauge while fueling. Turn on the ignition without starting the engine and monitor the gauge. Stop fueling as the gauge approaches the 'full' level and turn off the ignition when finished. Fuel spillage on our waterways will pollute our environment.

There is a fuel tank located under the deck behind the stern seat. To inspect the hose connections, remove the stern seat leanback. Your Nautique dealer should perform all fuel tank service.



### **WARNING**

**Explosion or fire can occur under certain conditions, causing death or serious injury:**

- Turn the engine OFF.
- DO NOT smoke or allow open flame or sparks within 50 feet (15 meters) of the refueling area.
- DO NOT refuel unattended, avoid contact and spilling.
- DO NOT refuel indoors.
- DO NOT use a plastic funnel.
- DO NOT allow any spilled fuel to remain on your boat's finish.
- DO NOT allow a fuel system problem to go unchecked.
- Always maintain contact with the fuel nozzle and the fuel tank to prevent electrostatic spark.



## Section 3

### Optional Equipment

#### Folding Instructions for Flight Control Tower®



#### **WARNING**

**Crush hazard. The Flight Control Tower is heavy. Use care to fold or unfold the tower.**


#### **Flight Control Tower®**

Remove all boards from the board racks prior to folding the tower. Make sure to support the tower before unlocking the tower lock handles.

**To Lower:** Support the tower. Push the lock handles (A) down and rotate fully, until they stop. Gently lower the tower ensuring it does not make contact with anybody or part of the boat.

**To Raise:** Make sure the handles are in the fully open position before raising the tower. Slowly raise the tower into position making sure nothing interferes with a smooth seating.

With the tower in the fully upright position, turn the lock handles (A) upward until they stop. The handles will be horizontal when locked properly.




CORC0222



## **Controls and Indicators**

Nautique towers are pre-wired so audio speakers can be added to the tower. The plugs have a “fish line” to retrieve speaker wires through the towers.



CORC0235




## Section 3

---

### Bimini Top

Your Nautique may be equipped with a bimini top which can be used for securing lighter watersports equipment. The top can be tilted by removing the aft pins (A) and allowing the top to tilt, to load the equipment. Make sure the equipment is secured before getting underway. **DO NOT** exceed 90 lbs. (40.8 kg) or trailer with equipment on top.



COR0237

## **Battery Charger**

Nautique offers battery charging systems for single- and dual-battery applications. The exact battery charger model required for your boat will depend on the number of batteries your boat is equipped with and the specific electrical requirements from the country in which your boat will be operating. Because of the wide variance in electrical plug configurations used in each country, all boats built for use outside the United States will require your Nautique dealer to install the proper electrical plug on the battery charger AC supply cord. Your Skippers Kit will contain a manual from the battery charger manufacturer that explains the proper wiring requirements for each system as well as instructions for safe operation of the charger.

## **Optional Accessories**

### **Stereo Systems**

All Nautique boats have been built stereo ready with power wires for head unit and cockpit speakers. Tower speakers can be purchased as an option. Digital remote controls can be mounted on the transoms of all boats and on the lower left side of the dash pod in boats that do not have Nautique LINC Systems. The digital remote control displays all necessary control functions at your fingertip. See your Nautique dealer for the stereo configuration for your boat.

The audio speakers of your Nautique boat are designed to deliver maximum fidelity in a marine environment. The speakers can be damaged if struck by a sharp object or if the moving elements are restricted from movement. Do not store or place any sharp objects near the speakers, or restrict element movement.




## Section 3


---

Optional accessories are available from your Nautique dealer. Your dealer may have a wide range of other accessories available to enhance your watersports or pleasure boating experience. Contact your Nautique dealer for more information. Here are just two of the fine accessories Nautique offers:

- Pull-out Cleats



- Phender Socket





## Section 4

# Boat Systems

Knowing the systems, controls and indicators on your boat is essential for safe and proper operation.



### **WARNING**

**Systems which are not inspected regularly or maintained can cause death, serious injury or damage to product. Inspect and maintain all systems to prevent unexpected hazards associated with worn or faulty components.**

When replacement parts are required, use marine grade parts with equivalent characteristics, including type, strength and material.

Marine grade parts are designed specifically for the conditions and environment they are exposed to. Using substandard parts could result in injury and product failure.

## Fuel System


The fuel system consists of a built-in fuel tank, a fuel fill and a fuel tank vent.

The fuel tank is located under the deck behind the stern seat in the Ski 200 and under the removable cockpit floorboard in the Sport 200. To inspect the hose connections, remove the stern seat leanback. Your Nautique dealer should perform all fuel tank service.

# Section 4

---

200-OB, 200-CB




CORC0599





## 200-V



CORC0473



## Section 4

---

### Ballast Tanks and Bilge System

#### NOTICE

*The Federal Water Pollution Control Act prohibits the discharge of oil or oily waste into the water. Violators can be fined \$5,000.00.*

Do not allow water to accumulate in the bilge area of your boat. When the boat is in use, make sure the bilge pump is turned on. The bilge pump is an automatic pump that tests for the presence of water every two to three minutes and pumps until the water is removed. If the pump is in between detection cycles, the detection mode can be bypassed to operate immediately by turning the switch off and then back on. Remember, the engine and other parts of the drive system could be damaged and there is also a risk of personal injury as increasing water level will adversely affect the handling and maneuverability of the boat.

#### CAUTION


**The risk of personal injury from excess water in the bilge area will adversely affect the handling and maneuverability of the boat. Also, damage to the engine and other parts of the drive system can occur from the additional water. DO NOT allow the bilge pump to operate after all the water has been cleared from the bilge area, damage to the pump will occur.**

European market boats include filters in the bilge drain hoses. These filters are designed to reduce the amount of contaminated bilge water being drained into waterways. The filters are installed in the bilge pump drain hoses. Refer to **Section 2, Deck Layouts** for model-specific locations. Follow the filter manufacturer's recommendations on when they must be replaced.

See page 7-4 in **Care and Maintenance** for more information regarding bilge filters.



**Ballast Tank Valves – 200-V**




CORC0305




# Section 4

## Ballast System – 200-V



## Bilge System – 200-OB, 200-CB, 200-V




CORC100a



# Section 4


## 12-Volt System – 200-OB, 200-CB



CORC0656



## 12-Volt System – 200-V Only




CORC0657



# Section 4

---

## Cockpit Heater System – Optional



CORC098







## Section 5

# Getting Underway

There are many things to consider to make your boating trip safe and enjoyable. You are responsible for the safety of all passengers, the boat and any damage the boat or its wake may cause. Keep passengers from blocking your view so that you do not run into other boats, swimmers, water skiers, personal water vehicles or aids to navigation.

## Safety Checklist



### **WARNING**

**Operating the boat if any problem is found during this inspection can cause death or serious injury. DO NOT operate the boat if any problem is found during this inspection.**

Problems found during this inspection should be handled by your Nautique dealer.

The following checks are essential to safe boating and must be performed before starting the engine.

- Check the weather report, wind and water conditions.
- Check that required safety equipment and PFDs are on-board and in proper operating condition.
- Check that the fire extinguisher is fully charged.
- Be sure the boat is not overloaded.
- Be sure the operator's visibility is not obstructed.
- Check that all maintenance has been performed.
- Raise the engine cover and smell for the presence of fuel vapors. If fuel vapors are detected, **DO NOT OPERATE BOAT** until the source of the vapors has been identified and corrected by a qualified Nautique Dealer service technician.

## Section 5

---

### Safety Equipment

Federal and local laws require certain safety equipment to be on-board at all times. In addition, responsible boaters carry other equipment in case of emergency. Check with local boating authorities for any additional requirements over and above the federal requirements.

### Fueling



#### **DANGER**

**Explosion or fire hazard. Gasoline is extremely flammable and highly explosive under certain conditions. Turn the engine OFF and DO NOT smoke or allow open flames or sparks within 50 feet (15 meters) of the fueling area. Check your boat for fuel leaks and fumes before, during and after each use. Maintain contact between the fuel nozzle and the fuel tank to prevent electrostatic spark. DO NOT use a plastic funnel.**



#### **CAUTION**

**To prevent engine damage not covered by warranty, refer to your engine operation and maintenance manual for recommended fuel type and octane rating.**

Take care not to spill gasoline. If gasoline is accidentally spilled, wipe up all traces of it with dry rags and immediately dispose of the rags properly ashore. Spilled fuel may “yellow” the gelcoat finish and damage gunwale trim.



## Gasoline Containing Alcohol



### CAUTION

**DO NOT** use any gasoline that contains **METHANOL**. This fuel is very corrosive and will create unsafe operating conditions to the boat's fuel system and serious damage to the engine. Any engine damage caused by the use of methanol will not be covered by the engine's warranty.

The implementation of ethanol-based fuel is spreading rapidly throughout the United States. As such, PCM Engines and Nautique provide the following information regarding the use of this fuel. This information addresses the use of ethanol fuels in PCM Engines and Nautique Boats.



### CAUTION

**Use of ethanol blended fuel rated E10 or less is acceptable. DO NOT** use fuels rated higher than **E10**. Ethanol fuels rated higher than **E10** could potentially damage the engine and/or present an unsafe boat fuel system. Damage to the engine resulting from the use of ethanol fuel rated higher than **E10** **IS NOT** covered by the engine's warranty.

If ethanol blended fuel rated E10 or less is used, or if the presence of alcohol is uncertain, inspections and service of the complete fuel system are required more frequently. Any sign of fuel leakage or deterioration must be repaired immediately before further engine operation. It is also important to know that ethanol blended fuel will act as a solvent and will attract and hold moisture.

### NOTICE

*Fuel system or engine damage caused by contamination from water, foreign particles, sludge, or gums entering or forming in the fuel system is not covered by the engine's limited warranty.*



## Section 5

---

Without proper fuel filtration or fuel stabilization, ethanol blended fuel may cause the following:

- Excessive moisture (water) can cause lean operation, hard starting, and operating difficulties such as vapor lock and low speed stalling, and can reduce fuel shelf life.
- Ethanol blended fuels acting as solvents can cause gum, sediment, sludge and other particles to be loosened and carried through the fuel system to the engine.

### **Fuel Stabilizer Recommendations for Ethanol Blended Fuels**

The use of a commercially available fuel stabilizer, such as STA-BIL®, is recommended when storing ethanol blended fuel for more than two weeks.

### **When Fueling:**

1. Avoid fueling at night, except under well-lighted conditions. Also avoid overfilling of the tank by monitoring the fuel level gauge while fueling. Turn on the ignition without starting the engine and monitor the gauge. Stop fueling as the gauge approaches the 'full' level and turn off the ignition when finished. Fuel spillage on our waterways will pollute our environment.
2. Moor your boat securely to the dock. Know the location of the fire extinguisher in case of emergency.
3. Close all doors, hatches, windows and other compartments.
4. Extinguish cigarettes, pipes, and all other flame producing items.
5. Make sure all power is OFF, and DO NOT operate any electrical switches.
6. Add fuel in accordance with the engine operator's manual. DO NOT overfill, and allow enough room for fuel expansion.
7. Refer to the engine operator's manual for correct octane level recommendations for your vessel's engine type.



## After Fueling:

1. Tighten the fuel filler cap. Wipe up any spilled fuel.
2. Check all fuel lines, hoses and connections for leaks and deterioration.

### NOTICE

*Each time you refuel, inspect all fuel lines, hoses and connections for leaks and deterioration.*

## Boarding

When boarding the boat, always step in. DO NOT jump. Avoid stepping on fiberglass or other potentially slippery surfaces. Board one person at a time.

DO NOT board the boat while carrying gear. Set the gear on the dock, board the boat and then pick up the gear.

Use the boarding platform to board from the water. To prevent injury, make sure the engine is OFF when swimmers, divers and skiers are boarding or even near the platform.

## Boat Planing

The performance of your Nautique boat depends on load weight and distribution. DISTRIBUTE WEIGHT EVENLY, from bow to stern, and also from port to starboard.

If your boat is equipped with a ballast tank or loaded, loss of horizon may occur when you begin to plane your boat. Get on plane immediately to restore the vision of your path. DO NOT operate your boat if the loss of horizon prevents you from operating it safely.



### WARNING

**Overloading of passengers, personal equipment and supplies could result in an accident, especially in rough waters.**



### Pre-Operation Checks

It is the owner's responsibility to check all of the items listed below to be certain all preparation steps are completed before you use your boat. Checking these items periodically will soon become a habit. If leaks or other abnormal conditions are found, stop using the boat and contact your Nautique dealer to have the problem corrected.

Get into the habit of performing these checks in the same order each time so that it becomes routine.

- Make sure to check all safety items.
- Check that drain plug is properly installed.
- Check condition of propeller.
- Check that all batteries are fully charged and at the proper level.
- Verify the amount of fuel in the fuel tanks.
- Be sure the lights, horn, bilge pumps and other electrical equipment are in operating condition.
- Check that steering system operates properly.
- Make sure your float plan is submitted to a responsible person.
- Refer to your engine operation and maintenance manual for additional pre-operation checks.



## Getting Underway

---

The following instructions are very important:

- Raise the engine hatch all the way up. Check to see if all the engine drain plugs are in place. Make sure the hull drain plug T-handle in the bilge area is installed.
- Look at all the hoses to make sure they are installed and the hose clamps are tight. Close the engine hatch and turn on the engine compartment blower. Run the blower at least four minutes to remove fuel vapors that might be in the bilge area and engine compartment before starting engine. Remember, if you have detected the presence of fuel vapors, do not start the engine until the source has been determined, problems corrected and vapors removed.
- **Check all gasoline line connections.** Connections are located at the fuel tank, the fuel control cell and the fuel injection system. All Nautique boats are equipped with anti-siphon valves on the outlet fittings of the fuel tanks to reduce the chance of fuel siphoning from the fuel tank if a fuel hose leaks or is severed.
- Fill the fuel tank and check for leaks. Check again for leaks after the engine has run for a few minutes.




## Section 5

---

Checklist before starting boat:

1. Engine oil level - boat must be level.
2. Transmission oil level - boat must be level.
3. Shifting linkage and detent in forward, neutral and reverse.
4. Leaks (water, fuel and oil).
5. Coolant level (closed cooling system).
6. Operation of the throttle and transmission shift control.
7. Battery condition.
8. Visually inspect for any loose mounting fasteners.
9. Verify the emergency stop switch located by the throttle is fully functional and the lanyard is not frayed or damaged. Clip the safety lanyard securely to your body. Keep it attached at all times while you are driving.
10. Check that the engine cooling water (raw water) valve is open and raw water strainer is clean.



CORC015

- Once the boat is in the water, visually check for water leaking at the stuffing box. There should be no leakage from the optional “dripless stuffing box” while a conventional stuffing box must drip a moderate amount of water to properly lubricate the drive shaft. If the “dripless stuffing box” is leaking or water is coming in rapidly with the conventional stuffing box, pull the boat out of the water and have your Nautique dealer service the stuffing box.





## Getting Underway

- Make sure there are no ropes, gear bags, arms/legs near the belts and pulleys of the engine. Severe injury can result by becoming entangled in the belts of the engine while it is running. Make sure the boat is deep enough in the water to supply the water intake with water to cool the engine. Move the throttle into the NEUTRAL “straight up” position.



### **WARNING**

Fire or explosion hazard from fumes accumulating in bilge area. Ventilate the engine compartment by running the blower for four minutes, especially after repairing or refueling and check for fuel spills or leaks.

- Close the engine cover.



### **WARNING**

An engine guard which is not in place or contact with any moving parts can cause death or serious injury. The engine box cover is a machinery guard. **DO NOT** operate your boat without the cover closed and in place unless you are performing a check or maintenance. Keep your hands, clothing, hair and any other body parts away from any moving parts.

- Start the engine.



### **CAUTION**

**DO NOT** continue to operate the starter for more than 30 seconds without pausing to allow the starter motor to cool off for five minutes. This allows the battery to recover between starting attempts.



## Section 5

---

In order to prevent personal injury to you or others, the engine cover must be closed whenever the engine is running.

- DO NOT operate the engine with the engine cover open or while someone is in the area of an open engine cover.
- DO NOT open the engine cover unless the engine is turned OFF and rotating parts are stationary and remain in a stationary position.

**IT IS RECOMMENDED THAT ALL WORK ON THE ENGINE BE DONE BY TRAINED AND QUALIFIED SERVICE PERSONNEL.**

During the warm up period, check the gauges for correct and normal operation of all the systems:

- Oil pressure 35-80 psi, approximately at 2000 rpm
- Cooling water flow and water temperature 140-170°
- Cooling water temperature for fresh water systems: 170-210°
- Volts should rise to around 13-14V or higher
- Idle rpm (600-700) in gear



### **CAUTION**

**DO NOT operate at high rpms in NEUTRAL.**

**DO NOT shift into forward or reverse at engine speeds above idle rpms.**

**DO NOT operate the engine without a cooling water supply.**

**Damage to the water pump impeller and engine can occur. If the engine does not start, refer to Section 9, Troubleshooting.**



If the engine does not start:

- If the fuel filter has been changed or if the fuel system was run dry, it will be necessary to cycle the ignition start button from the STOP position to the START position several times until the fuel pumps build adequate pressure. The cycling of the ignition is necessary because the fuel pumps will run only one to two seconds when the ignition is turned on, unless the engine starts. Keep the shifter/throttle control in NEUTRAL when starting the engine. If the throttle is advanced, the computer will think the engine is flooded and initiate a “clear flood” condition which will shut off fuel to the engine and not allow it to start. The idle speed increase is normally on hot or cold starts. This is programmed into the computer. When the engine starts, the idle speed will jump to approximately 1,500 rpm and quickly decrease to between 750 and 900 rpm.
- Check for gasoline and cooling water leaks on the engine.
- Check for cooling water circulation (look at the raw water strainer at the rear port side of the engine for water movement).

## Flooded Engine

If your engine does become flooded, use caution when attempting to start the engine. Push in the transmission disengagement button at the bottom of the shifter/throttle control handle and advance the throttle to the FULL THROTTLE position. By pushing the button in, the shift linkage is disengaged and the transmission remains in NEUTRAL during the starting procedure. Use the start key as described in **Section 3, Run Mode**. DO NOT operate the start switch for more than 30 seconds. Allow the starter to cool.

We suggest you bring your boat back to your Nautique dealer after 25 hours of operation for an inspection of the shaft alignment, stuffing boxes adjustment, and the fuel system checked for leaks. This is not a free service. Follow Pleasure Craft Marine's (PCM) recommendations in the maintenance section for additional service to the engine. Consult your Nautique dealer to determine what charges will apply.



## Section 5

---

When the engine starts, move the throttle lever back until the engine is running about 2,500 rpm or less. Check the gauges for normal readings and let the engine run for a minute to burn the excess fuel. If the gauge readings are abnormal, stop the engine and contact your Nautique dealer. When the engine runs normally, check the engine for fuel, water and exhaust leaks. If there are leaks, stop the engine and correct them before you continue.

After your initial run:

- Check the engine oil level
- Check the transmission oil level
- Check for leaks (water, fuel and oil)
- Check that engine frame bolts and mounts are tight
- Check that throttle and shift control operates correctly

### NOTICE

*If the engine backfires when you try to start it, the problem may be more serious than flooding.*

- *DO NOT CONTINUE TRYING TO START THE ENGINE.*
- *CONTACT YOUR NAUTIQUE DEALER OR A QUALIFIED TECHNICIAN TO CORRECT THE PROBLEM.*

*DO NOT keep trying to start the engine under these conditions. Engine damage or personal injury can result.*



## Break In Procedure

Make sure all your passengers are properly seated before starting the break in procedure. After the engine is thoroughly warmed up and you have driven the boat into a large open area, advance the throttle to wide open until the maximum rpms are reached. DO NOT exceed 5,000 rpm. Reduce the throttle to 2,800-3,000 rpms and cruise at or below this speed for 30 minutes. Reduce the speed to idle, advance the throttle to wide open and operate at that speed for one minute; reduce to the previous cruising speed for a few minutes and repeat. Accelerating from idle speed to wide open assists in seating the piston rings. This cycle can be repeated from time to time during the first five hours of operation. DO NOT operate engine at full throttle for longer than one to two minutes.



### CAUTION

**Follow these procedures only when conditions are such that you can drive the boat safely. DO NOT attempt to break in an engine by letting it idle at the dock.**

## Propeller Selection

The maximum rpm of the engine at full throttle under normal load conditions can be controlled by propeller pitch, diameter and design. It is essential the propeller does not underload or overload the engine.

**Propeller Overloading**, results in low rpms at wide open throttle will give poor performance, poor fuel economy and eventually result in engine damage.

**Propeller Underloading**, if operated with a propeller that has too little pitch or diameter, poor performance will result.



### NOTICE

*Running your boat in shallow water can cause propeller shaft, strut, propeller and rudder damage and sand and silt to be pulled into the cooling system. This will cause excessive water pump wear and can clog the water passages in the engine. Heavy weed growth in the water can plug the raw water strainer and oil coolers and cause engine damage. There is a raw water strainer located near the rear of the engine to strain the water before it goes into the transmission cooler and then the engine. Check this every time you use your boat to make sure it is not clogged.*

Refer to **Section 1, Hazardous Conditions, Boating Safety.**

If the engine fails to start or is not operating properly, contact your Nautique dealer for assistance.

## Shifting



### WARNING

**Boat movement without making sure your path is clear can cause death or serious injury. Make sure there are no swimmers or obstacles in the water near you.**

Keep the control lever clean and clear of obstructions. Refer to your engine operator and maintenance manual for shifting information.

Always pause in NEUTRAL before shifting from reverse to forward and from forward to reverse.

## Steering

Practice steering your boat. Make sure the steering system is working correctly and is properly maintained.



### CAUTION

**The steering system must be in good operating condition for safe boating. Frequent inspection, lubrication and adjustment by your Nautique dealer is recommended.**



## Stopping

Stopping the engine immediately after operating at high speed is not recommended. Allow the engine a two to three minute cool-down period at idle or low speed.

Refer to your engine operator and maintenance manual for stopping information.

## Docking



### WARNING

**There is a crushing hazard between the boat and other objects that could cause death or serious injury. DO NOT use your hands, arms or another part of your body to attempt to keep the boat from hitting other objects, especially a dock.**

Approach a dock slowly and use caution. Plan your maneuvers ahead of time. Allow wind and current movement to help maneuver your boat.

Come to a stop a short distance from the dock, then proceed slowly.

- Have your fenders and mooring lines ready.
- Observe how the wind and current are moving your boat. Approach the dock with the boat pointed into the wind, if possible.
- If possible, throw a line to a person on the dock and have that person secure a bow line. If no one is on the dock, maneuver as close as you can, then secure any line to a piling or dock cleat.

Before tying up your boat, be sure to use enough fenders to protect the boat from damage. If possible, tie up the bow toward the waves with a good quality double-braided nylon line. Tie up only to the lifting rings, tie down eyes or cleats; DO NOT use the handrails or windshield frame. If the boat is to be moored for a long period of time, use chafing protectors on the lines to protect the gelcoat finish. Leave a little slack in the lines to allow for some wave movement or tidal action as applicable.

When departing, cast off the bow line and move away. If the wind or current is pushing away from the dock, cast off all lines and allow to drift until you are clear.



### **NOTES**







## **Section 6**

### **Running**

Nautique urges you and all others operating your boat to seek certified instruction from the local boating authorities.

This section is designed to present the most basic operational principles. It is NOT intended to cover all conditions encountered during operation. Therefore, the principles in this manual are limited to the facts related directly to the operation of your boat, while the responsibility for the proper application of these principles belongs to you.


### **Hydro-Gate™**

The Hydro-Gate is engaged by moving the SportShift Hydro-Gate control handle located at the helm's starboard-side fore and disengaged by moving the handle aft. The SportShift and Hydro-Gate can be used at any speed or at rest. Refer to **Section 3 – Hydro-Gate Control and SportShift**.

### Maneuvering Techniques

Steering response depends on three factors: rudder position, motion and throttle.

Maneuvering in congested areas and advanced courses requires mastering and good “Rules of the Road” ethics. Your Nautique boat is designed to be responsive and agile enough to meet the challenge of these conditions.



#### Maneuvering

Learning to maneuver a boat safely takes practice. A boat will respond differently at lower speeds than it will at higher speeds. Learn these maneuvering techniques in an open water area before attempting maneuvers near docks and other objects.

When making tight maneuvers, it is important to understand the effects of turning. Since both thrust and steering are at the stern of the boat, the stern will push away from the direction of the turn. The bow follows a smaller turning circle than the stern.



#### **WARNING**

**Quick maneuvers can cause people and objects in the boat to be thrown about resulting in death or serious injury. DO NOT make quick or high-speed maneuvers when you or your passengers are not prepared.**




The effects of unequal propeller thrust, wind and current must also be kept in mind. While wind and current may not always be present, experienced boaters will use them to their advantage. Unequal thrust is an aspect shared by all single-engine propeller-driven watercrafts. The Ski 200 Nautique has a clockwise (right hand) rotation propeller and the Sport 200 Nautique has a counterclockwise (left hand) rotation propeller. Propeller rotation has a direct effect on steering, especially when operating your boat in reverse. Operators should familiarize themselves with the handling characteristics of the boat in an open area before attempting to dock or perform other close maneuvers.

Stopping (checking headway) is a technique that must be developed. Reverse thrust is used to slow and stop the boat. The momentum of the boat will vary according to the load as well as the speed. Make it a practice to slow to idle (no-wake) speed before shifting into reverse.

It is best to learn maneuvering skills in open water away from traffic. Adequate practice is the only way to develop your boating skills.

## Tow Pattern

A large loop pattern is preferred for beginners. This pattern does not require the skier to cross the wake. As the skier's skills improve, a looped end or dumb bell pattern may be used. The dumb bell pattern provides a long straight course which allows the wake to disperse, leaving the skier with a smooth water surface. The dumb bell pattern is popular with ski tournaments and clinics.



**Dumb Bell Ski Pattern**



## Section 6


---

### Freezing Temperatures

When the boat is removed from the water, drain the cooling and heater system (as equipped) completely. Refer to **Section 9 – Winterizing Your Boat**.

### Anchoring

There are many types of anchors available on the market. The choice of one anchor over another depends on many factors. An anchor will usually hold best in a mixture of mud and clay or in hard sand. A Danforth anchor is recommended for general boating. For more information on anchors, contact your Nautique dealer.



KC-1571C

**Danforth Anchor**




#### **WARNING**

Improper use of an anchor can pull a boat underwater causing death or serious injury. Anchor from the bow, NOT from the stern.



## Dropping Anchor

- Make sure the line is tied to the anchor and tie the other end to the forward cleat or bow eye.
- Head the boat into the wind or current over the spot where you want to lower the anchor. Spot the boat before lowering the anchor.
- When the anchor hits bottom, slowly back up the boat, keeping tension on the line. Let out an anchor line that is six to seven times the depth of the water. For example, if you are in 10 feet (3 m) of water, let out 60 to 70 feet (18 to 21 meters) of line.



### Anchoring

- Pull on the line to make sure the anchor is holding.
- Occasionally check your position against the shoreline. If the anchor is dragging and you are drifting, reset the anchor.

## Weighing (Pulling In) Anchor

Start the engine and move forward until the anchor line is straight up and down. Pull hard to lift the anchor from the bottom material.

If the anchor is caught on the bottom, attach a line to the bow cleat so that it is taut. The up and down motion of the bow from wave action may lift the anchor from the bottom. If the anchor remains caught, let out a few more feet of line and attach it to the bow cleat. Slowly maneuver the boat around the anchor until the anchor pulls loose. Be sure to keep the line tight during this procedure.



### Performance Boating



#### **WARNING**

**Failure to maintain control can result in death or serious injury. Always keep one hand on the steering wheel and the other on the control lever. If the boat begins to operate in an unsafe way, adjust speed and course as necessary to regain control.**

Your Nautique boat is a high performance boat. **DO NOT** be tempted to push your boat to its limits until you are completely familiar with its operating characteristics.

Nautique boats are the ones of choice of the better professional and amateur ski shows and tournaments. You may have seen drivers put their Nautique through extreme maneuvers. These drivers are paid professionals on a closed course with hundreds of hours of experience. **DO NOT** attempt extreme maneuvers without proper training.

We recommend that you never operate the boat without first having an initial orientation and familiarization/demonstration ride with your dealer or an operator experienced with the boat/engine combination. All boats perform differently.

The operator should have at least ten hours of experience with the boat before any full throttle operation. **DO NOT** operate your boat until you are completely experienced with its handling characteristics.

### Propellers

Your Nautique boat is equipped with a propeller best matched to its engine and boat combination. If you feel you are experiencing poor performance, contact your Nautique dealer. Care and selection of your propeller is very important to proper boat operation.





## Section 7

# Care and Maintenance

This section describes how to care and maintain your Nautique boat. Periodic inspection and maintenance of items listed in this section is absolutely necessary.

Winterization and some engine maintenance functions are best performed by your Nautique dealer. Some maintenance items that can be done by you or your dealer are listed below. We suggest that you familiarize yourself with these even if you have your dealer service your boat.

### General Maintenance

1. Read engine operator and maintenance manual very carefully.
2. Check for fuel line leaks every time you use the boat.
3. **DO NOT** start your engine if gasoline odor is present. Gasoline fumes are highly explosive. Before starting your engine, open the engine cover, inspect the engine compartment for gasoline fumes and operate the blower for at least four minutes. Run your blower when operating at slow speeds. If fuel vapors are present, do not start the engine. Check all hoses and fittings to determine the source of the vapor. Make the necessary adjustments or take the boat to your local dealer to eliminate the fuel vapor.



#### **WARNING**



**Fumes accumulating in bilge area present a fire or explosion hazard which could cause death or severe injury. Ventilate the engine compartment by running the blower for four minutes, especially after repairing or refueling and check for fuel spills or leaks. If you smell gasoline vapor or see liquid gasoline, DO NOT start the engine.**

## Section 7

4. When servicing the ignition switch or any wiring, always disconnect the battery cables from the battery.
5. Check for water circulation when the engine is running. Exhaust should contain steady flow of water. In closed cooling systems, make sure the coolant in the cooling system is at the proper level.

### Engine Intake Raw Water Strainer


Visually inspect the engine intake water strainer for debris before each use. To clean the strainer, close the engine intake water valve and unscrew the strainer bowl (A). DO NOT lose the rubber O-ring (B) that seals the bowl to the cap. Carefully remove the screen (C).





# Care and Maintenance

Clean debris from the bowl and screen and rinse parts in fresh water. Insert the screen, place the O-ring in the groove of the bowl and screw the bowl on hand tight. Be sure to open the water valve before starting the engine.



CORC029

Some engines are equipped with a closed cooling system with a self-contained reservoir for engine coolant. Self-contained systems are equipped with a heat exchanger which uses raw water to cool the coolant. All raw water systems are equipped with a valve and strainer.



### **Bilge Pumps**

Check your bilge pumps often to make sure they are operating efficiently. There are two bilge pumps: one is at the rear of the boat near the rudder and under the floor by the forward bulkhead located next to the fuel tank. To keep the pumps from getting clogged, remove any debris you find in the bilge. Wash the bilge with a good biodegradable household detergent or a bilge cleaner available at your Nautique dealer or a marine supply store. Rinse with water with your bilge pumps running. If your pumps seem to lag, remove the top of the pump from the base and check the impeller to make sure there is no debris inside. See your dealer if there is still a problem with the pumps.

### **CE Bilge Discharge Filter**


Your boat may be equipped with a CE-compliant bilge discharge filter system that is designed to prevent oil-contaminated bilge from being discharged into the environment. One CE bilge filter is required for each bilge pump. The CE bilge filter is located below the deck, connected to the bilge discharge hose just before the hose connection to the deck outlet fitting.

CE bilge discharge filter cartridge XOil™ replacement should be part of a regular maintenance program to prevent oily, contaminated bilge from passing through the deck outlet fitting into the environment. The period between cartridge replacements will depend on the condition of the bilge. Always replace the cartridge immediately after there has been a great amount of oil or other contaminants spilled into the bilge.



## Cartridge Replacement

1. Turn off power to the bilge pump.
2. Unscrew the filter bowl (A) by turning counterclockwise and pour any excess bilge water remaining in the bowl back into the bilge.
3. Remove the used cartridge (B) and dispose of in a suitable container.
4. Inspect the O-ring (C) located on top of the bowl and replace if worn.
5. Be sure that the seals located on the top and bottom of new cartridge are in place and correctly aligned.
6. Place the new cartridge into the bowl and reattach the bowl to the filter housing (D) by turning clockwise.
7. Turn on power to the bilge pump.
8. Turn on the bilge pump and inspect all connections for leaks.
9. Bleed any air trapped in the housing by using the bleed button (F) or, if so equipped, the bleed screw (E). Both are located on top of the filter housing.



CORC0241



### Ballast Filtration System (optional)

Some local lake authorities require the ballast system to be decontaminated before launch. Nautique offers Aquatic Invasive Species filters integrated directly into the ballast fill hoses that may allow you to speed up your inspection. The filters are sealed and date tagged at the time of manufacture and function automatically when the ballast pump is turned on.

#### NOTICE

*Ballast filtration elements must be replaced by an authorized dealer only.*

Ballast filtration elements should be changed at least every 6 months by an authorized dealer. Depending on the water quality where your boat operates, ballast filtration elements may need to be changed more frequently. If you experience longer than normal ballast fill times, it is likely time to replace the ballast filtration elements. This should be performed only by an authorized dealer so that the filter units are re-sealed with genuine Mussel Mast'R™

“Tamper Evident Seals” and “Date Tags” are re-applied. This must be done in order to be recognized and accepted at invasive species inspection stations. See your Nautique dealer as needed for replacement of filter cartridges.



CORC0647

## Propeller


### CAUTION

- A propeller can be very sharp. Be careful when you handle it. Wear a pair of protective gloves when handling any propeller.
- Remove your key from the ignition and remove the Emergency Stop Switch clip from the switch to prevent accidental starting of the engine.
- DO NOT reuse the nylon locknut or the cotter pin.
- DO NOT use a damaged propeller. A damaged propeller can damage your engine and boat.

### Removal

1. Remove the cotter pin from the propeller shaft and discard.
2. Wedge a piece of 1" x 4" wood between the propeller blade and the starboard side of the strut and rudder.
3. Remove the nylon locknut and discard.

Use a propeller puller to remove the propeller, then remove the key from the keyway. Inspect the keyways and key for any damage.



CORC047



## Section 7

---

### Installation

Before placing the propeller on the shaft, look at the keyway on the shaft and in the propeller. Make sure the key slides freely in the shaft keyway and the propeller keyway. **DO NOT** use the propeller nut to advance the prop onto shaft.

If the key has burrs, remove them by filing the flat sides or replace the key. **DO NOT** file the key beyond its normal shape or size.

1. Rotate the shaft until the keyway is “up.”
2. Place the key in the shaft keyway. The propeller will only slip on in one direction. Rotate the propeller so the keyway in the propeller is aligned with the keyway on the shaft. Once it is aligned, push the propeller onto the shaft. You’ll hear a solid “thunk” or feel it, as the propeller is seated.
3. Wedge a piece of 1" x 4" wood (**A**) between the propeller blade and the port side of the strut and rudder.
4. Install a new nylon locknut (**B**) and torque the nut to maximum of 30 ft-lbs (40.7 N•m).
5. Install new cotter pin (**C**). Bend the retaining ends of the cotter pin in the opposite directions. Make sure the cotter pin is snug and does not rotate.

### Through-Hull Fittings


All fittings that actually pass through the hull on the wetted surface are caulked in. These are not serviceable and must not be tampered with.



## Quick Oil Drain System

Change the engine oil after the first 25 hours of operation, then after every 50 hours. The boat must be removed from the water to use the quick oil drain system. There is a drain hose attached to the bottom of the oil pan with a small plug screwed into the loose end of the hose.

Remove the bilge drain plug and put the end of the drain hose through the bilge drain opening. Make sure there are no kinks or sharp bends in the hose. The engine will drain most efficiently when the oil is warm. Allow several minutes for the oil to settle and drain. Dispose of used oil in an environmentally safe manner.



CORC169

### NOTICE

*Be sure the engine is off when you are draining your oil.*



### WARNING

**Prolonged or repeated contact with used engine oil can cause death or serious injury. Wash affected area immediately with soap and water.**



# Salt Water Boating

### NOTICE

*If you use your boat in salt water or other unusual water conditions, fresh water flush your engine and cooling system with freshwater.*

Nautique offers an optional fresh water flush kit. The relief valve in this kit prevents excessive water pressure to your engine. Excess water pressure can damage the engine. This is the only system we recommend if you use your boat in salt water or unusual water conditions. Flushing the system by running the boat in fresh water is another good way to flush the engine, but it must be done immediately.

## Freshwater Flushing Kit - Optional

The optional freshwater flushing kit allows you to flush the water system after your boat is operated in salt water, brackish water or unusual water conditions.

We recommend using this system if you use your boat in salt water or unusual water conditions. Flushing the system by running the boat in fresh water is another good way to flush the engine, but it must be done immediately.

DO NOT connect the flushing kit to a water source which exceeds normal municipality water pressure.

### Proper Use of Freshwater Flushing Kit

1. Open the ball valve located between the system's deck fitting and main engine cooling water supply hose.
2. Make sure that the ball valve located in the main cooling system supply hose is open. This valve is located near the hull inlet fitting.
3. Open the cap of the system deck fitting and properly connect a water supply hose, making sure the connection is secure.
4. Turn on the hose and start the engine.





## Care and Maintenance

---

5. Close the ball valve of step 2 unless the boat is on a trailer or lifted up in the air, in which case it should be left open.
6. Run the engine for several minutes after it has reached the normal operating temperature to ensure proper flushing.
7. Reduce the engine speed to idle, shut off the engine and immediately shut off the water supply hose. Please note, failure to shut off the water supply hose immediately could possibly result in engine damage.
8. If the ball valve of step 5 was closed, open it now and close the step 1 ball valve.
9. Remove the water supply hose and reinstall the deck fitting cap securely.

### Coastal Edition

Nautique boats with the Coastal Edition are equipped to effectively resist saltwater corrosion while maintaining premium performance capabilities. Follow these procedures to help keep your Nautique boat operating efficiently.

1. Wash down the boat after each use. Wash the boat at least once a week even during periods of non-use. Use biodegradable soap. Include vinyl components (existing cleaners). Raise the cushions in the open position to improve drying. Ensure that the boat is fully dry before installing the mooring cover.
2. Wax metal parts every 6 months including anodized, aluminum and stainless steel components (stainless steel will rust without care). More frequent applications may be necessary depending on exposure. Use a polish that is recommended for metal.
3. Zinc anodes combat the effect of electrolytic corrosion on metal components. Nautique Boat Company, the manufacturer of Nautique boats, installs zinc anodes on the Hydro-Gate plate, the prop shaft and the rudder. Replace zinc anodes after they have worn to 50% of their original size (not tied to time). Anodes may have a red or blue wear indicator to help determine when replacement is necessary. Each time new anodes are installed, apply a marine grade waterproof grease to the fastening bolt.



## Section 7

---

4. Flush the engine with fresh water after each use. See Freshwater Flushing Kit - Optional on page 7-9 for more information.
5. Nautique Boat Company, the manufacturer of Nautique boats, applies dielectric grease to the battery connections at the factory. Reapply if these connections are serviced.
6. The steering tube is equipped with a grease fitting. Lubricate the tube with a marine grade, waterproof grease every 100 hours of use or once a year, whichever comes first. Do not over-grease the steering tube. Over-greasing can cause damage to the wiper seal and allow the excess grease to leak and expose the steering rod to moisture and corrosion.
7. Wax the hull at least once a year with a UV wax. Rotate the boat during outside storage every 6 months for even color blending.
8. Apply a rust corrosion protection spray such as Boeshield T-9® to the engine and bilge components (electrical connections, pumps, etc.) once a month or more frequently depending on exposure. Turn the engine off and ensure that the engine and all components are cool and dry before application. Follow all manufacturer's instructions when applying the product.

## Battery Maintenance



### **WARNING**

**Explosion or fire hazard from vented fumes can cause death or serious injury.**

- **Wear eye protection and rubber gloves when working on or around batteries.**
- **DO NOT charge or use a battery booster to start your engine.**
- **DO NOT smoke or bring a flame near a battery at any time.**
- **DO NOT have your head directly above a battery when making or breaking electrical connections.**
- **DO NOT use a metal object to spark between battery posts to check if the battery is charged.**



## Care and Maintenance


Take care when connecting or disconnecting a battery charger. Be sure the charger is turned OFF and unplugged from power source when you clip ON/OFF the connecting clamps.

Make sure you have a solid connection with the charging clamps. Poor connections are common causes of electrical arcs and engine problems. Follow instructions.

DO NOT make or break electrical circuits at the battery terminals; a spark will occur when a live circuit is opened or made. Turn off all components.

Use a voltmeter or hydrometer to check the battery charge condition.

The battery cables should be removed from the battery when the boat is placed in storage, on display or in transit. This will eliminate the possibility of the engine accidentally starting without a supply of cooling water and may damage the engine.



CORC212

+ = red positive (A)

- = black negative (not shown)



## Section 7

To clean your battery, remove and wash down the battery case with a diluted ammonia or baking soda/water solution to neutralize the acid, then flush with fresh water. Keep the fill/vent caps tight so the neutralizing solution does not get into the battery cells.

The electrolyte level should be checked every 30 days. Add only distilled water to maintain the level between the top of the plates and the bottom of the fill/vent cap. DO NOT overfill. Remember batteries contain sulfuric acid which can cause severe burns.

### Battery Cable Warning Alarm



#### CAUTION

**Avoid equipment damage caused by reversed polarity. Alarm sounds if battery leads are reversed.**

Nautique has included a Warning Alarm in the battery cable system that sounds an audible alarm if the positive or negative battery cables touch the opposite connecting post on the battery (reverse polarity situation). The alarm will sound even if the battery selector switch is in the OFF position. If this situation occurs and the alarm is activated, inspect all electrical systems for possible damage before attempting to reconnect the battery cables.




#### CAUTION

Avoid equipment damage caused by reversed polarity. Alarm sounds if battery leads are reversed.



BATTERY 1



BATTERY 2

CORC0474



## Gelcoat Maintenance

Your Skipper's Kit included samples of quality boat care products recommended by Nautique. Nautique is proud of its heritage and wants you to feel this pride every time you use your boat.

Regular maintenance is the key to keeping your hull and deck surfaces in good condition. Sun exposure, residue from trees and minerals in the water affect your boat's finish.

To help maintain the shine of your boat, wash the hull with a mild bio-degradable detergent after each use. This will help to remove any debris and waterborne materials that are on the hull. Use a soft sponge or towel and dry with a chamois cloth to prevent water spots.

Wax the hull sides and deck regularly with a high quality wax. Waxes and polishes are available at your Nautique dealer and marine supply stores. Always follow the directions on these products carefully before you use them.

The hull bottom is an especially important area to keep clean since any buildup of water scum and algae will create drag and reduce the boat's efficiency. If you must leave your boat in the water, there are compounds to remove algae buildup on your hull. Some of these can be caustic. Pay special attention to the cautions on the label of these coatings. Ask your Nautique dealer for advice on which work best in your area.



## Section 7

---

If your boat's gelcoat develops a chalky look over a period of time due to exposure to sun, there are gelcoat buffing and polishing compounds available at your Nautique dealer and marine supply stores. **DO NOT** use common household scouring pads or powders.

If you will be keeping your boat in the water for ANY period of time, we suggest that the wetted surface of the hull be painted with an epoxy paint formulated for blister protection.

Sudden changes in temperature can affect gelcoat. If you move your boat from outdoors to a heated area, allow the temperature change to be gradual. Heat the area after the boat is moved to allow the boat to warm up slowly as the area is heated. Also, if you move your boat from a warmer area to a colder one, wait for the outside temperature to be closer to the warmer area's temperature or allow the area and the boat to cool down first.



### **WARNING**

**Fire or explosion hazard from fumes accumulating from rags being stored in bilge area. DO NOT store rags used to wipe up fuel or solvent spills in the boat. Dispose of rags properly ashore.**

## Care of Metal

- Aluminum care
- Stainless care
- Chrome

Keep all metal work rinsed and wiped dry. Periodically polish it with a quality commercially available metal polish to remove substances such as air-borne pollution and natural body oils from your hands.

**DO NOT** use citrus cleaners on stainless steel or wax on anodized towers.



## Care of Glass

Your windshield, mirrors and gauge faces all deserve the same attention as the other parts of your boat. Clean them often with quality commercially available glass cleaners.

## Adhesive-Backed Non-Skid

All adhesive-backed non-skid surfaces can be cleaned by using a medium-to-stiff brush and warm, soapy water. Make brushing strokes in the direction of the non-skid grain. Rinse with clean water and let the non-skid air-dry.

## Vinyl Maintenance and Cleaning

Nautique has selected the finest marine grade vinyl for your Nautique. It is important to keep it clean at all times. There are some substances that will stain the vinyl if you leave them on for even a short period of time. Remove any contaminant and clean the area immediately. DO NOT use Formula 409® Cleaner, Fantastik® or any silicone-based products. Certain household cleaners, powdered abrasives, steel wool, industrial cleaners, dry cleaning fluids and lacquer solvents can cause damage and discoloration. DO NOT use these cleaners.



## Section 7

---

Common stains and steps to treat:

	Step #1	Step #2	Step #3
Chewing gum	D	A	D then A
Eye shadow	E	B	E then B
Engine oil	B	B	B
Spray paint	C	B	B
Mildew or wet leaves *	D	B	A
Shoe polish *	A	B	
Yellow mustard	D	B	
Oil based paint (fresh)	D	B	
Oil based paint (dried)	A	B	
Suntan lotion *	D	B	
Tar/Asphalt	A	B	
Lipstick	A	B	
Latex paint	A	B	
Crayon	D	B	
Ketchup	A	B	
Grease	D	B	
Ball-point ink *	E	B	
Permanent marker *	E	B	
Coffee, tea, chocolate	B	B	

Use the chart above to clean common stains:

- A. Medium-soft brush, warm, soapy water/rinse/dry
- B. Meguiar's Vinyl & Rubber Cleaner/Conditioner #57
- C. One(1) tablespoon ammonia, 1/4 cup hydrogen peroxide, 3/4 cup water rinse/dry
- D. Wipe or scrape off excess (chill gum with ice)
- E. Denatured Alcohol/rinse/dry

After all cleaning methods, rinse well with water.


\*Suntan lotion, shoe polish, wet leaves and some other products contain dyes that stain permanently.





## Tunable Rudder

The Tunable Rudder\* is designed to offer easy steering adjustment. This system uses a composite tuning foil which is located at the upper aft corner of the rudder blade. Use a Phillips head screwdriver to adjust the foil. Loosen the two screws in the relief slots of the tuning foil.




CORC045

If the boat is pulling port (A), rotate the foil to port (B) and tighten screws. If the boat is pulling starboard (C), rotate the foil to starboard (D) and tighten screws. Always remember that movement of the trailing edge of the foil to one side will cause the steering to pull to the opposite side.

### NOTICE

*After each adjustment, test run and adjust again if necessary.*



CORC162

\*Manufactured under license from National Products, Inc. U.S. patent 5,746,147.




## Section 7

### Rudder Remote Lube Fitting

The remote lube fitting allows for easy access to lubricating the rudder. In the Ski 200 the remote lube fitting is located on the port stringer under the aft removable floorboard. In the Sport 200 it is located on the deck under the engine hatch. Use a quality marine grease and gun. Connect the grease gun to the fitting and apply a light pressure to the gun until you feel a slight resistance.

### Checking Transmission Fluid

1. The fluid level must be checked in one of the following conditions:
  - A. Engine/Transmission is cold;
  - B. Engine/Transmission has been shut off for at least 2 minutes to allow fluid to drain back.
2. Remove the dipstick by turning the T-handle counterclockwise.
3. Wipe the dipstick off using a clean cloth.
3. Re-insert the dipstick to the threads (***DO NOT screw the dipstick in***) and remove. Observe the fluid level.
4. The fluid level should be at the “FULL” mark. If low, add the specified fluid in small increments through the dipstick hole in the transmission. Repeat the checking procedures until the fluid level is at the “FULL” mark.
5. Replace the dipstick and tighten securely.



CORC0617



### Checking V-Drive Unit Fluid (200-V Only)



#### WARNING

Burn hazard from hot V-Drive unit fluid can cause serious injury. Do not remove the V-Drive unit drain/fill plug while the engine is running or while the V-Drive unit is hot.


Allow the V-Drive unit to cool and check with the boat level.

1. Remove the drain/fill plug from the V-Drive unit.
2. Verify the fluid level; the fluid level should be at the bottom of the threaded hole. If low, add the specified fluid through the threaded hole to the proper level.

#### NOTICE

*The V-Drive unit fluid is a very high viscosity. To make adding fluid easier, remove both fill plugs.*

3. Replace the drain/fill plug and tighten securely.



CORC210



### NOTES





## **Section 8**

# **Troubleshooting**

The following chart will assist you in finding and correcting minor problems with your Nautique boat. Refer to your engine operation and maintenance manual for more detailed information for any problem concerning the starting, shifting or operation of the engine.

Some problems may require the skills of a trained technician and special service tools. Please contact your Nautique dealer for assistance.

## Trouble Check Chart

### Performance

Symptom	Possible Cause
Starter motor will not operate	• Shift handle not in NEUTRAL
	• Battery disconnect switch OFF
	• Battery and electrical connection loose or corroded
Engine will not start	• Emergency stop switch not in place
	• Starting procedure not followed
	• Fuel tank empty
Poor boat performance	• Contaminated fuel
	• Clogged fuel filter
	• Uneven load distribution
	• Improper propeller selection
	• Marine growth on hull
	• Engine problem
Poor gas mileage	• Marine growth on hull
	• Engine problem
Excessive vibration	• Damaged or fouled propeller
	• Misaligned propeller shaft coupling
	• Bent propeller shaft
	• Engine problem
Engine runs but boat makes little or no progress	• Fouled or damaged propeller
	• Engine problem
Steering problem	• Corroded steering cable
	• Rudder worn
Throttle problems	• Throttle wire harness loose or unplugged. Check the wiring harness connection at throttle and engine.
	• Defective throttle return spring
Shifting problems	• Low transmission fluid level
	• Sticking transmission shift lever
	• Bad wire connection in shifting harness



## Electrical

Symptom	Possible Cause
Electrical problem	• Open circuit breaker or blown fuse
	• Loose wiring connection
	• Defective switch or gauge
Dim or no lights	• Open circuit breaker tripped or in OFF position
	• Battery discharged



## Section 8

---

### NOTES








## Section 9 Storage

### Lifting Rings

Your Nautique is equipped with bow and stern lifting rings. These are designed to lift your boat in a steady and secure manner. The winch, hooks and other components of the lifting mechanism must have sufficient capacity sufficient for your boat. Refer to **Section 2, Specifications**. The weights listed in the specifications are dry weight. You must add the weight of the battery, fuel and gear to the dry weight.



CORC138

## Section 9

---




### CAUTION

Drain the bilge and / or launch control system and/or aftermarket water bladder(s) to eliminate excess water before you lift the boat.

### NOTICE

*Only use a hook that will pass easily through the lifting ring without binding. A hook that is too large or off-center could break the lifting ring. DO NOT use a sling to lift the boat. Damage to your boat can occur.*

If your boat is equipped with a retractable lifting ring, it can be used for lifting your boat.



CORC055




## Winterizing Your Boat

Winter storage procedures vary depending on climate, type of storage and length of storage. Check with your dealer/storage facility manager for their advice on what works best in your climate. Winterization functions are best performed by your Nautique dealer. Refer to your engine operation and maintenance manual for more information.

When storing your boat up on a rack system, it is important that the racks adequately support the hull bottom.

If you do not have a trailer, support the boat like a Nautique dealer recommended trailer. It is important to have an even weight distribution.


If you use a mooring cover, DO NOT put it on when the interior of the boat is wet and/or hot. It will trap moisture and lead to mildew on the carpet and/or vinyl. Make sure your mooring cover allows air to circulate, even if you have to leave a portion of the cover off.



## Section 9

---

The raw water strainer bowl (A) remains full of water even after the rest of the engine cooling water system is drained. To properly winterize your boat, the strainer must be removed and emptied. **DO NOT lose the rubber O-ring (B) that seals the bowl to the cap.** Clean screen (C) if required. If the water is not removed, the bowl can be damaged. A damaged sea strainer can cause overheating problems during the next season.



CORC078

### Winterizing the Heater System (in Closed-Cooled Engines Only)

1. Disconnect the hose connections at the engine (2 each).
2. Place one hose end into a small bucket and introduce 50 PSI (or less) of air into the other hose end. This will force all fluid out of the hoses and the heater core.
3. Reconnect the hoses to the engine.



### Check for Water in Your Fuel System

A small amount of water left in the fuel system for several months can result in damage to the fuel system and engine. If you are storing your boat for the winter, it is a good practice to remove any water in the fuel system.

The Fuel Control Cell can be drained by removing the drain plug at the bottom of the canister.

1. Loosen the return fuel hose to provide an incoming air source.
2. Clamp the return fuel line some way to minimize the amount of fuel that may drain.
3. Once the canister is drained, coat the threads of the drain plug with a fuel resistant pipe thread sealer, then replace and tighten the plug.
4. Reconnect the fuel hose, and tighten the hose clamp. The threads must be sealed properly to avoid a possible fuel leak.

Check your Fuel Control Cell once each year for signs of water in the canister. If it appears there is water buildup in the canister, see your Nautique dealer for service.

An empty fuel tank can accumulate water inside by changing temperature and repeated cycles of condensation on the inner surfaces of the tank. If the fuel tank is kept at about 3/4 full during storage, less water can condense, limiting the buildup of water in the fuel tank.

Fill the tank to 3/4 full maximum during storage to eliminate the possibility of fuel expansion problems caused by temperature changes. This minimizes overflow of fuel from the fuel vent. Not only can this overflow be hazardous, but it will also adversely affect decals and pin striping on the boat.



## Section 9

---

Add a good quality fuel stabilizer to the fuel prior to winterizing to slow down the rate of fuel decomposition. You can purchase a fuel stabilizer at your servicing dealer, most marinas or an auto supply store. Add the stabilizer to the tank.

If you did not add the stabilizer previously, run the engine to circulate fuel throughout the system. Remember, always follow the fuel stabilizer manufacturer's recommendations for proper mixing.

### **NOTICE**

*Gasoline expands when the temperature increases. Never store your boat with more than 3/4 of a tank.*

Refer to the engine's owner's manual for winterization of the engine.



## Trailer/Trailerling

### Hitch

If you do not already have a trailer hitch installed on your vehicle, go to a reputable installer to have the proper size hitch installed. Always use a hitch rated with the appropriate capacity to match the trailer and boat's gross weight.



#### **WARNING**

**Loss of control can cause death or serious injury. DO NOT attempt to tow more than one trailer at a time behind your vehicle. Attempting to tow an additional trailer will adversely affect the trailer tongue weight.**



#### **CAUTION**

**DO NOT use a bumper mounted hitch on your vehicle. Use a hitch that is attached to the frame of your vehicle only. DO NOT compromise your equipment, your safety or the safety of others.**

### Wiring

The trailer requires wiring from your vehicle to the trailer lights. This can usually be done by the hitch company.

### Security

There are several locking devices available at marine supply stores to aid in securing your boat whether or not it is attached to your vehicle.



## Section 9

---

### Towing Your Boat

Read this checklist prior to trailering your boat.

- Check wheel lug nuts for tightness.
- Be sure the trailer tongue is securely on the hitch and the safety chains from the trailer are secured to the vehicle.
- Be sure a cable or strap secures the bow eye of the boat to the trailer. Make sure this is tightly secured.
- Be sure the trailer electrical connector is plugged in. Allow sufficient slack for cornering. Check brake lights, turn signals, emergency flasher and running lights.
- Be sure your gear inside the boat and seat cushions cannot shift or fly out of the boat during trailering.
- Be sure the walk-thru door of the windshield is closed and latched while the boat is being trailered.
- If you are using any sort of water "ballast" system to add weight to the boat, be sure it is drained before you put the boat on the trailer. These systems can adversely affect the tongue weight of the trailer. Your boat is not designed to carry exceptionally heavy loads. This can adversely affect the proper balance of the boat/trailer combination and cause tire failure and/or loss of control.
- If your boat is equipped with a trailer bow winch, make sure the boat is properly located on the trailer and the winch strap/cable is tight.
- Make sure the platform bracket pins are in place before trailering.
- Remove bilge drain plug(s).





## Long Trips

DO NOT use your boat and trailer to haul excessive gear.

Each time you stop on a long trip, check the following:

- Make sure the wheel lug nuts are tight and the bearings are lubricated.
- Make sure the boat is still positioned snugly against the bow stops.
- Examine the hitch connection to be sure it is firmly attached and the safety pin and chains are securely fastened.
- Make sure all trailer lights are still functioning properly.
- Re-examine the contents of your boat to ensure that no items such as life jackets or other gear have shifted and will not fly out while you are on the road.



### NOTES





## Glossary

**ABYC** – American Boat and Yacht Council, Inc.

**AFLOAT** – On the water.

**AFT** – Toward the rear or stern of the boat.

**AGROUND** – Touching bottom.

**AMIDSHIP** – Center or middle of the boat.

**ANCHOR** – (1) An iron casting shaped to grip the lake bottom to hold the boat. (2) The act of setting the anchor.

**ANODE** – An electrode carrying a positive charge.

**ASHORE** – On the shore.

**ASTERN** – Toward the stern.

**BAIL** – To remove water from the bottom of the boat with a pump, bucket, sponge, etc.

**BALLAST** – Any solid or liquid weight placed in a boat to increase the draft, to change the trim.

**BEAM** – The widest point on the boat.

**BEARING** – Relative position or direction of an object from the boat.

**BILGE** – The lowest interior section of the boat hull.

**BOARDING** – To enter the boat.

**BOUNDARY WATERS** – A body of water between two areas of jurisdiction; i.e., a river between two states.

**BOW** – The forward end of the boat.

**BULKHEAD** – Vertical partition (wall) in a boat.

**BUNKS** – Carpeted trailer hull supports.

**BURDENED BOAT** – Term for the boat that must "give-way" to boats with the right-of-way.

**CAPACITY PLATE** – A plate that provides maximum weight capacity and engine horsepower rating information. It is located in full view of the helm.

**CAPSIZE** – To turn over.

---

**CAST-OFF** – To unfasten mooring lines in preparation for departure.

**CATHODE** – An electrode carrying a negative charge.

**CAVITATION** – A phenomenon in which low pressure within a liquid allows vapor bubbles to form.

**CENTER LINE** – A lengthwise imaginary line which runs fore and aft with the boat's keel.

**CHINE** – The point on a boat where the side intersects (meets) the bottom.

**CLEAT** – A deck fitting with ears to which lines are fastened.

**CONSOLE** – Also called helm. The steering wheel area of the boat.

**CRANKING BATTERY** – The main battery used for engine starting and electrical circuits.

**CURRENT** – Water moving in a horizontal direction.

**DEADRISE** – Transverse angle of the bottom of the hull.

**DECK** – The open surface on the boat where the passengers walk.

**DRAFT** – The depth of the boat below the water line, measured vertically to the lowest part of the hull.

**ELECTROLYSIS** – The break-up of metals due to the effects of galvanic corrosion.

**FENDER** – Devices built into or hung over the sides of a boat to prevent the boat from rubbing or chafing against other boats or piers.

**FORE** – Toward the front or bow of the boat. Opposite of aft.

**FREEBOARD** – The distance from the waterline to the upper surface of the side of the deck.

**FUEL SENDING UNIT** – The electrical device that is mounted on the outside of a built-in fuel tank and controls the dashboard fuel gauge.

**GIVE-WAY BOAT** – (1) Term for the boat that must take whatever action necessary to keep well clear of the boat with the right-of-way in meeting or crossing situations. (2) The burdened boat.

**GUNWALE** – The rail or upper edge of a boat's side.

**HEAD** – A marine toilet.

**HELM** – The steering wheel or command area.

**HULL** – The structural body of a boat below the deck.





---

**HYPOTHERMIA** – A physical condition where the body loses heat faster than it can produce it.

**IN-LINE FUSE** – A type of protective fuse located in the power wire of a direct current (DC) circuit usually near the battery.

**KEEL** – The lowest portion of the boat; extends fore and aft along the boat's bottom.

**LINE** – All rope in a boat or on the dock is referred to as "line."

**LIST** – Leaning or tilt of a boat toward the side.

**MAKING WAY** – Making progress through the water.

**MARINE CHART** – Seagoing maps showing depths, buoys, navigation aids, etc.

**MID SHIP (AMIDSHIP)** – In the vicinity of the mid-length of a boat, technically the exact half way between the bow and the stern.

**MOORING** – An anchor, chain, or similar device that holds a boat in one location.

**NAVIGATION AID** – Recognizable objects on land or sea such as buoys, towers or lights which are used to fix position to identify safe and unsafe waters.

**NMMA** – National Marine Manufacturer's Association

**NO-WAKE SPEED** – The speed at which a boat travels to produce an imperceptible wake.

**PFD** – Personal flotation device.

**PITOT TUBE** – See SPEEDOMETER PICKUP TUBE.

**PLANING HULL** – A hull designed to lift, thereby reducing friction and increasing efficiency.

**PORPOISE** – A condition in which the bow bounces up and down caused by trimming the engine too far out.

**PORT** – (1) The left side of a boat when facing the bow. (2) A destination or harbor.

**PRIVILEGED BOAT** – Term used for the boat with the right-of-way.

**PROPELLER PITCH** – Theoretical linear distance the propeller would move ahead during one complete revolution of it were turning with zero slippage.

**RIGHT-OF-WAY** – Term for the boat that has priority in meeting or crossing situations. The stand on or privileged boat.

**RUB RAIL** – The rubber extrusion that is fastened over the hull and deck joint.





## **Warranty**

### **NAUTIQUE LIMITED WARRANTY**

**(Nautique Boats as Originally Manufactured by Nautique Boat Company)**

The Nautique warranty is backed by a tradition of boat building experience since 1925.

#### **Lifetime Limited Warranty:**

Nautique Boat Company, Inc., exclusive manufacturer of Nautique, and also referred to as Nautique herein, warrants to the original user or purchaser, whoever comes first, of each new Nautique boat, that the deck, hull, and stringer system, as originally manufactured by Nautique, shall, under normal authorized use, remain free from structural defect in material and workmanship. For purposes of this warranty, the terms “Nautique Boat Company” and its Trademark “Nautique” are used interchangeably to refer to Nautique Boat Company, Inc., exclusive manufacturer of Nautique brand boats.

#### **Transferable Lifetime Limited Warranty:**

In addition, Nautique offers a Transferable Lifetime Limited Warranty against structural defect of the deck, hull and stringer system as detailed in the Lifetime Limited Warranty above. This policy may be transferred for a nominal fee to the second (2nd) purchaser during a period of five (5) years or five hundred (500) hours (whichever occurs first), from the date of delivery to the original user or purchaser. See owner’s manual for proper form.

**Exceptions:** The “Lifetime” and “Transferable” warranties do not cover the gelcoat, nor any other components fastened or applied to the hull or deck. Gel coat discoloration, blisters, or bubbles and cracks are not considered structural defects.

---

### **Boat Five (5) Year Transferable Limited Warranty:**

Nautique warrants to the original user or purchaser, whichever comes first, that each new Nautique boat, as originally manufactured by Nautique, shall, under normal authorized use, be free of defect in material and workmanship for a period of five (5) years or five hundred (500) hours (whichever occurs first), from the date of delivery. This coverage applies to factory-installed components including boat parts, options, or other components not manufactured by Nautique Boat Company. The remaining portion of this warranty may be transferred for a nominal fee to the second (2nd) purchaser during a period of five (5) years or five hundred (500) hours (whichever occurs first), from the date of delivery. See owner's manual for proper form.

### **Gel Coat Three (3) Year Transferable Limited Warranty:**

Nautique warrants to the original user or purchaser, whichever comes first, of each new Nautique boat that the gel coat, under normal authorized use, shall remain free from defect in material and workmanship (including: cracks not caused by negligence, impact or collision) for a period of three (3) years or three (300) hours (whichever occurs first), from date of delivery. **See owner's manual for owner's gel coat maintenance responsibilities.**

### **Engine/Power Train Warranty:**

Five (5) years or five hundred (500) hours (whichever occurs first). For details see Pleasurecraft Marine Engine Co., owner's manual.

### **Exceptions:**

This Nautique Limited Warranty shall not apply to:

- Normal maintenance of boat, or any component thereof, including but not limited to, vinyl care, alignment, adjustments, connectors, saltwater/brackish water corrosion, and wear items including, but not limited to, non-skid material, battery, bushings, packing material, bulbs, seals, gaskets, impellers, carpet backing.
- Gelcoat finish or colorfastness of gelcoat finish, blisters, chrome plated, anodized or aluminum finish or colorfastness or fading of finish, on carpet or vinyl.





- Damage or malfunction of a boat, or any component thereof, resulting from owner use, lack of maintenance, improper maintenance, impact, misuse, negligence, collision, delay of repair (unless specifically and directly authorized by the Nautique warranty department in writing), trailer or trailer design, improper or inadequate trailering or cradling of the boat.
- Any addition, modification or repair of the boat, or any component thereof, caused by, resulting from or in connection with any party other than Nautique or any defect or product failure caused by, resulting from or in connection with any such addition, modification or repair.
- Any Nautique boat which has been repossessed or sold through an auction house, third party, or unauthorized dealer.
- Any and all consequential damages including, but not limited to, costs incurred for haul-out, launching, towing, and storage charges, telephone or rental charges of any type, inconveniences, or loss of time or income.

**All warranty repairs must be performed in the country of purchase (warranty will not be honored in cross-international-border purchases).**

Any defect or damage covered by this warranty shall, at the discretion of Nautique, be repaired free of charge at an authorized dealership or service facility. Repairs will be warranted only for the remainder of the original warranty period. Transportation and/or labor to and from the point of repair will be the responsibility of the owner.



---

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION OF THE FACE HEREOF. THIS LIMITED WARRANTY IS EXPRESSLY MADE IN LIEU OF ALL OTHER EXPRESSED WARRANTIES. DURATION OF ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, SHALL BE LIMITED TO AND COINCIDENT TO THE DURATION OF THESE EXPRESSED WARRANTIES. UNDER NO CIRCUMSTANCES SHALL NAUTIQUE, INC. BE LIABLE TO THE PURCHASER OR ANY THIRD PARTY FOR LOSS OF PROFITS OR OTHER DIRECT OR INDIRECT COSTS, LOSSES OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR AS A RESULT OF DEFECTS IN PRODUCTS HEREIN ABOVE WARRANTED.

Some states do not allow limitations on how long an implied warranty lasts. Some states do not allow the exclusion or limitation of incidental or consequential damages. This warranty gives you specific legal rights, and you also have other rights which may vary from state to state. To the extent that your state does not allow any exclusion or limitation expressed herein, such exclusion or limitation will not apply to you. All other allowable limitations or exclusions shall apply to you.

**Note:** This warranty is expressly conditioned upon the completion of the electronic registration to Nautique. Although not obligated to and without creating such an obligation, this will enable Nautique to notify owners of any necessary performance or safety modifications to your boat, and to verify ownership in case a warranty claim is filed on the boat.

### **Procedure:**

In the event your Nautique boat has a claim covered by this warranty, the following procedure shall be allowed to secure performance of warranty obligations:

1. Notify the selling dealer, in writing, within thirty (30) days of the discovery of any claimed defect.
2. You may be required to transport the boat, at your expense, to an authorized dealership or service facility for their inspection and/or repair.



3. Nautique reserves the right to require further evaluation and/or information regarding a warranty claim against a boat prior to its repair as well as designate the place of repair.

Nautique reserves the right to make changes in prices, color, specifications, equipment, options, materials, hull, decks, and/or discontinue models at any time (without notice), and shall be under no obligation to equip or modify boats built prior to such changes.

Nautique Customer Care, 14700 Aerospace Parkway, Orlando, Florida 32832. (407)855-4141, FAX (407)851-7844, email: info@nautique.com. **Effective 2016 model boats.**

## **NAUTIQUE COASTAL EDITION LIMITED WARRANTY**

(Nautique Boats as Originally Manufactured by Nautique Boat Company, Inc.)

The Nautique warranty is backed by a tradition of boat building experience since 1925.

### **Lifetime Limited Warranty:**

Nautique Boat Company, Inc., exclusive manufacturer of Nautique, and also referred to as Nautique herein, warrants to the original user or purchaser, whoever comes first, of each new Nautique boat, that the deck, hull, and stringer system, as originally manufactured by Nautique, shall, under normal authorized use, remain free from structural defect in material and workmanship. For purposes of this warranty, the terms “Nautique Boat Company” and its Trademark “Nautique” are used interchangeably to refer to Nautique Boat Company, Inc., exclusive manufacturer of Nautique brand boats.

### **Transferable Lifetime Limited Warranty:**

In addition, Nautique offers a Transferable Lifetime Limited Warranty against structural defect of the deck, hull and stringer system as detailed in the Lifetime Limited Warranty above. This policy may be transferred for a nominal fee to the second (2nd) purchaser during a period of three (3) years or three hundred (300) hours (whichever occurs first), from the date of delivery to the original user or purchaser. See owner’s manual for proper form.



---

**Exception:** The “Lifetime” and “Transferable” warranties do not cover the gel coat, nor any other components fastened or applied to the hull or deck. Gel coat discoloration, blisters, or bubbles and cracks are not considered structural defects.

### **Boat Three (3) Year Transferable Limited Warranty:**

Nautique warrants to the original user or purchaser, whichever comes first, that each new Nautique boat, as originally manufactured by Nautique, shall under normal authorized use be free of defect in material and workmanship for a period of three (3) years or three hundred (300) hours (whichever occurs first), from the date of delivery. This coverage applies to factory-installed components including, boat parts, options, or other components not manufactured by Nautique Boat Company. The remaining portion of this warranty may be transferred for a nominal fee to the second (2nd) purchaser during a period of three (3) years or three hundred (300) hours (whichever occurs first), from the date of delivery. See owner’s manual for proper form.

**Exposure to a salt or brackish water environment can cause corrosion or damage. Failure to rinse thoroughly after each use and apply a protective coating will void warranty.**

### **Gel Coat One (1) Year Transferable Limited Warranty:**

Nautique warrants to the original user or purchaser, whichever comes first, of each new Nautique boat that the gel coat, under normal authorized use, shall remain free from defect in material and workmanship (including cracks not caused by negligence, impact or collision) for a period of three (3) years or three hundred (300) hours (whichever occurs first), from date of delivery. **See owner’s manual for owner’s gel coat maintenance responsibilities.**

### **Engine/Power Train Warranty:**

Three (3) years or three hundred (300) hours (whichever occurs first), for details see Pleasurecraft Marine Engine Co. owner’s manual.



## Exceptions:

This Nautique Coastal Edition Limited Warranty shall not apply to:

- Normal maintenance of boat, or any component thereof, including but not limited to alignment, adjustments, connectors, saltwater/brackish water corrosion, and wear items including, but not limited to, non-skid material, battery, bushings, packing material, bulbs, seals, gaskets, impellers, carpet backing.
- Gel coat finish or colorfastness of gel coat finish, blisters, chrome plated, anodized or aluminum finish or colorfastness of finish.
- Damage or malfunction of a boat, or any component thereof, resulting from owner use, lack of maintenance, improper maintenance, impact, misuse, negligence, collision, delay of repair (unless specifically and directly authorized by the Nautique warranty department in writing), trailer or trailer design, improper or inadequate trailering or cradling of the boat.
- Any addition, modification or repair of the boat, or any component thereof, caused by, resulting from or in connection with any party other than Nautique, or any defect or product failure caused by, resulting from or in connection with any such addition, modification or repair.
- Any Nautique boat which has been repossessed or sold through an auction house, third party or unauthorized Nautique dealer.
- Any and all consequential damages including, but not limited to, costs incurred for haul-out, launching, towing, and storage charges, telephone or rental charges of any type, inconveniences, or loss of time or income.

**All warranty repairs must be performed in the country of purchase (warranty will not be honored in cross-international-border purchases).**

Any defect or damage covered by this warranty shall, at the discretion of Nautique, be repaired free of charge at an authorized dealership or service facility. Repairs will be warranted only for the remainder of the original warranty period. Transportation and/or labor to and from the point of repair will be the responsibility of the owner.



---

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION OF THE FACE HEREOF. THIS LIMITED WARRANTY IS EXPRESSLY MADE IN LIEU OF ALL OTHER EXPRESSED WARRANTIES. DURATION OF ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, SHALL BE LIMITED TO AND COINCIDENT TO THE DURATION OF THESE EXPRESSED WARRANTIES. UNDER NO CIRCUMSTANCES SHALL NAUTIQUE, INC. BE LIABLE TO THE PURCHASER OR ANY THIRD PARTY FOR LOSS OF PROFITS OR OTHER DIRECT OR INDIRECT COSTS, LOSSES OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR AS A RESULT OF DEFECTS IN PRODUCTS HEREIN ABOVE WARRANTED.

Some states do not allow limitations on how long an implied warranty lasts. Some states do not allow the exclusion or limitation of incidental or consequential damages. This warranty gives you specific legal rights, and you also have other rights which may vary from state to state. To the extent that your state does not allow any exclusion or limitation expressed herein, such exclusion or limitation will not apply to you. All other allowable limitations or exclusions shall apply to you.

**Note:** This warranty is expressly conditioned upon the completion of the electronic registration to Nautique. Although not obligated to and without creating such an obligation, this will enable Nautique to notify owners of any necessary performance or safety modifications to your boat, and to verify ownership in case a warranty claim is filed on the boat.



## Procedure:

In the event your Nautique boat has a claim covered by this warranty, the following procedure shall be allowed to secure performance of warranty obligations:

- Notify the selling dealer, in writing, within thirty (30) days of the discovery of any claimed defect.
- You may be required to transport the boat, at your expense, to an authorized dealership or service facility for their inspection and/or repair.
- Nautique reserves the right to require further evaluation and/or information regarding a warranty claim against a boat prior to its repair as well as designate the place of repair.

Nautique reserves the right to make changes in prices, color, specifications, equipment, options, materials, hull, decks, and/or discontinue models at any time (without notice), and shall be under no obligation to equip or modify boats built prior to such changes.

Nautique Customer Care, 14700 Aerospace Parkway, Orlando, Florida 32832. (407)855-4141, FAX (407)851-7844, email: [info@nautique.com](mailto:info@nautique.com). **Effective 2016 Coastal Edition model boats.**





**REQUEST FOR TRANSFER OF WARRANTY ON  
HULL, DECK AND STRINGER**

\*\* A COPY OF THE PURCHASE RECEIPT MUST BE INCLUDED \*\*

At Nautique Boat Company, Inc.'s discretion, the remaining portion of the Nautique "Lifetime Limited Warranty" against structural defects in material and workmanship of the hull, deck and stringer for **2016** model boats can be transferred, for a nominal fee, to the second purchaser within five (5) years or five hundred (500) hours (whichever occurs first) and three (3) years or three hundred (300) hours (whichever occurs first) for Coastal Edition Boats from the date of sale to the first purchaser. The sale must be completed within five (5) years or five hundred (500) hours (whichever occurs first) and three (3) years or three hundred (300) hours (whichever occurs first) for Coastal Edition boats. The limited warranty will be transferred upon the receipt and verification of: (1) this completed form, (2) a copy of the purchase receipt, (3) a payment of **\$300.00**, payable to "Nautique Boat Company, Inc." These documents **MUST BE RECEIVED WITHIN 15 DAYS OF THE SALE DATE**. The warranty will be transferred retroactive to the sale date. Refer to the warranty policy for details.

**NOTE: THIS TRANSFER DOES NOT INCLUDE THE ENGINE.**

ORIGINAL OWNER: \_\_\_\_\_

BOAT MODEL: \_\_\_\_\_

HULL NUMBER (USCTC...): \_\_\_\_\_

**NEW OWNER INFORMATION:**

NAME: \_\_\_\_\_

STREET/P.O. BOX: \_\_\_\_\_

CITY/STATE/ZIP CODE: \_\_\_\_\_

DATE PURCHASED: \_\_\_\_/\_\_\_\_/\_\_\_\_      PHONE: \_\_\_\_\_

ENGINE HOURS: \_\_\_\_\_

EMAIL (FOR CONFIRMATION): \_\_\_\_\_

The criteria listed above **MUST** be received **WITHIN 15 DAYS** of the sale date. Submit to:

Nautique Boat Company, Inc.,  
Attention: Warranty Department  
14700 Aerospace Parkway  
Orlando, FL 32832







## REQUEST FOR TRANSFER OF WARRANTY

**\*\* A COPY OF THE PURCHASE RECEIPT MUST BE INCLUDED \*\***

At Nautique Boat Company, Inc.'s discretion, the remaining portion of the Nautique "Transferable Limited Warranty" and the Pleasurecraft Marine "Transferable Limited Warranty" of **2016** model boats can be transferred, for a nominal fee, to the second purchaser within five (5) years or five hundred (500) hours (whichever occurs first) and three (3) years or three hundred (300) hours (whichever occurs first) on Coastal Edition boats from the date of sale to the first purchaser. The sale must be completed within the first five (5) years or five hundred (500) hours (whichever occurs first) and three (3) years or three hundred (300) hours (whichever occurs first) on Coastal Edition Boats. The limited warranty will be transferred upon the receipt and verification of: (1) this completed form, (2) a copy of the purchase receipt, (3) a payment of **\$550.00**, payable to "Nautique Boat Company, Inc." These documents **MUST BE RECEIVED WITHIN 15 DAYS OF THE SALE DATE**. The warranty will be transferred retroactive to the sale date. Refer to the warranty policy for details.

ORIGINAL OWNER: \_\_\_\_\_

BOAT MODEL: \_\_\_\_\_

HULL NUMBER (USCTC...): \_\_\_\_\_

### NEW OWNER INFORMATION:

NAME: \_\_\_\_\_

STREET/P.O. BOX: \_\_\_\_\_

CITY/STATE/ZIP CODE: \_\_\_\_\_

DATE PURCHASED: \_\_\_\_/\_\_\_\_/\_\_\_\_ PHONE: \_\_\_\_\_

ENGINE HOURS: \_\_\_\_\_

EMAIL (FOR CONFIRMATION): \_\_\_\_\_

As the second owner of the vessel, I recognize that this warranty covers parts only, and does not include labor.

SIGNATURE \_\_\_\_\_

The criteria listed above **MUST** be received **WITHIN 15 DAYS** of the sale date. Submit to:

Nautique Boat Company, Inc.,  
Attention: Warranty Department  
14700 Aerospace Parkway  
Orlando, FL 32832



---

# NOTES







***NAUTIQUE®***

**14700 Aerospace Parkway • Orlando, FL 32832**

**1-800-346-2092 • [www.nautique.com](http://www.nautique.com)**