

SYSTEM MENU MAP FOR Xy6.4

SLALOM

[165 r 730 34.2]
[v = abt 16.93 OK]
[SPEED ADJ 34.2]
[v = KX, PX ^ = SSB]
[SLALOM ^ = jmp]
[RECAL 34.2 ^ = Y]
[RPM @ 34.2 3450]
[WIND ADJ 000]
[CREW ADJ 420]

SLALOM TOURN. MODE

[+00 165 lbs. 34.2]
[v = ABT 16.93 OK]
[SPEED ADJ 34.2]
[WEIGHT lbs 165]
[KX NORMAL]
[PX 10]
[SSB 12]
[CREW ADJ 420]

JUMP

[JUMP K^ 720 33.6]
[54.8 2.72 OK]
[ADJUST 00 RPM]
[SPEED ADJ 33.6]
[v = S2% ^ = NEW JMPR]
[JUMP ^ = trk]
[RECAL 33.6 ^ = Y]
[RPM 33.6 3270]
[CREW ADJ]

JUMP TOURN. MODE

[+00 K FAST 33.6]
[v = S2% ^ = NEW JMPR]
[LETTER K FAST]
[5.48 2.72 OK]
[JUMP ^ = trk]
[RECAL 33.6 ^ = Y]
[RPM @ 33.6 3270]
[CREW ADJ 420]

TRICK

[TRICK 17.5 00]
[CALIBRATE SPEEDO]
[TRICK ^ = wkb]

WAKEBOARD RPM

[2400 w 720 0.0]
[WKBD RPM ^ = spd]

WAKEBOARD SPEED

[WAKB D 20.0 0.0]
[CALIBRATE SPEEDO]
[WKBD SPD ^ = mgt]

MAGNET TEST

[MAGN T 00 0.0]
[MAGT TEST ^ = slm]
[DEVICE TEST ^ = Y]

DEVICE TESTING

[ROPE SWITCH TEST]
[FALL BUTTON TEST]
[VOLTS/SERVO TEST]
[13.0 = OK SERVO OFF]
[12.8 = OK SERVO ON]
[IN NEUTRAL ^ = YES]
[ROTATE SERVO ^ = YES]
[RESET SERVO ^ = YES]

* To travel downward through the list, press Menu Key to move to next item.

** One more press of Menu Key at the bottom of list will take you back to the top.